

AIRSTAGE

AIR CONDITIONER

Wall mounted type

FUJITSU

REFRIGERANT **R32**
INVERTER

SERVICE MANUAL

INDOOR



ASUH09KPAS
ASUH12KPAS




ASUH18KPAS
ASUH24KPAS



ASUH30KPAS
ASUH36KPAS

OUTDOOR



AOUH09KPAS1
AOUH12KPAS1



AOUH18KPAS1
AOUH24KPAS1



AOUH30KPAS1
AOUH36KPAS1

FUJITSU GENERAL LIMITED

Notices:

- Product specifications and design are subject to change without notice for future improvement.
- For further details, please check with our authorized dealer.

Trademarks

“AIRSTAGE Mobile” is a trademark of FUJITSU GENERAL LIMITED.

Google Play™ is trademark of Google LLC.

App Store® is a service mark of Apple Inc., registered in the U.S. and other countries.

CONTENTS

1. GENERAL INFORMATION

2. TECHNICAL DATA AND PARTS LIST

3. TROUBLESHOOTING

4. CONTROL AND FUNCTIONS

5. FIELD WORKING

1. GENERAL INFORMATION

CONTENTS

1. GENERAL INFORMATION

1. Specifications.....	01-1
1-1. Indoor unit	01-1
1-2. Outdoor unit.....	01-7
2. Dimensions.....	01-10
2-1. Indoor unit	01-10
2-2. Outdoor unit.....	01-17

1. Specifications

1-1. Indoor unit

■ Models: ASUH09KPAS and ASUH12KPAS

Type				Wall mounted		
				Inverter, Heat pump		
Model name				ASUH09KPAS	ASUH12KPAS	
Power supply intake				Outdoor unit		
System power supply		Voltage		208/230		
		Frequency		60		
		Available voltage range		187—253		
Indoor unit power supply (from outdoor unit)				208/230		
Capacity	Cooling		Rated	kW	2.64	3.52
				Btu/h	9,000	12,000
			Min.—Max.	kW	0.90—3.28	0.90—4.00
	Btu/h	3,100—11,200		3,100—13,600		
	Heating	47°FDB (Outdoor temp.)	Rated	kW	2.93	4.10
				Btu/h	10,000	14,000
			Min.—Max.	kW	0.70—4.00	0.80—4.98
				Btu/h	2,400—13,600	2,700—17,000
		17°FDB (Outdoor temp.)* ¹	Rated	kW	1.87	2.55
				Btu/h	6,400	8,700
			Max.	kW	2.64	3.22
				Btu/h	9,000	11,000
		5°FDB (Outdoor temp.)* ²	Rated	kW	2.09	2.50
				Btu/h	7,100	8,500
Max.			kW	2.09	2.50	
	Btu/h		7,100	8,500		
Input power	Cooling		Rated		0.72	1.03
					Min.—Max.	0.12—1.13
	Heating	47°FDB (Outdoor temp.)	Rated	kW	0.70	1.08
					Min.—Max.	0.11—1.18
		17°FDB (Outdoor temp.)* ¹	Rated	0.61	0.89	
				Max.	1.0	1.2
			5°FDB (Outdoor temp.)* ²	Rated	0.915	1.095
					Max.	0.915
	Fan		HIGH MED—HIGH MED MED—LOW LOW QUIET	W	21.8	26.3
					17.3	
					12.2	
					9.2	
					6.8	
					2.9	
Current		Cooling Heating	Rated	A	3.5	4.8
					3.4	5.0
EER2		Cooling		Btu/hW	12.5	11.7
COP2		Heating		kW/kW	4.18	3.80
SEER2		Cooling		Btu/hW	26.0	24.0
HSPF2		Heating			10.8	10.5
Power factor		Cooling		%	89.4	93.3
		Heating			89.5	93.9
Moisture removal			pints/h (L/h)	2.40 (1.12)	3.40 (1.59)	
Maximum operating current* ³		Cooling	A	6.4	6.9	
		Heating		7.9		
Fan	Airflow rate	Cooling	CFM (m ³ /h)	394 (670)	430 (730)	
				MED—HIGH	365 (620)	
				MED	318 (540)	
				MED—LOW	283 (480)	
				LOW	247 (420)	
				QUIET	153 (260)	
		Heating		HIGH	430 (730)	436 (740)
				MED—HIGH	365 (620)	394 (670)
				MED	336 (570)	365 (620)
				MED—LOW	300 (510)	330 (560)
				LOW	265 (450)	300 (510)
				QUIET	188 (320)	
	Type × Qty		Crossflow fan × 1			
	Motor output			W	30	
Sound pressure level* ⁴	Cooling	HIGH MED—HIGH MED MED—LOW LOW QUIET	dB (A)	40	42	
				MED—HIGH	38	
				MED	34	
				MED—LOW	32	
				LOW	29	
				QUIET	19	
	Heating	HIGH MED—HIGH MED MED—LOW LOW QUIET		42		
				38	39	
				36	38	
				33	35	
				31	33	
				21		

Type				Wall mounted			
				Inverter, Heat pump			
Model name				ASUH09KPAS		ASUH12KPAS	
Heat exchanger type		Dimensions (H × W × D)		in (mm)		Main 1: 8-1/4 × 26-5/16 × 1-1/16 (210 × 668 × 26.6) Main 2: 4-7/16 × 26-5/16 × 13/16 (112 × 668 × 20.0)	
		Fin pitch		FPI		Main 1: 21 Main 2: 23	
		Rows × Stages				Main 1: 2 × 10 Main 2: 2 × 7	
		Pipe type				Copper tube	
		Fin type				Aluminum	
Enclosure		Material				Polystyrene	
		Color				White Approximate color of Munsell N9.25/	
Dimensions (H × W × D)		Net		in (mm)		10-5/8 × 32-13/16 × 8-3/4 (270 × 834 × 222)	
		Gross				10-7/8 × 36 × 13-1/16 (277 × 914 × 332)	
Weight		Net		lb (kg)		21 (9.5)	
		Gross				26 (12.0)	
Connection pipe		Size		in (mm)		Ø1/4 (Ø6.35)	
		Liquid				Ø3/8 (Ø9.52)	
		Gas					
		Method				Flare	
Drain hose		Material				Polypropylene + High-density polyethylene	
		Tip diameter		in (mm)		I.D.: Ø17/32 (Ø13.8), O.D.: Ø19/32 to Ø21/32 (Ø15.0 to Ø16.8)	
Operation range		Cooling		°F (°C)		64 to 90 (18 to 32)	
		Heating		%RH		80 or less	
				°F (°C)		60 to 86 (16 to 30)	
Remote controller type				Wireless (Option: Wired, Mobile app*5 [AIRSTAGE Mobile])			
NOTES:							
<ul style="list-style-type: none">Specifications are based on the following conditions:<ul style="list-style-type: none">Cooling: Indoor temperature of 80°FDB/67°FWB (26.67°CDB/19.44°CWB), and outdoor temperature of 95°FDB/75°FWB (35°CDB/23.9°CWB).Heating: Indoor temperature of 70°FDB/60°FWB (21.11°CDB/15.56°CWB), and outdoor temperature of 47°FDB/43°FWB (8.33°CDB/6.11°CWB).*1: Heating (17°F): Indoor temperature of 70°FDB/60°FWB (21.11°CDB/15.56°CWB), and outdoor temperature of 17°FDB/15°FWB (-8.33°CDB/-9.44°CWB).*2: Heating (5°F): Indoor temperature of 70°FDB/60°FWB (21.11°CDB/15.56°CWB), and outdoor temperature of 5°FDB/4°FWB (-15.0°CDB/-15.56°CWB).Test conditions are based on AHRI 210/240 2023.Pipe length: 25 ft (7.5 m), Height difference: 0 ft (0 m). (Between outdoor unit and indoor unit.)Protective function might work when using it outside the operation range.*3: Maximum current:<ul style="list-style-type: none">The maximum value when operated within the operation range.The total current of indoor unit and outdoor unit.*4: Sound pressure level:<ul style="list-style-type: none">Measured values in manufacturer's anechoic chamber.Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.*5: Available on Google Play™ store or on App Store®. Optional WLAN Adapter is also required. For details, refer to the setting manual.							

Models: ASUH18KPAS and ASUH24KPAS

Type				Wall mounted				
				Inverter, Heat pump				
Model name				ASUH18KPAS		ASUH24KPAS		
Power supply intake				Outdoor unit				
System power supply		Voltage		V		208/230		
		Frequency		Hz		60		
		Available voltage range		V		187—253		
Indoor unit power supply (from outdoor unit)				V		208/230		
Capacity	Cooling		Rated	kW	5.28	6.45		
				Btu/h	18,000	22,000		
				Min.—Max.	kW	1.17—5.86	1.17—7.15	
				Btu/h	4,000—20,000	4,000—24,400		
	Heating	47°FDB (Outdoor temp.)	Rated	kW	5.28	7.03		
				Btu/h	18,000	24,000		
				Min.—Max.	kW	1.22—7.03	1.22—8.50	
				Btu/h	4,150—24,000	4,150—29,000		
			17°FDB (Outdoor temp.)*1	Rated	kW	3.31	4.34	
					Btu/h	11,300	14,800	
		Max.			kW	6.36	7.13	
			Btu/h	21,700	24,300			
		5°FDB (Outdoor temp.)*2	Rated	kW	5.42	5.86		
				Btu/h	18,500	20,000		
			Max.	kW	5.42	5.86		
				Btu/h	18,500	20,000		
Input power		Cooling		Rated	1.44	1.88		
	Min.—Max.				0.20—1.90	0.20—3.20		
	Heating	47°FDB (Outdoor temp.)	Rated	1.26	1.85			
				Min.—Max.	0.21—2.10	0.21—3.10		
		17°FDB (Outdoor temp.)*1	Rated	1.01	1.43			
				Max.	2.45	2.85		
			5°FDB (Outdoor temp.)*2	Rated	2.45	2.75		
					Max.	2.45	2.75	
	Fan		HIGH	38	69			
				MED—HIGH	34	46		
				MED	30	30		
				MED—LOW	24	24		
				LOW	19	19		
				QUIET	11	14		
	Current	Cooling		Rated	A	6.7	8.2	
					Heating	5.6	8.1	
EER2		Cooling		Btu/hW	12.5	11.7		
COP2		Heating		kW/kW	4.2	3.8		
SEER2		Cooling		Btu/hW	22.0	21.5		
HSPF2		Heating		Btu/hW	10.5	10.0		
Power factor		Cooling		%	97.3	99.2		
		Heating		%	98.0	98.9		
Moisture removal				pints/h (L/h)	4.9 (2.3)	6.3 (3.0)		
Maximum operating current*3		Cooling		A	9.9	14.4		
		Heating		A	11.9	13.9		
Fan	Airflow rate	Cooling	HIGH	CFM (m³/h)	536 (910)	689 (1,170)		
			MED—HIGH		506 (860)	583 (990)		
			MED		483 (820)			
			MED—LOW		430 (730)			
			LOW		377 (640)			
			QUIET		259 (440)	312 (530)		
		Heating	HIGH		506 (860)	600 (1,020)		
			MED—HIGH		465 (790)	553 (940)		
			MED		430 (730)	506 (860)		
			MED—LOW		388 (660)	441 (750)		
			LOW		347 (590)	377 (640)		
			QUIET		277 (470)	318 (540)		
	Type × Qty		Crossflow fan × 1					
	Motor output		W					
	Sound pressure level*4	Cooling		HIGH	dB (A)	44	51	
				MED—HIGH		43	48	
MED				42		43		
MED—LOW				40				
LOW				37				
QUIET				26		31		
Heating			HIGH	43		47		
			MED—HIGH	41		45		
			MED	39		43		
			MED—LOW	37		40		
			LOW	34		36		
			QUIET	28		32		
Heat exchanger type	Dimensions (H × W × D)		in (mm)	Main 1: 8-1/4 × 31-5/16 × 1-1/16 (210 × 796 × 26.6) Main 2: 5-5/16 × 31-5/16 × 13/16 (135 × 796 × 20.0) Sub 1: 3-5/16 × 31-5/16 × 1/2 (84 × 796 × 13.3) Sub 2: 3-5/16 × 31-5/16 × 1/2 (84 × 796 × 13.3)				
	Fin pitch		FPI	Main 1: 21 Main 2: 23 Sub 1: 18 Sub 2: 18				
	Rows × Stages			Main 1: 2 × 10 Main 2: 2 × 8 Sub 1: 1 × 4 Sub 2: 1 × 4				
	Pipe type			Copper tube				
	Fin type			Aluminum				

Type				Wall mounted			
				Inverter, Heat pump			
Model name				ASUH18KPAS		ASUH24KPAS	
Enclosure		Material		Polystyrene			
		Color		White Approximate color of Munsell N9.25/			
Dimensions (H × W × D)	Net		in (mm)	11 × 38-9/16 × 9-7/16 (280 × 980 × 240)			
	Gross			12-11/16 × 42-7/16 × 13-5/8 (322 × 1,078 × 346)			
Weight	Net		lb (kg)	28 (12.5)			
	Gross			36 (16.5)			
Connection pipe	Size	Liquid	in (mm)	Ø1/4 (Ø6.35)			
		Gas		Ø1/2 (Ø12.70)			
	Method			Flare			
Drain hose	Material			Polypropylene + High-density polyethylene			
	Tip diameter		in (mm)	Ø17/32 (Ø13.8) (I.D.), Ø19/32 to 21/32 (Ø15 to 16.8) (O.D.)			
Operation range	Cooling		°F (°C)	64 to 90 (18 to 32)			
			%RH	80 or less			
		Heating	°F (°C)	60 to 86 (16 to 30)			
Remote controller type				Wireless (Option: Wired, Mobile app* ⁵ [AIRSTAGE Mobile])			

NOTES:

- Specifications are based on the following conditions:
 - Cooling: Indoor temperature of 80°FDB/67°F_{WB} (26.67°CDB/19.44°C_{WB}), and outdoor temperature of 95°FDB/75°F_{WB} (35°CDB/23.9°C_{WB}).
 - Heating: Indoor temperature of 70°FDB/60°F_{WB} (21.11°CDB/15.56°C_{WB}), and outdoor temperature of 47°FDB/43°F_{WB} (8.33°CDB/6.11°C_{WB}).
 - *¹: Heating (17°F): Indoor temperature of 70°FDB/60°F_{WB} (21.11°CDB/15.56°C_{WB}), and outdoor temperature of 17°FDB/15°F_{WB} (-8.33°CDB/-9.44°C_{WB}).
 - *²: Heating (5°F): Indoor temperature of 70°FDB/60°F_{WB} (21.11°CDB/15.56°C_{WB}), and outdoor temperature of 5°FDB/4°F_{WB} (-15.0°CDB/-15.56°C_{WB}).
 - Test conditions are based on AHRI 210/240 2023.
 - Pipe length: 25 ft (7.5 m), Height difference: 0 ft (0 m). (Between outdoor unit and indoor unit.)
- Protective function might work when using it outside the operation range.
- *³: Maximum current:
 - The maximum value when operated within the operation range.
 - The total current of indoor unit and outdoor unit.
- *⁴: Sound pressure level:
 - Measured values in manufacturer's anechoic chamber.
 - Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.
- *⁵: Available on Google Play™ store or on App Store®. Optional WLAN Adapter is also required. For details, refer to the setting manual.

Models: ASUH30KPAS and ASUH36KPAS

Type				Wall mounted							
				Inverter, Heat pump							
Model name				ASUH30KPAS		ASUH36KPAS					
Power supply intake				Outdoor unit							
System power supply		Voltage		V		208/230					
		Frequency		Hz		60					
		Available voltage range		V		187—253					
Indoor unit power supply (from outdoor unit)				V		208/230					
Capacity	Cooling	Rated		kW		8.79		9.67			
				Btu/h		30,000		33,000			
		Min.—Max.		kW		2.90—9.50		2.90—10.00			
				Btu/h		9,900—32,400		9,900—34,100			
	Heating	47°FDB (Outdoor temp.)	Rated		kW		8.79		9.96		
					Btu/h		30,000		34,000		
			Min.—Max.		kW		2.7—10.2		2.7—11.0		
					Btu/h		9,200—34,800		9,200—37,500		
		17°FDB (Outdoor temp.)*1	Rated		kW		5.74		6.56		
					Btu/h		19,600		22,400		
			Max.		kW		8.83				
					Btu/h		30,100				
		5°FDB (Outdoor temp.)*2	Rated		kW		7.56				
					Btu/h		25,800				
			Max.		kW		7.56				
					Btu/h		25,800				
Input power	Cooling	Rated		kW		2.56		3.39			
						Min.—Max.		0.45—3.42		0.45—3.82	
		Heating	47°FDB (Outdoor temp.)			Rated		2.43		3.02	
								Min.—Max.		0.52—3.00	
	17°FDB (Outdoor temp.)*1		Rated			1.89		2.27			
						Max.		3.68			
	5°FDB (Outdoor temp.)*2	Rated						3.43			
						Max.		3.43			
	Fan	HIGH MED—HIGH MED MED—LOW LOW QUIET		W		58					
						45					
						36					
						28					
						22					
						15					
	Current		Cooling	Rated		A		11.3		14.8	
			Heating					10.8		13.3	
EER2		Cooling		Btu/hW		11.7		9.75			
COP2		Heating		kW/kW		3.62		3.30			
SEER2		Cooling		Btu/hW		22		21			
HSPF2		Heating		Btu/hW		10.2		10.0			
Power factor		Cooling		%		98.5		99.6			
		Heating				97.8		98.7			
Moisture removal				pints/h (L/h)		9.1 (4.3)		10.4 (4.9)			
Maximum operating current*3		Cooling		A		18.4					
		Heating				17.9					
Fan	Airflow rate	Cooling	CFM (m³/h)		806 (1,370)						
					724 (1,230)						
					653 (1,110)						
					583 (990)						
					518 (880)						
					418 (710)						
		Heating			742 (1,260)						
					671 (1,140)						
					612 (1,040)						
					547 (930)						
					483 (820)						
					418 (710)						
	Type × Qty		Crossflow fan × 1								
	Motor output		W		78						
Sound pressure level*4		Cooling	dB (A)		51						
					49						
					46						
					43						
					39						
					32						
		Heating			48						
					45						
					42						
					39						
					36						
					32						
Heat exchanger		Dimensions (H × W × D)		in (mm)		18-3/16 × 35-3/8 × 1-1/16 (462 × 898 × 26.6)					
		Fin pitch		FPI		21					
		Rows × Stages		2 × 22							
		Pipe type		Copper							
Enclosure		Material		Polystyrene							
		Color		White							
Dimensions (H × W × D)		Net		in (mm)		13-3/8 × 45-1/4 × 11 (340 × 1,150 × 280)					
		Gross				15-15/16 × 50 × 17-11/16 (405 × 1,270 × 450)					
Weight		Net		lb (kg)		36 (16.5)					
		Gross				49 (22.0)					
Connection pipe		Size	Liquid	in (mm)		Ø3/8 (Ø9.52)					
			Gas			Ø5/8 (Ø15.88)					
		Method		Flare							

Type			Wall mounted	
			Inverter, Heat pump	
Model name			ASUH30KPAS	ASUH36KPAS
Drain hose	Material		Polypropylene + High-density polyethylene	
	Tip diameter		Ø17/32 (Ø13.8) (I.D.), Ø19/32 to 21/32 (Ø15.0 to 16.8) (O.D.)	
Operation range	Cooling	°F (°C)	64 to 90 (18 to 32)	
		%RH	80 or less	
	Heating	°F (°C)	60 to 86 (16 to 30)	
Remote controller type			Wireless (Option: Wired, Mobile app* ⁵ [AIRSTAGE Mobile])	
NOTES:				
<ul style="list-style-type: none">Specifications are based on the following conditions:<ul style="list-style-type: none">Cooling: Indoor temperature of 80°FDB/67°F WB (26.67°CDB/19.44°CWB), and outdoor temperature of 95°FDB/75°F WB (35°CDB/23.9°CWB).Heating: Indoor temperature of 70°FDB/60°F WB (21.11°CDB/15.56°CWB), and outdoor temperature of 47°FDB/43°F WB (8.33°CDB/6.11°CWB).*¹: Heating (17°F): Indoor temperature of 70°FDB/60°F WB (21.11°CDB/15.56°CWB), and outdoor temperature of 17°FDB/15°F WB (-8.33°CDB/-9.44°CWB).*²: Heating (5°F): Indoor temperature of 70°FDB/60°F WB (21.11°CDB/15.56°CWB), and outdoor temperature of 5°FDB/4°F WB (-15.0°CDB/-15.56°CWB).Test conditions are based on AHRI 210/240 2023.Pipe length: 25 ft (7.5 m), Height difference: 0 ft (0 m). (Between outdoor unit and indoor unit.)Protective function might work when using it outside the operation range.*³: Maximum current:<ul style="list-style-type: none">The maximum value when operated within the operation range.The total current of indoor unit and outdoor unit.*⁴: Sound pressure level:<ul style="list-style-type: none">Measured values in manufacturer's anechoic chamber.Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.*⁵: Available on Google Play™ store or on App Store®. Optional WLAN Adapter is also required. For details, refer to the setting manual.				

1-2. Outdoor unit

■ Models: AOUEH09KPAS1 and AOUEH12KPAS1

Type				Inverter, Heat pump	
Model name				AOUH09KPAS1	AOUH12KPAS1
Power supply				208/230 V~ 60 Hz	
Power supply intake				Outdoor unit	
Available voltage range				187—253 V	
Starting current			A	3.5	5.0
Fan	Airflow rate	Cooling	CFM (m³/h)	936 (1,590)	959 (1,630)
		Heating		959 (1,630)	818 (1,390)
	Type × Qty		Propeller fan × 1		
	Motor output		W	23	
Sound pressure level*1		Cooling	dB (A)	46	48
		Heating		48	
Heat exchanger type		Dimensions (H × W × D)	in (mm)	19-13/16 × 25-9/16 × 11/16 (504 × 650 × 18.2)	19-13/16 × 24-13/16 × 1-7/16 (504 × 630 × 36.4)
		Fin pitch	FPI	20	
		Rows × Stages		1 × 24	2 × 24
		Pipe type		Copper tube	
		Fin type		Type (Material)	Aluminum
Compressor		Type	DC rotary		
		Motor output	W	550	
Refrigerant		Type	R32		
		Charge	lb oz	1 lb 5 oz	1 lb 9 oz
Refrigerant oil			g	600	700
		Type	RB74AF		
Enclosure		Amount	in³ (cm³)	14.6 (240)	
		Material	Steel sheet		
		Color	Beige		
Dimensions (H × W × D)		Net	in (mm)	Approximate color of Munsell 10YR 7.5/1.0	
		Gross		21-5/16 × 26-1/8 × 11-7/16 (541 × 663 × 290)	
Weight		Net	lb (kg)	23-11/16 × 31-5/8 × 14-3/4 (602 × 804 × 375)	
		Gross		51 (23)	57 (26)
Connection pipe	Size	Liquid	in (mm)	57 (26)	
		Gas		Ø1/4 (Ø6.35)	
				Ø3/8 (Ø9.52)	
	Method	Flare			
	Pre-charge length		ft (m)	49 (15)	
	Min. length			10 (3)	
	Max. length			66 (20)	
Max. height difference		49 (15)			
Operation range		Cooling	°F (°C)	14 to 122*2 (-10 to 50*2)	
		Heating		5 to 75 (-15 to 24)	
Drain hose		Material	Polypropylene		
		Tip diameter	in (mm)	Ø1/2 (Ø13.0) (I.D.), Ø5/8 to Ø11/16 (Ø16.0 to Ø16.8) (O.D.)	
NOTES:					
<div><div><div><div><div><div></div></div></div><div><div><div></div></div><div><div></div></div></div><div><div><div></div></div><div><div></div></div></div><div><div><div></div></div><div><div></div></div></div></div><div><div><div></div></div><div><div></div></div></div><div><div><div></div></div><div><div></div></div></div></div><div><div><div></div></div><div><div></div></div></div><div><div><div></div></div><div><div></div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div></div></div></div> <div><div><div></div></div><div><div><</div></div></div>					

Models: AOUH18KPAS1 and AOUH24KPAS1

Type				Inverter, Heat pump	
Model name				AOUH18KPAS1	AOUH24KPAS1
Power supply				208/230 V~ 60 Hz	
Power supply intake				Outdoor unit	
Available voltage range				187—253 V	
Starting current			A	5.6	
Fan	Airflow rate	Cooling	CFM (m³/h)	1,218 (2,070)	1,719 (2,920)
		Heating		1,348 (2,290)	1,560 (2,650)
	Type × Qty			Propeller fan × 1	
Motor output			W	49	
Sound pressure level*1		Cooling	dB (A)	50	55
		Heating		50	54
Heat exchanger type		Dimensions (H × W × D)	in (mm)	Main 1: 23-1/8 × 34-11/16 × 11/16 (588 × 881 × 18.19) Main 2: 23-1/8 × 33-1/2 × 11/16 (588 × 851 × 18.19)	
		Fin pitch	FPI	Main 1: 20 Main 2: 20	
		Rows × Stages		Main 1: 1 × 28 Main 2: 1 × 28	
		Pipe type		Copper tube	
		Fin type	Type (Material)	Aluminum	
			Surface treatment	PC fin	
Compressor		Type	DC rotary		
		Motor output	W	1,060	
Refrigerant		Type	R32		
		Charge	lb oz	2 lb 10 oz	
			g	1,200	
Refrigerant oil		Type	RmM68AF		
		Amount	in³ (cm³)	24.4 (400)	
Enclosure		Material		Steel sheet	
		Color		Beige	
		Approximate color of Munsell 10YR 7.5/1.0			
Dimensions (H × W × D)		Net	in (mm)	24-7/8 × 31-7/16 × 11-7/16 (632 × 799 × 290)	
		Gross		27-1/4 × 37 × 14-3/4 (692 × 940 × 375)	
Weight		Net	lb (kg)	86 (39)	
		Gross		93 (42)	
Connection pipe	Size	Liquid	in (mm)	Ø1/4 (Ø6.35)	
		Gas		Ø1/2 (Ø12.70)	
		Method		Flare	
	Pre-charge length		ft (m)	49 (15)	
	Min. length			10 (3)	
	Max. length			98 (30)	
	Max. height difference			82 (25)	
Operation range		Cooling	°F (°C)	14 to 122*2 (-10 to 50*2)	
		Heating		5 to 75 (-15 to 24)	
NOTES:					
<div><div>• Specifications are based on the following conditions:</div><div><div>– Cooling: Indoor temperature of 80°FDB (26.67°CDB)/67°FWB (19.44°CWB), and outdoor temperature of 95°FDB (35°CDB)/75°FWB (23.9°CWB).</div><div>– Heating: Indoor temperature of 70°FDB (21.11°CDB)/59°FWB (15°CWB), and outdoor temperature of 47°FDB (8.33°CDB)/43°FWB (6.11°CWB).</div><div>– Pipe length: 25 ft (7.5 m), Height difference: 0 ft (0 m). (Between outdoor unit and indoor unit.)</div></div><div>• Protective function might work when using it outside the operation range.</div><div>• *1: Sound pressure level</div><div><div>– Measured values in manufacturer's semi-anechoic chamber.</div><div>– Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.</div></div><div>• *2: Suction temperature of the outdoor unit.</div></div>					

Models: AOUH30KPAS1 and AOUH36KPAS1


Type				Inverter, Heat pump	
Model name				AOUH30KPAS1	AOUH36KPAS1
Power supply				208/230 V~ 60 Hz	
Power supply intake				Outdoor unit	
Available voltage range				187—253 V	
Starting current			A	11.3	14.8
Fan	Airflow rate	Cooling	CFM (m³/h)	2,166 (3,680)	
		Heating		2,166 (3,680)	
	Type × Qty			Propeller fan × 1	
Motor output			W	100	
Sound pressure level*1		Cooling	dB (A)	53	54
		Heating		55	56
Heat exchanger type		Dimensions (H × W × D)	in (mm)	Main 1: 29-3/4 × 35-5/8 × 11/16 (756 × 905 × 18.19) Main 2: 29-3/4 × 35-5/8 × 11/16 (756 × 905 × 18.19)	
		Fin pitch	FPI	Main 1: 18 Main 2: 18	
		Rows × Stages		Main1: 1 × 36 Main2: 1 × 36	
		Pipe type		Copper tube	
		Fin type	Type (Material)	Aluminum	
			Surface treatment	Blue fin	
		Compressor		Type	DC twin rotary
Motor output	W			1,500	
Refrigerant		Type	R32		
		Charge	lb oz	3 lb 12 oz	
	g		1,700		
Refrigerant oil		Type	FW68D		
		Amount	in³ (cm³)	36.6 (600)	
Enclosure		Material		Steel sheet	
		Color		Beige Approximate color of Munsell 10YR 7.5/1.0	
Dimensions (H × W × D)		Net	in (mm)	31 × 37 × 12-5/8 (788 × 940 × 320)	
		Gross		38-1/16 × 40-7/16 × 17-1/2 (966 × 1,027 × 445)	
Weight		Net	lb (kg)	117 (53)	
		Gross		134 (61)	
Connection pipe	Size	Liquid	in (mm)	Ø3/8 (Ø9.52)	
		Gas		Ø5/8 (Ø15.88)	
		Method		Flare	
	Pre-charge length		ft (m)	66 (20)	
	Min. length			16 (5)	
	Max. length			164 (50)	
	Max. height difference			98 (30)	
	Operation range		Cooling	°F (°C)	14 to 122*2 (-10 to 50*2)
Heating			5 to 75 (-15 to 24)		
Drain hose		Material		Low-density polyethylene	
		Tip diameter	in (mm)	Ø1/2 (Ø13.0) (I.D.), Ø5/8 to Ø11/16 (Ø16.0 to Ø16.7) (O.D.)	
NOTES:					
<ul style="list-style-type: none">Specifications are based on the following conditions:<ul style="list-style-type: none">Cooling: Indoor temperature of 80°FDB (26.67°CDB)/67°FWB (19.44°CWB), and outdoor temperature of 95°FDB (35°CDB)/75°FWB (23.9°CWB).Heating: Indoor temperature of 70°FDB (21.11°CDB)/59°FWB (15°CWB), and outdoor temperature of 47°FDB (8.33°CDB)/43°FWB (6.11°CWB).Pipe length: 25 ft (7.5 m), Height difference: 0 ft (0 m). (Between outdoor unit and indoor unit.)Protective function might work when using it outside the operation range.*1: Sound pressure level<ul style="list-style-type: none">Measured values in manufacturer's semi-anechoic chamber.Because of the surrounding sound environment, the sound levels measured in actual installation conditions might be higher than the specified values here.*2: Suction temperature of the outdoor unit.					

2. Dimensions

2-1. Indoor unit

■ Models: ASUH09KPAS and ASUH12KPAS

Unit: in (mm)




● Installation space requirement

Provide sufficient installation space for product safety.

⚠ CAUTION



Do not place any other electrical products or household belongings under the product. Condensation dripping from the product might get them wet, and may cause damage or malfunction to the property.

Unit: in (mm)



Models: ASUH18KPAS and ASUH24KPAS

Unit: in (mm)





● Installation space requirement

Provide sufficient installation space for product safety.

⚠ CAUTION

Do not place any other electrical products or household belongings under the product. Condensation dripping from the product might get them wet, and may cause damage or malfunction to the property.

Unit: in (mm)





● Installation space requirement

Provide sufficient installation space for product safety.

⚠ CAUTION

Do not place any other electrical products or household belongings under the product. Condensation dripping from the product might get them wet, and may cause damage or malfunction to the property.

Unit: in (mm)




■ Pipe exit length from the rear

Design the system considering the length of the pipes or hose exiting from the rear of the indoor unit.

NOTE: Detailed shapes of the indoor unit and the tip of each pipe or hose may vary depending on the model.

Unit: in (mm)




Model name	Approximate length		
	a Gas pipe	b Liquid pipe	c Drain hose
ASUH09-12KPAS	14-15/16 (380)	16-15/16 (430)	18-7/8 (480)
ASUH18-24KPAS	16-15/16 (430)	19-1/8 (485)	18-1/2 (470)
ASUH30-36KPAS	21-7/8 (555)	19-1/8 (485)	20-1/4 (515)


2-2. Outdoor unit

■ Models: AOUH09KPAS1 and AOUH12KPAS1


Unit: in (mm)




Top view




Side view




Front view



Side view




Bottom view




Side view (Valve part)

Models: AOUH18KPAS1 and AOUH24KPAS1


Unit: in (mm)




Top view




Side view




Front view



Side view




Bottom view




Side view (Valve part)

Models: AOUH30KPAS1 and AOUH36KPAS1


Unit: in (mm)




Top view



Detail A




Detail B




Front view

Side view

Rear view



Bottom view



Detail C

2. TECHNICAL DATA AND PARTS LIST

CONTENTS

2. TECHNICAL DATA AND PARTS LIST

1. Precautions.....	02-1
2. Indoor unit parts list.....	02-2
2-1. Models: ASUH09KPAS and ASUH12KPAS	02-2
2-2. Models: ASUH18KPAS and ASUH24KPAS	02-6
2-3. Models: ASUH30KPAS and ASUH36KPAS	02-10
3. Outdoor unit parts list.....	02-14
3-1. Models: AOUH09KPAS1 and AOUH12KPAS1	02-14
3-2. Models: AOUH18KPAS1 and AOUH24KPAS1	02-18
3-3. Models: AOUH30KPAS1 and AOUH36KPAS1	02-22
4. Accessories	02-26
4-1. Indoor unit	02-26
4-2. Outdoor unit.....	02-28
5. Optional parts	02-29
5-1. Indoor unit	02-29
5-2. Outdoor unit.....	02-32
6. Refrigerant system diagrams	02-33
6-1. Models: AOUH09KPAS1 and AOUH12KPAS1	02-33
6-2. Models: AOUH18KPAS1 and AOUH24KPAS1	02-34
6-3. Models: AOUH30KPAS1 and AOUH36KPAS1	02-35
7. Wiring diagrams	02-36
7-1. Indoor unit	02-36
7-2. Outdoor unit.....	02-38
8. PC board diagrams	02-40
8-1. Models: ASUH09KPAS and ASUH12KPAS	02-40
8-2. Models: ASUH18KPAS and ASUH24KPAS	02-41
8-3. Models: ASUH30KPAS and ASUH36KPAS	02-42
8-4. Models: AOUH09KPAS1 and AOUH12KPAS1	02-43
8-5. Models: AOUH18KPAS1 and AOUH24KPAS1	02-44
8-6. Models: AOUH30KPAS1 and AOUH36KPAS1	02-45

1. Precautions

When you start servicing, pay attention to the following points. For detailed precautions, refer to the installation manual of the products.


CAUTION

-
- Service personnel
 - Any person who is involved with working on or breaking into a refrigerant circuit should hold a current valid certificate from an industry-accredited assessment authority, which authorizes their competence to handle refrigerants safely in accordance with an industry recognized assessment specification.
 - Servicing shall only be performed as recommended by the equipment manufacturer. Maintenance and repair requiring the assistance of other skilled personnel shall be carried out under the supervision of the person competent in the use of flammable refrigerants.
 - Servicing shall be performed only as recommended by the manufacturer.
 - Work
 - Prior to beginning work on systems containing flammable refrigerants, safety checks are necessary to ensure that the risk of ignition is minimized. When repairing the refrigerant system, refer to the precautions written in the installation manual of the products before you start servicing.
 - Work shall be undertaken under a controlled procedure so as to minimize the risk of a flammable gas or vapor being present while the work is being performed.
 - All maintenance staff and others working in the local area shall be instructed on the nature of work being carried out.
 - Work in confined spaces shall be avoided.
 - The area around the workspace shall be sectioned off.
 - Ensure that the conditions within the area have been made safe by control of flammable material.
 - Electric shock may occur. After turning off the power, always wait 5 minutes before touching electrical components.
 - Do not touch the fins of the heat exchanger. Touching the heat exchanger fins could result in damage to the fins or personal injury such as skin rupture.
 - Do not place any other electrical products or household belongings under the product.
 - Condensation dripping from the product might get them wet, and may cause damage or malfunction to the property.
 - Checking for presence of refrigerant
 - The area shall be checked with an appropriate refrigerant leak detector prior to and during work, to ensure the technician is aware of potentially flammable atmospheres.
 - Ensure that the leak detector being used is suitable for use with flammable refrigerants, i.e. non-sparking, adequately sealed or intrinsically safe.
-
- Service parts information and design are subject to change without notice for product improvement.
 - For the latest information of the service parts, refer to our Service Portal.
<https://fujitsu-general.force.com/portal/>
 - Precise figure of the service parts listed in this manual may differ from the actual service parts.

2. Indoor unit parts list


2-1. Models: ASUH09KPAS and ASUH12KPAS

■ Exterior parts



Item no.	Part no.	Part name
1	9388142005	Bracket panel
2	9387714036	Stepping motor holder assy
3	9387456004	Stepping motor holder
4	9901011047	Stepping motor
5	9387479003	Horizontal louver assy
6	9384977618	Front panel total assy
7	9387473018	Air filter
8	9317250009	Air clean filter assy
9	9387471007	Louver spring
10	9387590241	Drain pan total assy
11	9316177017	Drain cap
12	9316904002	Drain hose assy
13	9362142007	Remote controller total assy
14	9350319008	Remote controller holder


■ Base, evaporator, and control unit



Item no.	Part no.	Part name
50	9362077057	Evaporator total assy
51	9387467000	Room thermistor holder
52	9901160035	Thermistor assy
53	9387587265	Base assy
54	9712546264	Main PCB (09 model)
	9712546271	Main PCB (12 model)
55	9901013010	Terminal block 3P
56	9711146199	Indicator assy
57	9711147073	Indicator PCB
58	9384500014	Motor case sub assy
59	9603768003	DC fan motor
60	9387713022	Motor cover assy
61	9387055047	Crossflow fan assy
62	9333628004	Bearing D assy
—	9701439126	Wire with terminal (E1 on Main PCB—Earth terminal)

2-2. Models: ASUH18KPAS and ASUH24KPAS

■ Exterior parts




Item no.	Part no.	Part name
1	9388158013	Bracket panel
2	9383728006	Vertical louver stepping motor assy
3	9901011023	Stepping motor
4	9387714012	Gear case assy
5	9901011016	Stepping motor
6	9387479010	Horizontal louver assy
7	9384977670	Front panel total assy
8	9323340022	Air filter
9	9317250009	Air clean filter assy
10	9383730030	Louver spring
11	9387590142	Drain pan total assy
12	9316177017	Drain cap
13	9316904002	Drain hose assy
14	9362142014	Remote controller assy
15	9350319008	Remote controller holder

■ Base, evaporator, and control unit

TECHNICAL DATA
AND PARTS LIST


TECHNICAL DATA
AND PARTS LIST



Item no.	Part no.	Part name
50	9383735400	Evaporator total assy
51	9387467000	Room thermistor holder
52	9901160035	Thermistor assy
53	9387587272	Base assy
54	9712546288	Main PCB (18 model)
	9712546295	Main PCB (24 model)
55	9711146304	Indicator assy
56	9711147073	Indicator PCB
57	9901013010	Terminal block 3P
58	9384500007	Motor case sub assy
59	9603631000	DC fan motor
60	9387713015	Motor cover assy
61	9387055054	Crossflow fan assy
62	9333628004	Bearing D assy
—	9901010071	Wire with connector (CN75 on Main PCB—Optional Wireless LAN Adapter)
—	9709509081	Wire with terminal (E1 on Main PCB—Earth terminal)

2-3. Models: ASUH30KPAS and ASUH36KPAS


■ Exterior parts



Item no.	Part no.	Part name
1	9386990004	Bracket panel
2	9386958011	Louver U
3	9386959018	Louver Z
4	9315212016	Air clean filter assy
5	9386960014	Air filter
6	9387072396	Front panel total assy
7	9362142014	Remote controller total assy
8	9350319008	Remote controller holder

■ Base, evaporator, and control unit

 TECHNICAL DATA
AND PARTS LIST


 TECHNICAL DATA
AND PARTS LIST


Item no.	Part no.	Part name
50	9387064209	Evaporator total assy
51	9386975001	Rear panel
52	9901013010	Terminal block 3P
53	9712546301	Main PCB (30 model)
	9712546318	Main PCB (36 model)
54	9901160011	Thermistor assy
55	9386988001	Room temp. thermistor holder
56	9711146229	Indicator assy
57	9711147035	Indicator PCB
58	9316601000	Motor cover
59	9603839017	DC fan motor
60	9316568006	Motor cover
61	9387063004	Link holder assy
62	9900139186	Stepping motor
63	9387062038	Gear cover assy
64	9901011146	Stepping motor
65	9387060034	Casing assy
66	9388540009	Drain hose assy
67	9316177017	Drain cap
68	9387055009	Crossflow fan assy
69	9306628017	Bearing C assy
—	9701439195	Wire with terminal (E1 on Main PCB—GND)
—	9901010071	Wire with connector (USB) (CN75 on Main PCB—Optional WLAN Adapter)

3. Outdoor unit parts list


3-1. Models: AOUH09KPAS1 and AOUH12KPAS1

■ Exterior parts and Chassis



Item no.	Part no.	Part name
1	9322556103	Top panel assy
2	9322811004	Protective net assy
3	9322552310	Cabinet right assy
4	9322570055	Switch cover assy
5	9709689967	Main PCB (09 model)
	9709689974	Main PCB (12 model)
6	9900727062	Thermistor assy
7	9900565176	Thermistor (Outdoor temp.)
8	9900583019	Reactor assy
9	9322144003	Drain pipe
10	9322555359	Front panel assy
11	0700103070	Nut
12	9322136008	Propeller fan
13	9603553005	DC fan motor
14	9322553089	Motor bracket assy (09 model)
	9322553096	Motor bracket assy (12 model)
15	9322272010	Condenser total assy (09 model)
	9322273000	Condenser total assy (12 model)


■ Compressor



Item no.	Part no.	Part name
50	9970110153	Solenoid
51	9322392008	4-way valve assy
52	9970222009	Expansion valve coil
53	9322403001	Pulse motor valve assy
54	9322472007	2-way valve assy
55	9322473004	3-way valve assy
56	9322423009	Compressor assy (09 model)
	9322425003	Compressor assy (12 model)


3-2. Models: AOUH18KPAS1 and AOUH24KPAS1

■ Exterior parts and Chassis



Item no.	Part no.	Part name
1	9322556028	Top panel assy
2	9322811028	Protective net
3	9900565145	Thermistor (Outdoor temp.)
4	9712996113	Main PCB (18 model)
	9712996120	Main PCB (24 model)
5	9900935054	Thermistor assy
6	9900985011	Thermistor (Compressor temp.)
7	9322570062	Switch cover assy
8	9384276001	Conduit cover
9	9322552365	Cabinet right assy
10	9322144003	Drain pipe
11	9322555182	Front panel assy
12	0700103070	Nut
13	9322150004	Propeller fan
14	9604091001	DC fan motor
15	9322553027	Motor bracket assy
16	9323834286	Heat exchanger unit


■ Compressor



Item no.	Part no.	Part name
50	9810521002	Compressor
51	9322446015	4-way valve assy
52	9970194023	Solenoid
53	9970222016	Expansion valve coil
54	9322463029	Pulse motor valve assy
55	9322474001	2-way valve assy
56	9387831016	3-way valve assy

3-3. Models: AOUH30KPAS1 and AOUH36KPAS1

■ Exterior parts and chassis



Item no.	Part no.	Part name
1	9383880001	Top panel sub assy
2	9383779008	Protective net
3	9900984038	Thermistor (Heat exchanger temp.)
4	9900727154	Thermistor assy
5	9900565152	Thermistor (Outdoor temp.)
6	9383607004	Thermostat holder
7	9383874000	Right panel sub assy
8	9384997005	Rear pipe cover
9	9712996106	Inverter PCB
10	9901031014	Thermistor (Heat sink temp.)
11	9900203061	Terminal block 7P
12	9711434746	Main PCB (30 model)
	9711434739	Main PCB (36 model)
13	313166024302	Drain cap
14	9303029015	Drain assy
15	9383876103	Service panel sub assy
16	9384196019	Front pipe cover
17	9383863066	Front panel assy
18	9383882005	Left panel sub assy
19	0700103063	Nut
20	9383336003	Propeller fan
21	9603732011	DC fan motor
22	9383862007	Motor bracket assy
23	9374420612	Condenser sub assy
—	9711332004	Wire with terminal (P102 on Main PCB—L1 on Terminal block 7P)
—	9711332011	Wire with terminal (P103 on Main PCB—L2 on Terminal block 7P)
—	9712261037	Wire with connector (P108 on Main PCB—1, 2, and 3 on Terminal block 7P)
—	9711199003	Wire with connector (P109 on Main PCB—GND)
—	9711203038	Wire with connector (P660 on Main PCB—P662 on Inverter PCB)
—	9711204004	Wire with connector (P661 on Main PCB—P663 on Inverter PCB)
—	9712265011	Wire with connector (P350 on Main PCB—P351 on Inverter PCB)
—	9711206060	Wire with terminal (P400, 401, 402 on Inverter PCB—Compressor)
—	9711212009	Wire with connector (P650 on Inverter PCB—Fan motor [joint])
—	9712264014	Wire with connector (P770 on Inverter PCB—Pressure switch [joint])
—	9711214003	Wire with connector (Pressure switch—Wire with connector [to Inverter PCB])

TECHNICAL DATA AND PARTS LIST















Item no.	Part no.	Part name
50	9900186029	Pressure switch
51	9374425648	4-way valve assy
52	9970194016	Solenoid
53	9375250249	Accumulator assy
54	9970209000	Expansion valve coil
55	9370947373	Expansion valve assy
56	9379079037	3-way valve assy
57	9387794007	3-way valve assy
58	9900985035	Thermistor (Compressor temp.)
59	9383821004	Compressor














4. Accessories

4-1. Indoor unit

■ Models: ASUH09KPAS, ASUH12KPAS, ASUH18KPAS, and ASUH24KPAS





Part name	Exterior	Qty	Part name	Exterior	Qty
Operation manual		1	Wall hook bracket		1
Installation manual		1	Self-tapping screw (large)		5
Remote controller		1	Self-tapping screw (small)		2
Remote controller holder		1	Cloth tape		1
Battery		2	Filter holder		2
Installation spacer		1	Air cleaning filters		1

■ Models: ASUH30KPAS and ASUH36KPAS





Part name	Exterior	Qty	Part name	Exterior	Qty
Operation manual		1	Drain hose insulation		1
Installation manual		1	Cloth tape		1
Wall hook bracket		1	Self-tapping screw (large)		8
Remote controller		1	Self-tapping screw (small)		2
Battery		2	Air cleaning filters		1
Remote controller holder		1	Filter holder		2
Installation spacer		1			

4-2. Outdoor unit

■ Models: AOUH09KPAS1, AOUH12KPAS1, AOUH18KPAS1, and AOUH24KPAS1

Part name	Exterior	Qty	Part name	Exterior	Qty
Installation manual		1	Cable tie		2
Drain pipe		1	Protection label		1







■ Models: AOUH30KPAS1 and AOUH36KPAS1

Part name	Exterior	Qty	Part name	Exterior	Qty
Installation manual		1	Drain pipe		1
Protection label		1	Drain cap		3

5. Optional parts

5-1. Indoor unit










■ Controllers

Exterior	Part name	Model name	Summary
	Wired Remote Controller (Touch Panel)	UTY-RVRU	<p>Remote controller that provides the functions you need in a sleek design that uniquely transforms itself to blend with any interior.</p> <p>Optional Communication Kit is necessary for installation.</p> <p>NOTE: When this remote controller is connected, wireless remote controller cannot be used.</p>  <p>Wireless RC</p>
	Wired Remote Controller (Touch Panel)	UTY-RNRUZ*	<p>Easy finger touch operation with LCD panel. Backlit LCD enables easy operation in a dark room.</p> <p>Optional Communication Kit is necessary for installation.</p> <p>NOTE: When this remote controller is connected, wireless remote controller cannot be used.</p>  <p>Wireless RC</p>
	Simple Remote Controller	UTY-RSRY	<p>Compact remote controller concentrates on the basic functions such as Start/Stop, fan control, temperature setting, and operation mode.</p> <p>Optional Communication Kit is necessary for installation.</p>
	Simple Remote Controller	UTY-RHRY	<p>Compact remote controller concentrates on the basic functions such as Start/Stop, fan control, and temperature setting.</p> <p>Optional Communication Kit is necessary for installation.</p>


NOTES:

- Available functions may differ by the remote controller. For details, refer to the operation manual.
- When using the group controlling system of the Wired Remote Controller, using WLAN Adapter is prohibited.

Others


Exterior	Part name	Model name	Summary
	External Connect Kit	UTY-XWZX	Use to connect with various peripheral devices and air conditioner PCB. Connecting point: CN46 and CN47 on Main PCB
	External Connect Kit	UTY-XWZXZ5	Required when external device is connected. Connecting point: CN46 and CN47 on Main PCB
	External Input and Output PCB	UTY-XCSXZ2	Use to connect with external devices and air conditioner PCB. Optional External Connect Kit might be required to connect locally purchased devices via this PCB. Connecting point: CN65 on Main PCB
	Communication Kit	UTY-TWRXZ2	Use to connect Non-polar 2-core wired remote controller. Connecting point: CN13 on Main PCB
	WLAN Adapter	UTY-TFSXH4	Remotely manage an air conditioning system using mobile devices such as smartphones and tablets. Appropriate application for each region is required to use this option. For details, contact FGL sales company. Connecting point: USB connector
	Modbus Converter	UTY-VMSX	For connection between indoor unit with UART interface and a Modbus open network. Connecting point: CN65 on Main PCB
	Thermostat Converter	UTY-TTRXZ*	This converter can control Fujitsu General products using a third-party thermostat controller. Optional Communication Kit is necessary for installation.
	Network Converter	UTY-VTGX	This converter is required when connecting single split system to VRF network system. Optional Communication Kit is necessary for installation.
	External Switch Controller	UTY-TERX	Air conditioner switching can be controlled by connecting other external sensor switches. Optional Communication Kit is necessary for installation.

5-2. Outdoor unit

Exterior	Part name	Model name	Summary
	External Connect Kit	UTY-XWZXZ3	Use to operate the external input and output functions of outdoor unit. (for 30-36 model)

6. Refrigerant system diagrams

6-1. Models: AOUH09KPAS1 and AOUH12KPAS1



ThD : Thermistor (Discharge temperature)


ThO : Thermistor (Outdoor temperature)

ThHO : Thermistor (Heat exchanger out temperature)

ThPI : Thermistor (Pipe temperature)

ThR : Thermistor (Room temperature)

6-2. Models: AOUH18KPAS1 and AOUH24KPAS1



Th_c : Thermistor (Compressor temperature)

Th_D : Thermistor (Discharge temperature)


Th_o : Thermistor (Outdoor temperature)

Th_{HO} : Thermistor (Heat exchanger out temperature)

Th_P : Thermistor (Pipe temperature)

Th_R : Thermistor (Room temperature)

6-3. Models: AOUH30KPAS1 and AOUH36KPAS1



Thc : Thermistor (Compressor temperature)

ThD : Thermistor (Discharge temperature)

ThHM : Thermistor (Heat exchanger middle temperature)

Tho : Thermistor (Outdoor temperature)

ThHO : Thermistor (Heat exchanger out temperature)


ThPI : Thermistor (Pipe temperature)

ThR : Thermistor (Room temperature)


7. Wiring diagrams

7-1. Indoor unit

■ Models: ASUH09KPAS and ASUH12KPAS




■ Models: ASUH18KPAS, ASUH24KPAS, ASUH30KPAS, and ASUH36KPAS




7-2. Outdoor unit


■ Models: AOUH09KPAS1 and AOUH12KPAS1



Models: AOUH18KPAS1 and AOUH24KPAS1




Models: AOUH30KPAS1 and AOUH36KPAS1



8-1. Models: ASUH09KPAS and ASUH12KPAS



TECHNICAL DATA AND PARTS LIST




8-3. Models: ASUH30KPAS and ASUH36KPAS

TECHNICAL DATA
AND PARTS LIST

TECHNICAL DATA
AND PARTS LIST


CONTROL UNIT

30 model: EZ-0240WHSE
36 model: EZ-0240YHSE



8-4. Models: AOUH09KPAS1 and AOUH12KPAS1


TECHNICAL DATA
AND PARTS LIST



TECHNICAL DATA
AND PARTS LIST

8-5. Models: AOUH18KPAS1 and AOUH24KPAS1


TECHNICAL DATA
AND PARTS LIST



TECHNICAL DATA
AND PARTS LIST

TECHNICAL DATA AND PARTS LIST

8. PC board diagrams



3. TROUBLESHOOTING

CONTENTS

3. TROUBLESHOOTING

1. Error code	03-1
1-1. How to check the error memory.....	03-1
1-2. How to erase the error memory	03-1
1-3. Error code table (Indoor unit and wired remote controller).....	03-2
1-4. Error code table (Outdoor unit)	03-4
1-5. Error code table (Wireless LAN indicator).....	03-6
1-6. How to check the error code on Mobile app	03-7
1-7. Error code table (Mobile app)	03-8
1-8. Error message for wireless LAN control (Mobile app).....	03-10
2. Troubleshooting with error code	03-24
2-1. E: 11.X. Serial communication error (Serial reverse transfer error) (Outdoor unit)	03-24
2-2. E: 11.X. Serial communication error (Serial forward transfer error) (Indoor unit)	03-26
2-3. E: 12.X. Wired remote controller communication error (Indoor unit)	03-28
2-4. E: 18.X. External communication error (Indoor unit)	03-29
2-5. E: 22.X. Indoor unit capacity error (Indoor unit)	03-30
2-6. E: 23.X. Combination error (Outdoor unit)	03-31
2-7. E: 26.X. Address setting error in wired remote controller (Indoor unit)	03-32
2-8. E: 29.X. Connected unit number error (Indoor unit)	03-33
2-9. E: 32.X. Indoor unit main PCB error (Indoor unit)	03-34
2-10. E: 33.X. Indoor unit motor electricity consumption detection error (Indoor unit).....	03-35
2-11. E: 35.X. MANUAL AUTO button error (Indoor unit)	03-36
2-12. E: 39.X. Indoor unit power supply error for fan motor (Indoor unit)	03-37
2-13. E: 3A.X. Indoor unit communication circuit (wired remote controller) error	03-38
2-14. E: 41.X. Room temperature sensor error (Indoor unit).....	03-39
2-15. E: 42.X. Indoor unit heat exchanger sensor error (Indoor unit).....	03-40
2-16. E: 51.X. Indoor unit fan motor error (Indoor unit)	03-41
2-17. E: 5U.X. Indoor unit error.....	03-42
2-18. E: 62.X. Outdoor unit main PCB error (Outdoor unit).....	03-43
2-19. E: 64.X. PFC circuit error (Outdoor unit).....	03-44
2-20. E: 65.X. IPM error (Outdoor unit).....	03-45
2-21. E: 71.X. Discharge thermistor error (Outdoor unit)	03-47
2-22. E: 72.X. Compressor thermistor error (Outdoor unit)	03-48
2-23. E: 73.X. Outdoor unit heat exchanger liquid outlet thermistor error (Outdoor unit)	03-49
2-24. E: 74.X. Outdoor temperature thermistor error (Outdoor unit)	03-50
2-25. E: 77.X. Heat sink thermistor error (Outdoor unit)	03-51
2-26. E: 84.X. Current sensor error (Outdoor unit).....	03-52
2-27. E: 86.X. High pressure switch error (Outdoor unit)	03-54
2-28. E: 86.X. Pressure sensor error (Outdoor unit)	03-55
2-29. E: 94.X. Over current error (Outdoor unit)	03-56
2-30. E: 95.X. Compressor motor control error (Outdoor unit).....	03-57
2-31. E: 97.X. Outdoor unit fan motor error (Outdoor unit).....	03-58
2-32. E: 99.X. 4-way valve error (Outdoor unit)	03-60

CONTENTS (continued)

2-33. E: A1.X. Discharge temperature error (Outdoor unit).....	03-62
2-34. E: A3.X. Compressor temperature error (Outdoor unit)	03-64
2-35. E: AC.X. Heat sink temperature error (Outdoor unit)	03-66
3. Troubleshooting without error code.....	03-67
3-1. Indoor unit—No power.....	03-67
3-2. Outdoor unit—No power	03-68
3-3. No operation (Power is on)	03-69
3-4. No cooling/No heating	03-70
3-5. Abnormal noise.....	03-72
3-6. Water leaking.....	03-73
4. Troubleshooting with error code (For wireless LAN adapter).....	03-74
4-1. E: 18.X. External communication error between indoor unit and wireless LAN adapter	03-74
4-2. Network communication error between wireless LAN router and wireless LAN adapter	03-75
4-3. E: 18.X. Communication error	03-77
4-4. E: 18.X. Wireless LAN adapter non-energized	03-79
4-5. Mobile app setting method.....	03-80
5. Service parts information	03-82
5-1. Compressor	03-82
5-2. Inverter compressor.....	03-83
5-3. Outdoor unit Electronic Expansion Valve (EEV)	03-85
5-4. Indoor unit fan motor	03-87
5-5. Outdoor unit fan motor	03-88
5-6. Reactor assy.....	03-89
5-7. Pressure switch	03-89
5-8. 4-way valve coil (solenoid coil)/4-way valve	03-90
6. Thermistor resistance values.....	03-91
6-1. Indoor unit	03-91
6-2. Outdoor unit.....	03-92

1. Error code

When a problem occurs in the system or the connected device, the error content is notified by displaying the code.

NOTE: This function is only available in a system with indoor or IR receiver units equipped with indicator lamps to show the error content.


Errors, once displayed, will be automatically stored in the PC board of the indoor unit. Even if the power is disconnected, the memory containing the error history will not be erased.

If another error occurs later, the stored error memory will be updated automatically and replaced with the new one. (Previous error will be erased.)

1-1. How to check the error memory

When an error occurs, the operation lamp (Green) and the timer lamp (Orange) indicate the error content by blinking. To check the error memory, follow the procedures below.

1. Stop the operation of the air conditioner, and then disconnect the power supply.
2. Reconnect the power supply.
3. In one of the following two methods, the memorized error is only displayed during the “3 minutes ST”^{*} state period.
 - Start the operation and then press the TEST RUN button on the remote controller.
 - Press the MANUAL AUTO button on the indoor unit for 10 seconds or more.



^{*}: The “3 minutes ST” period lasts 2 minutes and 20 seconds after turning on the power supply.

1-2. How to erase the error memory

The error memory can be erased in one of the following two methods.

- Manual erase: Pressing the MANUAL AUTO button on the indoor unit while the “Error memory display” is being shown. (Short beep emits for about 3 seconds.)
- Automatic erase: After continuing the normal operation of the air conditioner without error for 2 hours or longer after displaying the error memory as described in [How to check the error memory](#). (Except FAN operation mode.)

1-3. Error code table (Indoor unit and wired remote controller)

The operation, timer, and economy indicators operate according to the error contents.

For confirmation of the error contents, refer the flashing pattern as follows.

Error contents	Indoor unit display			Wired remote controller display
	Operation [I] (Green)	Timer [⌚] (Orange)	Economy [E] (Green)	
E: 11.X. Serial communication error (Serial reverse transfer error) (Outdoor unit)	1 times	1 times	Continuous	11
E: 11.X. Serial communication error (Serial forward transfer error) (Indoor unit)	1 times	1 times	Continuous	11
E: 12.X. Wired remote controller communication error (Indoor unit)	1 times	2 times	Continuous	12
E: 18.X. External communication error (Indoor unit)	1 times	8 times	Continuous	18
E: 22.X. Indoor unit capacity error (Indoor unit)	2 times	2 times	Continuous	22
E: 23.X. Combination error (Outdoor unit)	2 times	3 times	Continuous	23
E: 26.X. Address setting error in wired remote controller (Indoor unit)	2 times	6 times	Continuous	26
E: 29.X. Connected unit number error (Indoor unit)	2 times	9 times	Continuous	29
E: 32.X. Indoor unit main PCB error (Indoor unit)	3 times	2 times	Continuous	32
E: 33.X. Indoor unit motor electricity consumption detection error (Indoor unit)	3 times	3 times	Continuous	33
E: 35.X. MANUAL AUTO button error (Indoor unit)	3 times	5 times	Continuous	35
E: 39.X. Indoor unit power supply error for fan motor (Indoor unit)	3 times	9 times	Continuous	39
E: 3A.X. Indoor unit communication circuit (wired remote controller) error	3 times	10 times	Continuous	3A
E: 41.X. Room temperature sensor error (Indoor unit)	4 times	1 times	Continuous	41
E: 42.X. Indoor unit heat exchanger sensor error (Indoor unit)	4 times	2 times	Continuous	42
E: 51.X. Indoor unit fan motor error (Indoor unit)	5 times	1 times	Continuous	51
E: 5U.X. Indoor unit error	5 times	15 times	Continuous	5U
E: 62.X. Outdoor unit main PCB error (Outdoor unit)	6 times	2 times	Continuous	62
E: 64.X. PFC circuit error (Outdoor unit)	6 times	4 times	Continuous	64
E: 65.X. IPM error (Outdoor unit)	6 times	5 times	Continuous	65
E: 71.X. Discharge thermistor error (Outdoor unit)	7 times	1 times	Continuous	71
E: 72.X. Compressor thermistor error (Outdoor unit)	7 times	2 times	Continuous	72
E: 73.X. Outdoor unit heat exchanger liquid outlet thermistor error (Outdoor unit)	7 times	3 times	Continuous	73
E: 74.X. Outdoor temperature thermistor error (Outdoor unit)	7 times	4 times	Continuous	74
E: 77.X. Heat sink thermistor error (Outdoor unit)	7 times	7 times	Continuous	77
E: 84.X. Current sensor error (Outdoor unit)	8 times	4 times	Continuous	84
E: 86.X. High pressure switch error (Outdoor unit)	8 times	6 times	Continuous	86
E: 86.X. Pressure sensor error (Outdoor unit)	8 times	6 times	Continuous	86

Error contents	Indoor unit display			Wired remote controller display
	Operation [I] (Green)	Timer [⌚] (Orange)	Economy [E] (Green)	
E: 94.X. Over current error (Outdoor unit)	9 times	4 times	Continuous	94
E: 95.X. Compressor motor control error (Outdoor unit)	9 times	5 times	Continuous	95
E: 97.X. Outdoor unit fan motor error (Outdoor unit)	9 times	7 times	Continuous	97
E: 99.X. 4-way valve error (Outdoor unit)	9 times	9 times	Continuous	99
E: A1.X. Discharge temperature error (Outdoor unit)	10 times	1 times	Continuous	A1
E: A3.X. Compressor temperature error (Outdoor unit)	10 times	3 times	Continuous	A3
E: AC.X. Heat sink temperature error (Outdoor unit)	10 times	11 times	Continuous	AC

1-4. Error code table (Outdoor unit)

The operation status is determined by the lighting up and blinking of the LED lamp.
After check that ERROR LED lamp blinks, press the ENTER button once.

NOTE: For the positions of LED lamp and buttons, refer to "Function settings (for 30–36 outdoor units)" in Chapter 5. FIELD WORKING on page 05-11.


Error contents	POWER/ MODE	ERROR	PUMP DOWN	LOW NOISE		PEAK CUT		
			L1	L2	L3	L4	L5	L6
E: 11.X. Serial communication error (Serial forward transfer error) (Indoor unit) (Occurs immediately after starting operation)	■ 2	●	■ 1	■ 1	○	○	●	●
E: 11.X. Serial communication error (Serial forward transfer error) (Indoor unit) (Occurs during operation)	■ 2	●	■ 1	■ 1	○	●	○	○
E: 12.X. Wired remote controller communication error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 18.X. External communication error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 22.X. Indoor unit capacity error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 23.X. Combination error (Outdoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 26.X. Address setting error in wired remote controller (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 29.X. Connected unit number error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 32.X. Indoor unit main PCB error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 33.X. Indoor unit motor electricity consumption detection error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 35.X. MANUAL AUTO button error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 39.X. Indoor unit power supply error for fan motor (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 3A.X. Indoor unit communication circuit (wired remote controller) error	■ 2	●	■ 5	■ 15	○	○	○	●
E: 41.X. Room temperature sensor error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 42.X. Indoor unit heat exchanger sensor error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 51.X. Indoor unit fan motor error (Indoor unit)	■ 2	●	■ 5	■ 15	○	○	○	●
E: 62.X. Outdoor unit main PCB error (Outdoor unit)	■ 2	●	■ 6	■ 2	○	○	○	●
E: 64.X. PFC circuit error (Outdoor unit)	■ 2	●	■ 6	■ 4	○	○	○	●
E: 65.X. IPM error (Outdoor unit)	■ 2	●	■ 6	■ 5	○	○	●	●
E: 71.X. Discharge thermistor error (Outdoor unit)	■ 2	●	■ 7	■ 1	○	○	○	●
E: 72.X. Compressor thermistor error (Outdoor unit)	■ 2	●	■ 7	■ 2	○	○	○	●
E: 73.X. Outdoor unit heat exchanger liquid outlet thermistor error (Outdoor unit)	■ 2	●	■ 7	■ 3	○	○	●	○

Error contents	POWER/ MODE	ERROR	PUMP DOWN	LOW NOISE		PEAK CUT		
			L1	L2	L3	L4	L5	L6
E: 73.X. Outdoor unit heat exchanger liquid outlet thermistor error (Outdoor unit)	■ 2	●	■ 7	■ 3	○	○	●	○
E: 74.X. Outdoor temperature thermistor error (Outdoor unit)	■ 2	●	■ 7	■ 4	○	○	○	●
E: 77.X. Heat sink thermistor error (Outdoor unit)	■ 2	●	■ 7	■ 7	○	○	○	●
E: 84.X. Current sensor error (Outdoor unit)	■ 2	●	■ 8	■ 4	○	○	○	●
E: 86.X. High pressure switch error (Outdoor unit)	■ 2	●	■ 8	■ 6	○	●	●	○
E: 86.X. Pressure sensor error (Outdoor unit)	■ 2	●	■ 8	■ 6	○	●	●	○
E: 94.X. Over current error (Outdoor unit)	■ 2	●	■ 9	■ 4	○	○	○	●
E: 95.X. Compressor motor control error (Outdoor unit)	■ 2	●	■ 9	■ 5	○	○	○	●
E: 97.X. Outdoor unit fan motor error (Outdoor unit)	■ 2	●	■ 9	■ 7	○	○	●	●
E: 99.X. 4-way valve error (Outdoor unit)	■ 2	●	■ 9	■ 9	○	○	○	●
E: A1.X. Discharge temperature error (Outdoor unit)	■ 2	●	■ 10	■ 1	○	○	○	●
E: A3.X. Compressor temperature error (Outdoor unit)	■ 2	●	■ 10	■ 3	○	○	○	●
E: AC.X. Heat sink temperature error (Outdoor unit)	■ 2	●	■ 10	■ 11	○	○	●	●


● : Light on ○ : Light off ■ (n) : n Times blinking

1-5. Error code table (Wireless LAN indicator)

- Wireless LAN control system diagram example



- Name of parts



- Wireless LAN indicator lamps


For confirmation of the error contents, refer to the following flashing patterns.


Wireless LAN indicator lamp (orange) on the indoor unit operate according to the error contents.



Error contents	Wireless LAN indicator lamp (orange)	Error code
E: 18.X. External communication error between indoor unit and wireless LAN adapter	Flashing slowly	18
Network communication error between wireless LAN router and wireless LAN adapter	Flashing slowly	No error
E: 18.X. Communication error	Flashing slowly	18
E: 18.X. Wireless LAN adapter non-energized	Off	18

Flashing slowly: Repeating 7 seconds on/2 seconds off

1-6. How to check the error code on Mobile app

If there is an abnormality on the air conditioning, refer to  as follows.

When the  (error button) on the home screen is tapped, error code and error name is displayed.



1-7. Error code table (Mobile app)


Error message	Error contents	Error code
Serial reverse transmission error at start-up	E: 11.X. Serial communication error (Serial reverse transfer error) (Outdoor unit)	11.1
Serial reverse transmission error during operation		11.2
Serial forward transmission error at start-up	E: 11.X. Serial communication error (Serial forward transfer error) (Indoor unit)	11.3
Serial forward transmission error during operation		11.4
Wired remote controller communication error	E: 12.X. Wired remote controller communication error (Indoor unit)	12.1
Wired remote controller signal error		12.2
Excess number of devices in wired remote controller system		12.3
Wired remote controller system start-up error		12.4
External communication 1 error	E: 18.X. External communication error (Indoor unit)	18.1
Indoor unit capacity error	E: 22.X. Indoor unit capacity error (Indoor unit)	22.1
Connection forbidden (series error)	E: 23.X. Combination error (Outdoor unit)	23.1
Unit combination error		23.2
Address duplication in wired remote controller system	E: 26.X. Address setting error in wired remote controller (Indoor unit)	26.4
Address setting error in wired remote controller system		26.5
Connection unit number error (indoor unit in wired remote controller system)	E: 29.X. Connected unit number error (Indoor unit)	29.1
Indoor unit PCB model information error	E: 32.X. Indoor unit main PCB error (Indoor unit)	32.1
Constant correction control error		32.6
Indoor unit motor electricity consumption detection microcomputers error	E: 33.X. Indoor unit motor electricity consumption detection error (Indoor unit)	33.2
Indoor unit manual auto switch error	E: 35.X. MANUAL AUTO button error (Indoor unit)	35.1
Indoor unit power supply error for fan motor 1	E: 39.X. Indoor unit power supply error for fan motor (Indoor unit)	39.1
Indoor unit communication circuit (wired remote controller) microcomputers communication error	E: 3A.X. Indoor unit communication circuit (wired remote controller) error	3A.1
Indoor unit suction air temp. thermistor error	E: 41.X. Room temperature sensor error (Indoor unit)	41.1
Indoor unit heat ex. middle temp. thermistor error	E: 42.X. Indoor unit heat exchanger sensor error (Indoor unit)	42.2
Indoor unit fan motor 1 lock error	E: 51.X. Indoor unit fan motor error (Indoor unit)	51.1
Indoor unit fan motor 1 rotation speed error		51.2
Outdoor unit PCB model information error	E: 62.X. Outdoor unit main PCB error (Outdoor unit)	62.1
Outdoor unit PCB microcomputer communication error		62.2
Outdoor unit abnormal voltage error (permanent stop)	E: 64.X. PFC circuit error (Outdoor unit)	64.1
Outdoor unit abnormal voltage error (automatic restore)		64.3
Outdoor unit over current error (permanent stop)		64.4
Outdoor unit PFC hardware error		64.8
Outdoor unit trip terminal L error	E: 65.X. IPM error (Outdoor unit)	65.3
Outdoor unit discharge temp. thermistor 1 error	E: 71.X. Discharge thermistor error (Outdoor unit)	71.1
Outdoor unit discharge temp. thermistor 1 error	E: 72.X. Compressor thermistor error (Outdoor unit)	72.1

Error message	Error contents	Error code
Outdoor unit heat ex. liquid temp. thermistor error	E: 73.X. Outdoor unit heat exchanger liquid outlet thermistor error (Outdoor unit)	73.3
Outside air temp. thermistor error	E: 74.X. Outdoor temperature thermistor error (Outdoor unit)	74.1
Outdoor unit heat sink temp. thermistor error	E: 77.X. Heat sink thermistor error (Outdoor unit)	77.1
Outdoor unit current sensor 1 error (permanent stop)	E: 84.X. Current sensor error (Outdoor unit)	84.1
Outdoor unit discharge pressure sensor error	E: 86.X. High pressure switch error (Outdoor unit)	86.1
Outdoor unit trip detection	E: 94.X. Over current error (Outdoor unit)	94.1
Outdoor unit compressor rotor position detection error (permanent stop)	E: 95.X. Compressor motor control error (Outdoor unit)	95.1
Outdoor unit fan motor 1 power source duty error	E: 97.X. Outdoor unit fan motor error (Outdoor unit)	97.3
Outdoor unit 4-way valve error	E: 99.X. 4-way valve error (Outdoor unit)	99.1
Outdoor unit discharge temperature 1 error (permanent stop)	E: A1.X. Discharge temperature error (Outdoor unit)	A1.1
Outdoor unit compressor 1 temperature error	E: A3.X. Compressor temperature error (Outdoor unit)	A3.1
Operation over upper range limit error	E: AC.X. Heat sink temperature error (Outdoor unit)	AC.1
Operation under lower range limit error		AC.2

1-8. Error message for wireless LAN control (Mobile app)

■ Error display

If there is an abnormality on the wireless control system, refer to error messages as follows.



← Error message

■ Error message list

• Registration error

Error code	Error message	Cause
		Solution
2400	<p>Communication failed. After checking the following contents, please try again after a while.</p> <ul style="list-style-type: none"> Ensure that the air conditioner is turned on. 	<p>Communication with the air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
		<p>Failed because the smartphone could not connect to the air conditioner.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ol style="list-style-type: none"> Check that the 2D barcode is for the air conditioner to be registered. Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. Retry the connection step procedure for the air conditioner registration displayed in the application to set the lamp to the blinking state. When lighting or blinking <ol style="list-style-type: none"> Check that the 2D barcode is for the air conditioner to be registered. Check that the wireless LAN setting of smartphone is set to ON.
2930	<p>Cannot connect to your air conditioner. Check if the WiFi setting of the mobile device is turned on.</p> <p>When problems are not resolved, there may be other causes. Tap the link below to check other solutions.</p>	<p>Failed because the smartphone could not connect to the air conditioner.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ol style="list-style-type: none"> Check that the 2D barcode is for the air conditioner to be registered. Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. Retry the connection step procedure for the air conditioner registration displayed in the application to set the lamp to the blinking state. When lighting or blinking <ol style="list-style-type: none"> Check that the 2D barcode is for the air conditioner to be registered. Check that the wireless LAN setting of smartphone is set to ON.
		<p>Failed because the smartphone could not connect to the air conditioner.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ol style="list-style-type: none"> Check that the 2D barcode is for the air conditioner to be registered. Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. Retry the connection step procedure for the air conditioner registration displayed in the application to set the lamp to the blinking state. When lighting or blinking <ol style="list-style-type: none"> Check that the 2D barcode is for the air conditioner to be registered. Check that the wireless LAN setting of smartphone is set to ON.

Error code	Error message	Cause
		Solution
2931	WLAN adapter password is wrong. Enter it again. When problems are not resolved, there may be other causes. Tap the link below to check other solutions.	Failed because the smartphone could not connect to the air conditioner. Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.
		<ul style="list-style-type: none"> • When not lighting <ol style="list-style-type: none"> 1. Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. 2. Check that the power plug of the air conditioner main unit is plugged in. 3. Retry the connection step procedure for the air conditioner registration displayed in the application to set the lamp to the blinking state. • When lighting or blinking <ol style="list-style-type: none"> 1. Check that the entered SSID and PIN numbers of WLAN Adapter are correct. 2. Check that the wireless LAN setting of smartphone is set to ON.
2932 2933	Failed to connect to wireless router. Check if the WiFi setting of the mobile device is turned on. When problems are not resolved, there may be other causes. Tap the link below to check other solutions.	<ul style="list-style-type: none"> • Registration failed because the smartphone cannot connect to the network. • Connection to the WLAN Adapter was disconnected during processing.
		<ol style="list-style-type: none"> 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet.
2934	Wi-Fi router password is wrong. Tap "From the beginning" to enter it again. When problems are not resolved, there may be other causes. Tap the link below to check other solutions.	<ul style="list-style-type: none"> • The wireless router password is not correct. • The air conditioner is not connected to the same wireless router as the smartphone.
		Check the following contents and operate again. <ol style="list-style-type: none"> 1. Check that the wireless router password is correct. 2. Check that the smartphone and the air conditioner are connected to the same wireless router. 3. The wireless router encryption method WPA3 is not supported. Check if SSID other than WPA3 is selected. 4. Check that the local network setting of the smartphone is "Enabled". (Only for smartphones with iOS14 or later)
2935 2937 2939 2941	Failed to register the air conditioner. Make sure the wireless router is connected to the Internet, and then tap "Re-register" to perform the registration process again. When problems are not resolved, there may be other causes. Tap the link below to check other solutions.	Registration failed because the air conditioner cannot connect to the Internet.
		Check the following contents and operate again. <ol style="list-style-type: none"> 1. Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. 2. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router. 3. Check that the MAC address filter and privacy separator settings are not "enabled" on the wireless router.

Error code	Error message	Cause
		Solution
2936 2940	Air conditioner registration failed. Tap "Re-register" and conduct the registration processing again. If not successful after multiple attempts, tap "From the beginning" and then initialize the WLAN and start over from the beginning.	<ul style="list-style-type: none"> The air conditioner you are trying to register is already registered to another account. Registration failed because the air conditioner cannot connect to the Internet. Immediately after turning on the power of the air conditioner, wait for about 5 minutes before registering it.
		Check the following contents and operate again. <ol style="list-style-type: none"> Tap "Re-register" and conduct the registration processing again. Delete from another account or initialize the WLAN Adapter. Check that the wireless router is turned on. Check that wireless router is connected to the Internet. If not connected, reboot the wireless router. When rebooting does not solve the problem, contact the manufacturer of the wireless router. Check that the MAC address filter and privacy separator settings are not "enabled" on the wireless router.
2938	Registration failed because the air conditioner could not connect to the Internet. Perform the WPS connection procedure again and confirm that the WLAN lamp on the indoor unit or LED2 on the WLAN adapter is lit before registering. When problems are not resolved, there may be other causes. Tap the link below to check other solutions.	<ul style="list-style-type: none"> Registration failed because the air conditioner cannot connect to the Internet. Registration failed because the air conditioner is not connected to the same wireless router as the smartphone.
		Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again. <ul style="list-style-type: none"> When not lighting <ol style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. Check that the wireless router is turned on. Retry the connection step procedure for the air conditioner registration displayed in the application and complete WPS connection with wireless router to set the lamp to the blinking state. When lighting <ol style="list-style-type: none"> Check that the air conditioner and the smartphone are connected to the same wireless router. Check that the local network setting of the smartphone is "Enabled". (Only for smartphones with iOS14 or later)
2942	Your mobile device is not connected to WiFi. Connect to the target wireless router through the OS WiFi setting and restart the procedure. <ol style="list-style-type: none"> Open the Wi-Fi setting screen of your device. Connect your mobile device to the {ssid}. Return to the application screen and tap "Re-register". When problems are not resolved, there may be other causes. Tap the link below to check other solutions.	Registration failed because the air conditioner cannot connect to the Internet.
		Check the following contents and operate again. <ol style="list-style-type: none"> Check that the wireless LAN setting of smartphone is set to ON. Check that the smartphone is connected to the Internet. Set the connection setting with the wireless router to Auto Connection in the smartphone settings. Check that the wireless router is turned on.

Error code	Error message	Cause
		Solution
2944	Communication failed.	Registration may have failed because a problem occurred in communication with the server (cloud). Wait for a while and then operate again.
2946	The connected air conditioner cannot use the Direct control.	Your air conditioner does not support Direct Control. Operate the air conditioner with Cloud Control.
2947	Already reached the max number of air conditioners per user.	The number of air conditioners that can be registered on AIRSTAGE Mobile has reached the maximum limit. Check the number of air conditioners registered on AIRSTAGE Mobile. (Maximum number of registered units: 50 units for Cloud Control, 50 units for Direct Control) Delete the unused air conditioners on the "Air conditioner editing" screen before registration.
2949	The number of air conditioners registered by the entered user has reached the upper limit, so registration is not possible.	The number of sub users that can be registered has reached the maximum limit. Check the number of registered sub users. (Maximum number of registered sub users: 4 sub users) Delete the unused sub users on the "Sub User Registration" screen.
2953	The specified air conditioner is already registered. To Reregister, delete the air conditioner information on the air conditioner edit screen and initialize the wireless LAN adapter with the remote control.	The specified air conditioner was already registered. Check that the specified air conditioner is displayed on the air conditioner list screen. To register again, delete the air conditioner on the air conditioner editing screen.
2954	The wireless router to which the mobile device and the wireless LAN adapter are connected must be the same. Follow the steps below. 1. Please open the Wi-Fi setting screen of the mobile device. 2. Connect your mobile device to the wireless router that you pressed the automatic connection button. 3. Return to the app screen and tap "OK".	The air conditioner and the smartphone are not connected to the same wireless router network. Check the following contents and operate again. 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on. 4. Check that the air conditioner and the smartphone are connected to the same wireless router.

• Sign in error

Error code	Error message	Cause
		Solution
4010 4410 4610 4810 4910	Communication failed. After checking the following contents, please try again after a while. <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	Various settings could not be completed because communication with the server (cloud) failed. Check the following contents and operate again. 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on.
4100	The account you are currently signed in to may have been deleted. If necessary, please create the account again.	Token has been disabled because the signed-in account has been deleted or certain amount of time has elapsed. Restart the application and check that you can sign in. If you cannot sign in, create the account again.
4101	The session has expired. Please sign in again to continue.	Token has been disabled because the signed-in account has been deleted or certain amount of time has elapsed. Restart the application and check that you can sign in. If you cannot sign in, create the account again.
4102	Your session has expired. Please sign in again. *If you cannot sign in, your account may have been deleted. If necessary, please create an account again.	Token has been disabled because the signed-in account has been deleted or certain amount of time has elapsed. Restart the application and check that you can sign in. If you cannot sign in, create the account again.
4110	Failed to connect to the server. Some functions can be used with Direct Control. Do you want to switch to direct control?	<ul style="list-style-type: none"> Communication with the server (cloud) failed at sign in. Registration process of Account registration procedure verification email has not been completed. Check the following contents and sign in again. 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on. 4. Tap the link of Account registration procedure verification email and check that registration process has completed.
4111	Failed to read the device. Since some functions are available in Direct control, switch to Direct control.	Air conditioner information could not be obtained because communication with the server (cloud) failed after sign in. Check the following contents and sign in again. 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on.
4112	Failed to connect to the server. Some functions are limited.	<ul style="list-style-type: none"> Communication with the server (cloud) failed at sign in. Registration process of Account registration procedure verification email has not been completed. Check the following contents and sign in again. 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on. 4. Tap the link of Account registration procedure verification email and check that registration process has completed.
4113	Failed to connect to the server. Would you like to sign in again? Yes: Sign in again No: Return to the sign-in screen	Air conditioner information could not be obtained because communication with the server (cloud) failed after sign in. Check the following contents and sign in again. 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on.

Error code	Error message	Cause
		Solution
4420	Loading of user information failed. Check the following contents. • Check that your mobile device is connected to the internet.	User information or temperature unit information could not be obtained because communication with the server (cloud) failed.
		Check the following contents and operate again. 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on.
4530	Password update failed. Please check if the entered current password is correct.	Password update failed because the entered password was not correct.
		Check that the entered "Current password" is correct and operate again.
4920	Loading of time zone failed. Check the following contents. • Check that your mobile device is connected to the internet.	Time zone information could not be obtained because communication with server (cloud) failed.
		Check the following contents and operate again. 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on.

• General error

Error code	Error message	Cause
		Solution
0100 0200 0300 0400 0500 0501 0600 0601 0800 0900 1000 1200 1400 1500 3200 5500 5700 5900 6200	Communication failed. After checking the following contents, please try again after a while. <ul style="list-style-type: none"> Ensure that the air conditioner is turned on. 	<p>Communication with the air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p>
0810 0811 0812 1510 1511 1512 3010 5510 5520 5530 6001 6002 6003 6010 6011 6012 6013 6310	Communication failed. After checking the following contents, please try again after a while. <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<ul style="list-style-type: none"> Various settings could not be completed because communication with the server (cloud) failed. Air conditioner information could not be obtained because communication with server (cloud) failed. <p>Check the following contents and operate again.</p> <ol style="list-style-type: none"> Check that the wireless LAN setting of smartphone is set to ON. Check that the smartphone is connected to the Internet. Check that the wireless router is turned on.

Error code	Error message	Cause
		Solution
0820	Loading of outdoor low noise timer failed. Check the following contents. <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>The outdoor unit low noise timer information could not be obtained because communication with the server (cloud) failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
1520	Loading of weekly timer failed. Check the following contents. <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>The weekly timer setting information could not be obtained because communication with the server (cloud) failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the lamp lights and then operate again. If the lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>

Error code	Error message	Cause
		Solution
1720	Loading of error history failed. Check the following contents. <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>The error history information could not be obtained because communication with the server (cloud) failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Or check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
		<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
3110	<p>Communication failure prevented the group movement processing from being conducted. After checking the following contents, please try again after a while.</p> <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>

Error code	Error message	Cause
		Solution
3111	<p>Communication failure prevented the group creation processing from being conducted. After checking the following contents, please try again after a while.</p> <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
		<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
3112	<p>Communication failure prevented the group name change processing from being conducted. After checking the following contents, please try again after a while.</p> <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
		<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>

Error code	Error message	Cause
		Solution
3113	<p>Communication failure prevented the group deletion processing from being conducted. After checking the following contents, please try again after a while.</p> <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
		<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
3114	<p>The room temperature display indoor unit setting could not be made due to a communication failure. After checking the following contents, please try again after a while.</p> <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
		<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>

Error code	Error message	Cause
		Solution
3115	Some device group move processing could not be conducted due to communication failure. After checking the following contents, please try again after a while. <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>Air conditioner group setting has not been completed because communication with air conditioner failed.</p> <p>Check the following contents depending on the status of indoor unit wireless LAN indicator lamp or WLAN Adapter LED 2 and operate again.</p> <ul style="list-style-type: none"> When not lighting <ul style="list-style-type: none"> Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in. When lighting <p>Use a smartphone to check that the wireless router to which the air conditioner is connected is connected to the Internet. If the smartphone cannot connect to the Internet, reboot the wireless router. When rebooting the wireless router does not solve the problem, contact the manufacturer of the wireless router.</p> When blinking <p>Wait for a while until the indicator lamp lights and then operate again. If the indicator lamp is still blinking after waiting for a while, check that the wireless router is turned on.</p>
5320	Loading of air conditioner information failed. Check the following contents. <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>Air conditioner information could not be obtained because communication with server (cloud) failed.</p> <ol style="list-style-type: none"> Check that the wireless LAN setting of smartphone is set to ON. Check that the smartphone is connected to the Internet. Check that the wireless router is turned on.
5531 5540	New firmware update failed.	<p>Firmware update failed.</p> <p>Check the following contents and operate again.</p> <ol style="list-style-type: none"> Check that the wireless LAN setting of smartphone is set to ON. Check that the smartphone is connected to the Internet. Check that the wireless router is turned on. Refer to the operation manual of air conditioner and check the indicator lamp state of air conditioner indoor unit.
5601	Failed to get the air conditioner information.	<p>Failed to obtain air conditioner information by Direct Control.</p> <p>Sign in again.</p>
5602	Failed to add the air conditioner.	<p>Failed to add air conditioner by Direct Control.</p> <p>Check the following contents and operate again.</p> <ol style="list-style-type: none"> When 2D barcode label is used, scan 2D barcode label again. When 2D barcode label is not used, check that the entered SSID or PIN code is correct.
5630	Device disconnection failed. After checking the following contents, please try again after a while. <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	<p>Failed to disconnect the connection with air conditioner by Direct Control.</p> <p>Check the following contents and operate again.</p> <ol style="list-style-type: none"> Check that the smartphone is connected with the air conditioner. Check that the Electrical panel (Switch breaker) to the air conditioner is turned on. Check that the power plug of the air conditioner main unit is plugged in.

Error code	Error message	Cause
		Solution
6201	<p>Failed to update the screen. After checking the following contents, please try again after a while.</p> <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	Various settings could not be completed because communication with the server (cloud) failed.
		<p>Check the following contents and operate again.</p> <ol style="list-style-type: none"> 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on.
7610	<p>Communication failed. Check the following contents.</p> <ul style="list-style-type: none"> Ensure that your mobile device is connected to the internet. 	Various settings could not be completed because communication with the server (cloud) failed.
		<p>Check the following contents and operate again.</p> <ol style="list-style-type: none"> 1. Check that the wireless LAN setting of smartphone is set to ON. 2. Check that the smartphone is connected to the Internet. 3. Check that the wireless router is turned on.

2. Troubleshooting with error code

2-1. E: 11.X. Serial communication error (Serial reverse transfer error) (Outdoor unit)

Indicator	Indoor unit	Operation indicator	1 time flash
		Timer indicator	1 time flash
		Economy indicator	Continuous flash
		Error code	E: 11
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit	Main PCB	When the indoor unit cannot receive the serial signal from outdoor unit more than 2 minutes after power on, or the indoor unit cannot receive the serial signal more than 15 seconds during normal operation.
		Fan motor	
Forecast of cause			Connection failure
			External cause
			Main PCB failure
			Outdoor unit fan motor failure

Check point 1. Reset the power and operate

Does error indication show again?

→ If no, go to "[Check point 1-2](#)".



Check point 2. Check connection

Check any loose or removed connection line of indoor unit and outdoor unit.

Check connection condition is control unit. (If there is loose connector, open cable or mis-wiring.)

→ If there is an abnormal condition, correct it by referring to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 3. Check the voltage of power supply


Check the voltage of power supply

Check if AC 187 V (AC 208 V -10%) to AC 253 V (AC 230 V +10%) appears at outdoor unit terminal L—N.



Check point 4. Check serial signal (Reverse transfer signal)

Check serial signal (Reverse transfer signal)



- Check if indicated value swings between AC 90 V and AC 270 V at the outdoor unit terminal 1 —3.
- If it is abnormal, check the parts below.
 - Outdoor unit fan motor
- If outdoor fan motor is abnormal, replace outdoor unit fan motor and main PCB.
- If the checked parts are normal, replace the main PCB.



End

Check point 1-2. Check external cause such as noise

- Check the complete insulation of the grounding.
- Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).



End

2-2. E: 11.X. Serial communication error (Serial forward transfer error) (Indoor unit)

Indicator	Indoor unit	Operation indicator	1 time flash
		Timer indicator	1 time flash
		Economy indicator	Continuous flash
		Error code	E: 11
	outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit	Main PCB	When the outdoor unit cannot properly receive the serial signal from indoor unit for 10 seconds or more.
		Fan motor	
	Outdoor unit	Main PCB	
Forecast of cause			Connection failure
			External cause
			Main PCB failure
			Indoor unit fan motor failure

Check point 1. Reset the power and operate

Does error indication show again?

→ If no, go to "[Check point 1-2](#)".



Check point 2. Check connection

Check any loose or removed connection line of indoor unit and outdoor unit.

→ If there is an abnormal condition, correct it by referring to the installation manual or the "DESIGN & TECHNICAL MANUAL".

Check connection condition is control unit. (If there is loose connector, open cable or mis-wiring.)



Check point 3. Check the voltage of power supply


Check the voltage of power supply

Check if AC 187 V (AC 208 V -10%) to AC 253 V (AC 230 V +10%) appears at outdoor unit terminal L—N.



Check point 4. Check serial signal (Forward transfer signal)

Check serial signal (Forward transfer signal)



- Check if indicated value swings between AC 30 V and AC 130 V at outdoor unit terminal 2—3.
- If it is abnormal, replace main PCB.



End

Check point 1-2. Check external cause such as noise

- Check if the ground connection is proper.
- Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).



End

2-3. E: 12.X. Wired remote controller communication error (Indoor unit)

Indicator	Indoor unit	Operation indicator	1 time flash
		Timer indicator	2 time flash
		Economy indicator	Continuous flash
		Error code	E: 12
	outdoor unit		Refer to " Error code table (Outdoor unit) " on page 03-4
Detective actuator	Indoor unit	Main PCB	When the indoor unit cannot receive the signal from Wired remote controller more than 1 minute during normal operation.
	Wired remote control		
Forecast of cause			Connection failure
			Wired remote control failure
			Main PCB failure
			Communication kit

Check point 1. Check the connection of terminal

After turning off the power, check & correct the followings.

- Check the connection of terminal between remote controller and indoor unit, and check if there is a disconnection of the cable.



Check point 2. Check connection

Check voltage at CN300 (terminal 1—3) of Communication Kit. (Power supply to the remote controller)

Upon correcting the removed connector or mis-wiring, reset the power.



- If it is DC 12 V, remote controller is failure. (Main PCB is normal)
 - Replace Remote Control
- If it is DC 0 V, main PCB is failure. (Check remote controller once again)
 - Replace main PCB



End

2-4. E: 18.X. External communication error (Indoor unit)

Indicator	Indoor unit	Operation indicator	1 time flash
		Timer indicator	8 time flash
		Economy indicator	Continuous flash
		Error code	E: 18
	Outdoor unit		Refer to " Error code table (Outdoor unit) " on page 03-4
Detective actuator	Indoor unit	External communication error	After receiving a signal from the external input and output PCB, the same signal has not been received for 15 seconds.
Forecast of cause			Connection failure
			WLAN Adapter failure
			Main PCB

Check point 1. Check the connection

- Check any loose or removed connection between the main PCB to the WLAN Adapter.
-> If there is an abnormal condition, correct it by refer to the installation manual or the "DESIGN & TECHNICAL MANUAL".
- Check the connection condition on the WLAN Adapter and the main PCB (If there is loose connector, open cable or mis-wiring.)



Check point 2. Replace the WLAN Adapter

If check point 1 do not improve the symptom, change WLAN Adapter.



Check point 3. Replace the main PCB

If check point 2 do not improve the symptom, replace the main PCB.



End

2-5. E: 22.X. Indoor unit capacity error (Indoor unit)

Indicator	Indoor unit	Operation indicator	2 time flash
		Timer indicator	2 time flash
		Economy indicator	Continuous flash
		Error code	E: 22
	outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit main PCB	When the total capacity of the indoor units does not match outdoor unit capacity while 3 minutes after power on.	
Forecast of cause		Indoor unit selection is incorrect.	
		Main PCB failure	

Check point 1. Check the total capacity of indoor units

Check the total capacity of the indoor units.

→ If abnormal condition is found, correct it referring to the installation manual or DESIGN & TECHNICAL MANUAL.



Check point 2. Replace the main PCB

If check point 1 does not improve the symptom, replace the main PCB.



End

2-6. E: 23.X. Combination error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	2 time flash
		Timer indicator	3 time flash
		Economy indicator	Continuous flash
		Error code	E: 23
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit	The outdoor unit receives the serial signal of applied refrigerant information from indoor unit.	
Forecast of cause		Incorrect indoor unit is selected.	

Check point 1. Check the type of indoor unit

- Check the type of the connected indoor unit.
-> If there is an abnormal condition, correct it by refer to the installation manual or the "DESIGN & TECHNICAL MANAL".



Check point 2. Replace the main PCB

If check point 1 do not improve the symptom, replace the main PCB of the outdoor unit.



End

2-7. E: 26.X. Address setting error in wired remote controller (Indoor unit)

Indicator	Indoor unit	Operation indicator	2 time flash
		Timer indicator	6 time flash
		Economy indicator	Continuous flash
		Error code	E: 26
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Wired remote controller (2-wire)	<ul style="list-style-type: none"> When the address number set by auto setting and manual setting are mixed in one remote controller group When the duplicated address number exists in one remote controller group 	
	Indoor unit controller PCB		
Forecast of cause		Wrong wiring of remote controller group	
		Wrong remote controller address setting	
		Indoor unit main PCB failure	
		Remote controller failure	

Check point 1. Wire installation

- Check the wire connection in the remote controller group (For installation method, refer to installation manual)
-> If there is an abnormal condition, correct it by refer to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 2. Wrong remote controller group setting

- The given address number by auto setting (00) and the manual set number (except 00) are not existing in one remote controller group.
- The remote controller address setting by UI is not existing same address.
- The duplicate address number is not existing in one remote controller group.



Check point 3. Check indoor unit main PCB

- Check if main PCB is damaged.
- Change main PCB and check the error after setting remote controller address.



End

2-8. E: 29.X. Connected unit number error (Indoor unit)

Indicator	Indoor unit	Operation indicator	2 time flash
		Timer indicator	9 time flash
		Economy indicator	Continuous flash
		Error code	E: 29
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Wired remote controller (2-wire)	When the number of the connected indoor unit exceeds the limitation.	
	Indoor unit main PCB		
Forecast of cause		Wrong wiring of indoor unit or remote controller	
		Number of indoor unit or remote controller in remote controller group	
		Indoor unit main PCB failure	

Check point 1. Wire installation

- Wrong number of connected indoor unit
-> If there is an abnormal condition, correct it by refer to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 2. Check indoor unit main PCB

- Check if main PCB is damaged.
- Change main PCB and check the error after setting remote controller address.



End

2-9. E: 32.X. Indoor unit main PCB error (Indoor unit)

Indicator	Indoor unit	Operation indicator	3 time flash
		Timer indicator	2 time flash
		Economy indicator	Continuous flash
		Error code	E: 32
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit	Main PCB	When power is on and there is some below case. 1. When model information of EEPROM is incorrect. 2. When the access to EEPROM failed.
Forecast of cause			External cause
			Defective connection of electrical components
			Main PCB failure

Check point 1. Reset power supply and operate

Does error indication show again?

→ If no, go to "[Check point 1-2](#)".



Check point 2. Check Indoor unit electrical components

- Check all connectors. (loose connector or incorrect wiring)
- Check any shortage or corrosion on PCB.



Check point 3. Replace the main PCB

Replace the main PCB.



End

Check point 1-2. Check external cause such as noise

- Check if the ground connection is proper.
- Check if there is any equipment that causes harmonic wave near the power cable (Neon light bulb or any electronic equipment which causes harmonic wave).



End

NOTE: EEPROM

EEPROM (Electrically Erasable and Programmable Read Only Memory) is a non-volatile memory which keeps memorized information even if the power is turned off. It can change the contents electronically. To change the contents, it uses higher voltage than normal, and it cannot change a partial contents. (Rewriting shall be done upon erasing the all contents.) There is a limit in a number of rewriting.

2-10. E: 33.X. Indoor unit motor electricity consumption detection error (Indoor unit)

Indicator	Indoor unit	Operation indicator	3 time flash
		Timer indicator	3 time flash
		Economy indicator	Continuous flash
		Error code	E: 33
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit motor electricity consumption detection		When the voltage value or the current value of the motor go beyond the limits
Forecast of cause		Fan motor failure	
		Main PCB failure	

Check point 1. Check the rotation of fan

Rotate the fan by hand when the operation is off. (Check if fan is caught, drop off or locked motor)
→ If fan or bearing is abnormal, replace it.



Check point 2. Check ambient temperature around the motor

Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat.)
→ Upon the temperature coming down, restart operation.



Check point 3. Check indoor unit fan motor

Check indoor unit fan motor. (Refer to indoor unit fan motor in "[Service parts information](#)" on page 03-82.)
→ If indoor unit fan motor is abnormal, replace it.



Check point 4. Replace the main PCB

If check point 1-3 does not improve the symptom, replace the main PCB.



End

2-11. E: 35.X. MANUAL AUTO button error (Indoor unit)

Indicator	Indoor unit	Operation indicator	3 time flash
		Timer indicator	5 time flash
		Economy indicator	Continuous flash
		Error code	E: 35
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit controller PCB	When the MANUAL AUTO button becomes on for consecutive 60 or more seconds.	
	Indicator PCB		
	Manual auto switch		
Forecast of cause		MANUAL AUTO button failure	
		Controller PCB and indicator PCB failure	

Check point 1. Check the MANUAL AUTO button

- Check if MANUAL AUTO button is kept pressed.
- Check ON/OFF switching operation by using a meter.



If MANUAL AUTO button is disabled (ON/OFF switching), replace it.



Check point 2. Replace the main PCB and indicator PCB

If Check Point 1 does not improve the symptom, replace the main PCB and indicator PCB.



End

2-12. E: 39.X. Indoor unit power supply error for fan motor (Indoor unit)

Indicator	Indoor unit	Operation indicator	3 time flash
		Timer indicator	9 time flash
		Economy indicator	Continuous flash
		Error code	E: 39
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit main PCB	<ul style="list-style-type: none"> When a momentary power cut off When do not start fan motor 	
Forecast of cause		External cause	
		Connector connection failure	
		Main PCB failure	

Check point 1. Check external cause at indoor and outdoor (Voltage drop or Noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



Check point 2. Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.

→ Upon correcting the removed connector or mis-wiring, reset the power.



Check point 3. Replace the main PCB

If check point 1 to 2 do not improve the symptom, replace the main PCB.



End

2-13. E: 3A.X. Indoor unit communication circuit (wired remote controller) error

Indicator	Indoor unit	Operation indicator	3 time flash
		Timer indicator	10 time flash
		Economy indicator	Continuous flash
		Error code	E: 3A
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Wired remote controller (2-wire)	Detect the communication error of microcomputer and communication PCB.	
	Indoor unit controller PCB circuit		
Forecast of cause		Communication PCB defective	
		Indoor unit main PCB defective	

Check point 1. Check the connection of terminal

- After turning off the power supply, check and correct the followings
Indoor unit - Check the connection the communication PCB and the main PCB



Check Point 2 : Replace the communication PCB

If the Check point 1 is ok, replace the communication PCB



Check Point 3 : Replace the main PCB

If condition is doesn't change, replace the main PCB



End

2-14. E: 41.X. Room temperature sensor error (Indoor unit)

Indicator	Indoor unit	Operation indicator	4 time flash
		Timer indicator	1 time flash
		Economy indicator	Continuous flash
		Error code	E: 41
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit main PCB	Room temperature thermistor is open or short is detected always.	
	Room temperature thermistor		
Forecast of cause		Connector failure	
		Thermistor failure	
		Main PCB failure	

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

-> Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the room thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-91.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of each indoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.



If the voltage does not appear, replace main PCB.



End

2-15. E: 42.X. Indoor unit heat exchanger sensor error (Indoor unit)

Indicator	Indoor unit	Operation indicator	4 time flash
		Timer indicator	2 time flash
		Economy indicator	Continuous flash
		Error code	E: 42
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit main PCB	When heat exchanger temperature thermistor open or short circuit is detected.	
	Heat exchanger temperature thermistor		
Forecast of cause		Connector connection failure	
		Thermistor failure	
		Main PCB failure	

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

-> Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the heat exchanger thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-91.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of each indoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.



If the voltage does not appear, replace main PCB.



End

2-16. E: 51.X. Indoor unit fan motor error (Indoor unit)

Indicator	Indoor unit	Operation indicator	5 time flash
		Timer indicator	1 time flash
		Economy indicator	Continuous flash
		Error code	E: 51
	outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Indoor unit	main PCB	When the actual rotation number of the indoor unit fan motor is below 1/3 of the target rotation number continuously for more than 56 seconds.
		Fan motor	
Forecast of cause			Fan rotation failure
			Fan motor winding open
			Motor protection by surrounding temperature rise
			Main PCB failure
			Indoor unit fan motor failure

Check point 1. Check rotation of fan

Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor)
→ If fan or bearing is abnormal, replace it.



Check point 2. Check ambient temperature around motor

Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat)
→ Upon the temperature coming down, restart operation.



Check point 3. Check indoor unit fan motor

Check Indoor unit fan motor. (Refer to indoor unit fan motor in "[Service parts information](#)" on page 03-82.)
→ If Indoor unit fan motor is abnormal, replace Indoor unit fan motor.



Check point 4. Replace main PCB

If Check Point 1 to 3 do not improve the symptom, replace main PCB.



End

2-17. E: 5U.X. Indoor unit error

Indicator	Indoor unit	Operation indicator	5 time flash
		Timer indicator	15 time flash
		Economy indicator	Continuous flash
		Error code	E: 5U
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	

Check point. Check following error code.

E: 11.X. Serial communication error (Serial reverse transfer error) (Outdoor unit)

E: 11.X. Serial communication error (Serial forward transfer error) (Indoor unit)

E: 12.X. Wired remote controller communication error (Indoor unit)

E: 18.X. External communication error (Indoor unit)

E: 22.X. Indoor unit capacity error (Indoor unit)

E: 23.X. Combination error (Outdoor unit)

E: 26.X. Address setting error in wired remote controller (Indoor unit)

E: 29.X. Connected unit number error (Indoor unit)

E: 32.X. Indoor unit main PCB error (Indoor unit)

E: 35.X. MANUAL AUTO button error (Indoor unit)

E: 39.X. Indoor unit power supply error for fan motor (Indoor unit)

E: 41.X. Room temperature sensor error (Indoor unit)

E: 42.X. Indoor unit heat exchanger sensor error (Indoor unit)

E: 51.X. Indoor unit fan motor error (Indoor unit)



End

2-18. E: 62.X. Outdoor unit main PCB error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	6 time flash
		Timer indicator	2 time flash
		Economy indicator	Continuous flash
		Error code	E: 62
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit	Main PCB	Access to EEPROM failed due to some cause after outdoor unit started.
Forecast of cause			External cause (Noise, temporary open, voltage drop)
			Main PCB failure

Check point 1. Reset power supply and operate

Does error indication show again?

If no, go to "[Check point 1-2](#)".



Check point 2. Replace the main PCB

Replace the main PCB.



End

Check point 1-2. Check external cause

- Check if temporary voltage drop was not generated.
- Check if momentary open was not generated.
- Check if ground is connection correctly or there are no related cables near the power line.



End

2-19. E: 64.X. PFC circuit error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	6 time flash
		Timer indicator	4 time flash
		Economy indicator	Continuous flash
		Error code	E: 64
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit	Main PCB	<ul style="list-style-type: none"> When inverter input DC voltage is higher than 415 V for over 3 seconds, the compressor stops. If the same operation is repeated 5 times, the compressor stops permanently.
Forecast of cause			External cause
			Connector connection failure
			Main PCB failure

Check point 1. Check external cause at indoor and outdoor (Voltage drop or Noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



Check point 2. Check connection of Connector

- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.

→ Upon correcting the removed connector or mis-wiring, reset the power.



Check point 3. Replace the main PCB

If check point 1 to 2 do not improve the symptom, replace the main PCB.



End

2-20. E: 65.X. IPM error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	6 time flash
		Timer indicator	5 time flash
		Economy indicator	Continuous flash
		Error code	E: 65
	Outdoor unit	Refer to "Error code table (Outdoor unit)" on page 03-4	
Detective actuator	Outdoor unit	Main PCB	<div>1. When more than normal operating current to IPM in main PCB flows, the compressor stops.</div> <div>2. After the compressor restarts, if the same operation is repeated within 40 seconds, the compressor stops again.</div> <div>3. If 1. and 2. repeats 5 times, the compressor stops permanently.</div>
		Compressor	
Forecast of cause			Defective connection of electrical components
			Outdoor fan operation failure
			Outdoor heat exchanger clogged
			Compressor failure
			Main PCB failure

Check point 1. Check connections of outdoor unit electrical components

- Check if the terminal connection is loose.
- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.

→ Upon correcting the removed connector or mis-wiring, reset the power.



Check point 2. Check outdoor fan and heat exchanger

- Is there anything obstructing the air distribution circuit?
- Is there any clogging of outdoor heat exchanger?
- Is the fan rotating by hand when operation is off?

→ If the fan motor is locked, replace it.



Check point 3. Check outdoor fan

Check outdoor fan motor. (Refer to "[E: 97.X. Outdoor unit fan motor error \(Outdoor unit\)](#)" on page 03-58.)

→ If the fan motor is failure, replace it.



Check point 4. Check compressor

Check compressor. (Refer to inverter compressor in "[Service parts information](#)".)



Check point 5. Replace main PCB

If Check point 1 to 4 do not improve the symptom, change main PCB.



End

2-21. E: 71.X. Discharge thermistor error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	7 time flash
		Timer indicator	1 time flash
		Economy indicator	Continuous flash
		Error code	E: 71
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit main PCB	When discharge pipe temperature thermistor open or short circuit is detected at power on or while running the compressor	
	Discharge pipe temperature thermistor		
Forecast of cause		Connector failure	
		Thermistor failure	
		Main PCB failure	

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

→ Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the discharge temperature thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-91.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.



If the voltage does not appear, replace main PCB.



End

2-22. E: 72.X. Compressor thermistor error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	7 time flash
		Timer indicator	2 time flash
		Economy indicator	Continuous flash
		Error code	E: 72
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit main PCB	When compressor temperature thermistor open or short circuit is detected at power on or while running the compressor	
	Compressor temperature thermistor		
Forecast of cause		Connector failure	
		Thermistor failure	
		Main PCB failure	

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

→ Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the compressor thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-91.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.



If the voltage does not appear, replace main PCB.



End

2-23. E: 73.X. Outdoor unit heat exchanger liquid outlet thermistor error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	7 time flash
		Timer indicator	3 time flash
		Economy indicator	Continuous flash
		Error code	E: 73
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit main PCB	When heat exchanger temperature thermistor open or short circuit is detected at power on or while running the compressor	
	Heat exchanger temperature thermistor		
Forecast of cause		Connector failure	
		Thermistor failure	
		Main PCB failure	

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

→ Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the outdoor unit heat exchanger thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-91.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.

If the voltage does not appear, replace main PCB.



End

2-24. E: 74.X. Outdoor temperature thermistor error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	7 time flash
		Timer indicator	4 time flash
		Economy indicator	Continuous flash
		Error code	E: 74
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit main PCB	When outdoor temperature thermistor open or short circuit is detected at power on or while running the compressor	
	Outdoor temperature thermistor		
Forecast of cause		Connector failure	
		Thermistor failure	
		Main PCB failure	

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

-> Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the outdoor temperature thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-91.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of main PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.



If the voltage does not appear, replace main PCB.



End

2-25. E: 77.X. Heat sink thermistor error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	7 time flash
		Timer indicator	7 time flash
		Economy indicator	Continuous flash
		Error code	E: 77
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Heat sink temperature thermistor	Heat sink temperature thermistor short or open detected	
Forecast of cause		Connector failure	
		Thermistor failure	
		Inverter PCB failure	

Check point 1. Check connection of connector


- Check if connector is loose or removed.
- Check erroneous connection.
- Check if thermistor cable is open

-> Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Remove connector and check thermistor resistance value

- For the Heat sink thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-91.
- If thermistor is either open or shorted, replace it and reset the power.



Check point 3. Check voltage of inverter PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V).

NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.



If the voltage does not appear, replace inverter PCB.



End

2-26. E: 84.X. Current sensor error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	8 time flash
		Timer indicator	4 time flash
		Economy indicator	Continuous flash
		Error code	E: 84
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit	Main PCB	When input current sensor has detected 0 A, while inverter compressor is operating at higher than 56 rps, after 1 minute upon starting the compressor. (Except during the defrost operation)
		Inverter PCB	
Forecast of cause			Defective connection of electrical components
			External cause
			Inverter PCB failure
			Main PCB failure

Check point 1. Reset power supply and operate

Does error indication show again?

If no, go to "[Check point 1-2](#)".



Check point 2. Check connections of outdoor unit electrical components

- Check if the terminal connection is loose.
- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.

Upon correcting the removed connector or miswiring, reset the power.



Check point 3. Replace the Inverter PCB

If Check point 1, 2 do not improve the symptom, replace the Inverter PCB.

If the model does not have an Inverter PCB, go to "[Check point 4](#)".



Check point 4. Replace the Main PCB

If Check point 3 do not improve the symptom, replace the Main PCB.



End

Check point 1-2. Check external cause at Indoor and Outdoor (Voltage drop or Noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.

**End**

2-27. E: 86.X. High pressure switch error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	8 time flash
		Timer indicator	6 time flash
		Economy indicator	Continuous flash
		Error code	E: 86
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit main PCB	When pressure switch open is detected in 10 seconds after the power is turned on.	
	High pressure switch		
Forecast of cause		High pressure switch connector disconnection or open	
		High pressure switch characteristics failure	
		Main PCB failure	

Check point 1. Check the high pressure switch connection state

- Check connector and wiring connection state.
- Check if cable is open

-> Reset power when reinstalling due to removed connector or incorrect wiring.



Check point 2. Check the high pressure switch characteristics

- Check switch characteristics.
For the characteristics of the high pressure switch, refer to below.




Check point 3. Replace main PCB

Change main PCB and check operation again.



End

- Type of contact



- Characteristics of pressure switch

Pressure switch 1	
Contact: Short → Open	4.2 ±0.1 MPa
Contact: Open → Short	3.2 ±0.15 MPa

P770

2-28. E: 86.X. Pressure sensor error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	8 time flash
		Timer indicator	6 time flash
		Economy indicator	Continuous flash
		Error code	E: 86
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit main PCB	30 seconds or more after power-on, when pressure sensor detection value detects the condition below continuously for 30 seconds or more. $P_s \leq 0$ or $P_s \geq 5$ [MPa]	
	High pressure switch		
Forecast of cause		Connector connection failure	
		Pressure sensor failure	
		Main PCB failure	

Check point 1. Check connection of the pressure sensor

- Check if the terminal connection is loose.
- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open.

-> Upon correcting the removed connector or mis-wiring, reset the power.



Check point 2. Check output voltage of main PCB

Make sure circuit diagram of outdoor unit and check terminal voltage at thermistor (DC 5.0 V \pm 5%).


NOTE: For details of thermistor connector, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.

If the voltage is not correct, replace main PCB.



Check point 3. Check output voltage of pressure sensor

Make sure circuit diagram of outdoor unit and check terminal voltage. Voltage is refer to the following graph.



If the voltage is not correct, replace pressure sensor.



End

2-29. E: 94.X. Over current error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	9 time flash
		Timer indicator	4 time flash
		Economy indicator	Continuous flash
		Error code	E: 94
	outdoor unit	Refer to "Error code table (Outdoor unit)" on page 03-4	
Detective actuator	Outdoor unit	Main PCB	Protection stop by over-current generation after inverter compressor start processing completed generated consecutively 10 times. NOTE: The number of generations is reset when the compressor starts up.
		Compressor	
Forecast of cause			Outdoor unit fan operation defective, foreign matter on heat-exchanger, excessive rise of ambient temperature
			Main PCB failure
			Inverter compressor failure (lock, winding short)

Check point 1. Check the outdoor unit fan operation, heat-exchanger, ambient temperature

- No obstructions in air passages?
- Heat exchange fins clogged
- Outdoor unit fan motor check
- Ambient temperature not raised by the effect of other heat sources?
- Discharged air not sucked in?



Check point 2. Replace main PCB

If Check point 1 do not improve the symptom, change main PCB.



Check point 3. Replace compressor

If Check point 2 do not improve the symptom, change compressor.



End

2-30. E: 95.X. Compressor motor control error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	9 time flash
		Timer indicator	5 time flash
		Economy indicator	Continuous flash
		Error code	E: 95
	outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit	Main PCB	<div>1. When running the compressor, if the detected rotor location is out of phase with actual rotor location more than 90°, the compressor stops.</div> <div>2. After the compressor restarts, if the same operation is repeated within 40 seconds, the compressor stops again.</div> <div>3. If 1. and 2. repeats 5 times, the compressor stops permanently.</div>
		Compressor	
Forecast of cause			Defective connection of electrical components
			Main PCB failure
			Compressor failure

Check point 1. Check Noise from Compressor

Turn on Power and check operation noise.
→ If an abnormal noise show, replace compressor.



Check point 2. Check connection of around the compressor components

For compressor terminal, main PCB

- Check if connector is removed.
- Check erroneous connection.
- Check if cable is open. (Refer to inverter compressor in "[Service parts information](#)" on page 03-82.)

→ Upon correcting the removed connector or mis-wiring, reset the power.



Check point 3. Replace the main PCB

If Check point 1, 2 do not improve the symptom, replace the main PCB.



Check point 4. Replace compressor

If Check point 3 do not improve the symptom, change compressor.



End

2-31. E: 97.X. Outdoor unit fan motor error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	9 time flash
		Timer indicator	7 time flash
		Economy indicator	Continuous flash
		Error code	E: 97
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit	Main PCB	<div>1. When outdoor fan rotation speed is less than 100 rpm in 20 seconds after fan motor starts, fan motor stops.</div> <div>2. After fan motor restarts, if the same operation within 60 seconds is repeated 3 times in a row, compressor and fan motor stops.</div> <div>3. If 1. and 2. repeats 5 times in a row, compressor and fan motor stops permanently.</div>
		Fan motor	
Forecast of cause			Fan rotation failure
			Motor protection by surrounding temperature rise
			Main PCB failure
			Outdoor unit fan motor

Check point 1. Check rotation of fan

Rotate the fan by hand when operation is off. (Check if fan is caught, dropped off or locked motor)
→ If fan or bearing is abnormal, replace it.



Check point 2. Check ambient temperature around motor

Check excessively high temperature around the motor. (If there is any surrounding equipment that causes heat)
→ Upon the temperature coming down, restart operation.



Check point 3. Check outdoor unit fan motor

Check outdoor unit fan motor. (Refer to outdoor unit fan motor in "[Service parts information](#)" on page 03-82.)
→ If outdoor unit fan motor is abnormal, replace outdoor unit fan motor and main PCB.



Check point 4. Check output voltage of main PCB

Check outdoor unit circuit diagram and the voltage. (Measure at main PCB side connector)

NOTE: For details of wiring diagram, refer to "[Wiring diagrams](#)" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.



Read wire	DC voltage
Red—Black	280 V \pm 10% (09/12 models), 240—400 V (18/24 models), 262—362 V (30/36 models)
White—Black	15 \pm 1.5 V

-> If the voltage is not correct, replace Main PCB.



End

2-32. E: 99.X. 4-way valve error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	9 time flash
		Timer indicator	9 time flash
		Economy indicator	Continuous flash
		Error code	E: 99
	outdoor unit		Refer to " Error code table (Outdoor unit) " on page 03-4
Detective actuator	Indoor unit	main PCB	When the indoor heat exchanger temperature is compared with the room temperature, and either following condition is detected continuously two times, the compressor stops. Indoor heat exchanger temp. - Room temp. > 20°F (10°C) (Cooling or Dry operation) Indoor heat exchanger temp. - Room temp. < -20°F (-10°C) (Heating operation) If the same operation is repeated 5 times, the compressor stops permanently.
	Heat exchanger temperature thermistor		
	Room temperature thermistor		
	4-way valve		
Forecast of cause			Connector connection failure
			Thermistor failure
			Coil failure
			4-way valve failure
			Main PCB failure

Check point 1. Check connection of connector

- Check if connector is removed.
- Check erroneous connection.
- Check if thermistor cable is open.

→ Upon correcting the removed connector or mis-wiring, reset the power.



Check point 2. Check each thermistor

- Isn't it fallen off the holder?
- Is there a cable pinched?

Check characteristics of room thermistor and indoor unit heat exchanger thermistor.

For the thermistor resistance value, refer to "[Thermistor resistance values](#)" on page 03-91.

→ If defective, replace the thermistor.



Check point 3. Check the solenoid coil and 4-way valve

NOTE: Refer solenoid coil and 4-way valve in "[Service parts information](#)" on page 03-82.

- **Solenoid coil**

Remove P60 from PCB and check the resistance value of coil. Resistance value is below.

- 09/12 models: 2.085 kΩ (at 68°F [20°C])
- 18/24/30/36 models: 1.970 kΩ (at 68°F [20°C])

→ If it is open or abnormal resistance value, replace solenoid coil.

- **4-way valve**

Check each piping temperature, and the location of the valve by the temperature difference.

If the value location is not proper, replace 4-way valve.

**Check point 4. Replace main PCB**

If Check Point 1 to 3 do not improve the symptom, replace main PCB.



End

2-33. E: A1.X. Discharge temperature error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	10 time flash
		Timer indicator	1 time flash
		Economy indicator	Continuous flash
		Error code	E: A1
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit main PCB	Protection stop by discharge temperature $\geq 230^{\circ}\text{F}$ (110°C) during compressor operation generated 2 times within 24 hours.	
	Discharge temperature thermistor		
Forecast of cause		3-way valve not opened	
		EEV or capillary tube defective, strainer clogged	
		Outdoor unit operation failure, foreign matter on heat exchanger	
		Discharge temperature thermistor failure	
		Insufficient refrigerant	
		Main PCB failure	

Check point 1. Check if 3-way valve is open

If the 3-way valve is closed, open the 3-way valve and check operation.

NOTE: For cooling operation, check gas side of the 3-way valve.
For heating operation, check liquid side of the 3-way valve.



Check point 2. Check any of the electronic expansion valve (EEV), capillary tube, or strainer, or all

- Check if EEV open or there is a capillary tube defect.
Refer to outdoor unit Electronic Expansion Valve (EEV) or Capillary tube in "[Service parts information](#)" on page 03-82.
- Check the strainer clogging.



Check point 3. Check the outdoor unit fan and heat exchanger

- Check for foreign object at heat exchanger
- Check if fan can be rotated by hand.
- Check the motor. (Refer to outdoor unit fan motor in "[Service parts information](#)" on page 03-82.)



Check point 4. Check the discharge thermistor

The discharge temperature thermistor characteristics check. (Check by disconnecting thermistor from PCB.)

NOTE: For the characteristics of the thermistor, refer to "[Thermistor resistance values](#)" on page 03-91.



Check point 5. Check the refrigerant amount

Check the refrigerant leakage.



Check point 6. Replace the main PCB

If check point 1 to 5 do not improve the symptom, replace the main PCB.



End

2-34. E: A3.X. Compressor temperature error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	10 time flash
		Timer indicator	3 time flash
		Economy indicator	Continuous flash
		Error code	E: A3
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit main PCB	Protection stop by compressor temperature $\geq 226^{\circ}\text{F}$ (108°C) during compressor operation generated 2 times within 24 hours.	
	Compressor temperature thermistor		
Forecast of cause		3-way valve not opened	
		EEV defective, strainer clogged	
		Outdoor unit operation failure, foreign matter on heat exchanger	
		Compressor temperature thermistor failure	
		Insufficient refrigerant	
		Main PCB failure	

Check point 1. Check if 3-way valve is open

If the 3-way valve is closed, open the 3-way valve and check operation.

NOTE: For cooling operation, check gas side of the 3-way valve.
For heating operation, check liquid side of the 3-way valve.



Check point 2. Check the electronic expansion valve (EEV) and strainer

- Check if EEV open.
Refer to outdoor unit Electronic Expansion Valve (EEV) in "[Service parts information](#)" on page 03-82.
- Check the strainer clogging.



Check point 3. Check the outdoor unit fan and heat exchanger

- Check for foreign object at heat exchanger
- Check if fan can be rotated by hand.
- Check the motor. (Refer to outdoor unit fan motor in "[Service parts information](#)" on page 03-82.)



Check point 4. Check the compressor thermistor

The compressor temperature thermistor characteristics check. (Check by disconnecting thermistor from PCB.)

NOTE: For the characteristics of the thermistor, refer to "[Thermistor resistance values](#)" on page 03-91.



Check point 5. Check the refrigerant amount

Check the refrigerant leakage.



Check point 6. Replace the main PCB

If check point 1 to 5 do not improve the symptom, replace the main PCB.



End

2-35. E: AC.X. Heat sink temperature error (Outdoor unit)

Indicator	Indoor unit	Operation indicator	10 time flash
		Timer indicator	11 time flash
		Economy indicator	Continuous flash
		Error code	E: AC
	Outdoor unit	Refer to " Error code table (Outdoor unit) " on page 03-4	
Detective actuator	Outdoor unit inverter PCB	Protection stop by heat sink temperature $\geq 176^{\circ}\text{F}$ (80°C) during heat sink operation generated 2 times within 24 hours.	
	Heat sink temperature thermistor		
Forecast of cause		Foreign matter on heat sink, heat sink dirty	
		Foreign matter on heat exchanger, excessive ambient temperature rise	
		Heat sink temp. thermistor defective	

Check point 1. Check the heat sink state

Heat sink foreign matter, soiling check



Check point 2. Check the foreign matter and ambient temperature of heat exchanger

- Heat exchange foreign matter check
- Ambient temperature not raised by effect of other heat sources?
- Discharged air not sucked in?



Check point 3. Check the heat sink temperature thermistor

The heat sink temperature thermistor characteristics check. (Check by disconnecting thermistor from PCB.)

NOTE: For the characteristics of the thermistor, refer to "[Thermistor resistance values](#)" on page 03-91.



Check point 4. Replace inverter PCB

Replace inverter PCB



End

3. Troubleshooting without error code

3-1. Indoor unit—No power

Forecast of cause	Power supply failure
	External cause
	Electrical components defective

Check point 1. Check installation condition

- Isn't the breaker down?
- Check loose or removed connection cable.

-> If abnormal condition is found, correct it by referring to the installation manual or the *DESIGN & TECHNICAL MANUAL*.



Check point 2. Check external cause at indoor and outdoor (voltage drop or noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



Check point 3. Check electrical components

Check the voltage of power supply.

Check if AC 187 to 253 V appears at outdoor unit terminal L—N.

-> If no, go to "[Check point 1](#)" and "[Check point 2](#)".



- Check fuse in the Filter PCB.
If fuse is open, check if the wiring between terminal and filter PCB is loose, and replace the Filter PCB.
- Check varistor in the Filter PCB.
If varistor is defective, there is a possibility of an abnormal power supply.
Check the correct power supply and replace the Filter PCB.
Upon checking the normal power supply, replace the Filter PCB.



End

3-2. Outdoor unit—No power

Forecast of cause	Power supply failure
	External cause
	Electrical components defective

Check point 1. Check installation condition

- Is the circuit breaker on or off?
- Check loose or removed connection cable.

→ If abnormal condition is found, correct it by referring to the installation manual or the *DESIGN & TECHNICAL MANUAL*.



Check point 2. Check external cause at indoor and outdoor (voltage drop or noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



Check point 3. Check electrical components

Check the voltage of power supply.

Check if AC 187 to 253 V appears at outdoor unit terminal L—N

→ If no, go to "[Check point 1](#)" and "[Check point 2](#)".



- Check fuse in main PCB.
If fuse is open, check if the wiring between terminal and main PCB is loose, and replace the Main PCB.
- Check varistor in the Main PCB.
If varistor is defective, there is a possibility of an abnormal power supply. Check the correct power supply and replace the Main PCB.
→ Upon checking the normal power supply, replace the Main PCB.



Check point 4. Replace the main PCB

If check point 1 to 3 do not improve the symptom, replace the main PCB.



End

3-3. No operation (Power is on)

Forecast of cause	Setting/ Connection failure
	External cause
	Electrical components defective

Check point 1. Check indoor and outdoor installation condition

- Indoor unit:
 - Check incorrect wiring between indoor unit and remote controller.
 - Check if there is an open cable connection.
 - Are these indoor unit, outdoor unit, and remote controller suitable model names to connect?
- > If there is some abnormal condition, correct it by referring to the installation manual and "DESIGN & TECHNICAL MANUAL".



Turn off the power and check correct followings.

- Is there loose or removed communication line of indoor unit and outdoor unit?



Check point 2. Check external cause at indoor and outdoor (Voltage drop or Noise)

- Instant drop: Check if there is a large load electric apparatus in the same circuit.
- Momentary power failure: Check if there is a defective contact or leak current in the power supply circuit.
- Noise: Check if there is any equipment causing harmonic wave near electric line. (Neon bulb or electric equipment that may cause harmonic wave)
Check the complete insulation of grounding.



Check point 3. Check wired remote controller and controller PCB

Check voltage at CN13 (terminal 1—3) of main PCB.

(Power supply to remote controller)

- If it is DC 12 V, remote controller is failure. (The controller PCB is normal)
-> Replace remote controller.
- If it is DC 0 V, controller PCB is failure. (Check the remote controller once again)
-> Replace controller PCB.



Check point 4. Replace main PCB

If check point 1 to 3 do not improve the symptom, change main PCB.



End

3-4. No cooling/No heating

Forecast of cause	Indoor unit error
	Outdoor unit error
	Effect by surrounding environment
	Connection pipe/Connection wire failure
	Refrigeration cycle failure

Check point 1. Check Indoor unit

- Does Indoor unit fan run in the HIGH mode?
- Is air filter dirty?
- Is heat exchanger clogged?
- Check if energy save function is operated.



Check point 2. Check outdoor unit operation

- Check if outdoor unit is operating.
- Check any objects that obstruct the air flow route.
- Check if heat exchanger is clogged.
- Is the valve open?



Check point 3. Check site condition

- Is capacity of Indoor unit fitted to the room size?
- Any windows open or direct sunlight?



Check point 4. Check indoor/outdoor installation condition


- Check connection pipe (specified pipe length and pipe diameter?)
- Check any loose or removed communication line.

→ If there is an abnormal condition, correct it by referring to the installation manual or the "DESIGN & TECHNICAL MANUAL".



Check point 5. Check Refrigeration cycle

- Check if strainer is clogged (Refer to the figure below).
- Measure gas pressure, and if there is a leakage, correct it.
- Check if EEV open or there is a capillary tube defect.
Refer to outdoor unit Electronic Expansion Valve (EEV) or Capillary tube in ["Service parts information"](#) on page 03-82.
- Check compressor.
Refer to compressor in ["Service parts information"](#) on page 03-82.
Refer to inverter compressor in ["Service parts information"](#) on page 03-82.




NOTE: When recharging the refrigerant, make sure to perform vacuuming, and recharge the specified amount.




End

NOTES:

- Strainer normally does not have temperature difference between inlet and outlet as shown below.



- If there is a difference like shown below, there is a possibility of inside clogged. In this case, replace the strainer.



3-5. Abnormal noise

Forecast of cause	Abnormal installation (indoor unit/outdoor unit)
	Fan failure (indoor unit/outdoor unit)
	Compressor failure (outdoor)

Diagnosis method when abnormal noise is occurred

Abnormal noise is coming from Indoor unit.
(Check and correct followings)



- Is main unit installed in stable condition?
- Is the installation of air suction grille and front panel normal?



- Is fan broken or deformed?
- Is the screw of fan loose?
- Is there any object which obstruct the fan rotation?



End

Abnormal noise is coming from Outdoor unit.
(Check and correct followings)



- Is main unit installed in stable condition?
- Is fan guard installed normally?



- Is fan broken or deformed?
- Is the screw of fan loose?
- Is there any object which obstruct the fan rotation?



Check if vibration noise by loose bolt or contact noise of piping is happening.



Is compressor locked?


- Check Compressor
Refer to compressor and inverter compressor in "[Service parts information](#)" on page 03-82.



End

3-6. Water leaking

Forecast of cause	Erroneous installation
	Drain hose failure




TROUBLESHOOTING

TROUBLESHOOTING

4. Troubleshooting with error code (For wireless LAN adapter)

4-1. E: 18.X. External communication error between indoor unit and wireless LAN adapter

Indicator	Indoor unit	Operation indicator	1 time flash
		Timer indicator	8 time flash
		Economy indicator	Continuous flash
		Wireless LAN indicator	Flashing slowly
		Error code	E: 18
	Mobile app		E: 18.1
Detective actuator	Wireless LAN adapter PCB		After receiving a signal from the wireless LAN adapter, the same signal has not been received for 15 seconds.
	Controller PCB		
			
Forecast of cause			Connection between indoor unit and wireless LAN adapter failure
			Wireless LAN adapter PCB failure
			Controller PCB failure

Check point 1. Check the connection

- Check any loose or removed connection of between the wireless LAN adapter PCB and controller PCB.
-> If there is abnormal condition, correct it.
- Check the connection condition on the controller PCB.
-> If there is loose connector, open cable or mis-wiring, correct it.



Check point 2. Replace wireless LAN adapter.

If check point 1 do not improve the symptom, replace the wireless LAN adapter and cancel the registration of air conditioner on the Mobile app.
After replacing the adapter, perform the pairing on the Mobile app.

For the method of the Mobile app, refer to ["Mobile app setting method"](#) on page 03-80.




Check point 3. Replace controller PCB

If check point 1 to 2 do not improve the symptom, replace the controller PCB.



End

4-2. Network communication error between wireless LAN router and wireless LAN adapter

Indicator	Indoor unit	Operation indicator	No indication
		Timer indicator	No indication
		Economy indicator	No indication
		Wireless LAN indicator	Flashing slowly
		Error code	—
	Mobile app		No indication
Detective actuator	Wireless LAN router	When the not connection between wireless LAN adapter and wireless LAN router. 	
	Wireless LAN adapter PCB		
Forecast of cause	Connection cable failure of wireless LAN router		
	Connection between wireless LAN adapter and wireless LAN router failure		
	Wireless LAN router failure		
	Wireless LAN adapter PCB failure		

Check point 1. Check the connection cable

Check the connection cable on the wireless LAN router.

-> If there is loose connector, open cable or mis-wiring, correct it.



Check point 2. Check the connection status.

Check the connection status to the Internet and wireless LAN router.

-> If the wireless LAN router is not connected to the Internet, check the transmission between wireless LAN products (ex. PC or game console, etc.) other than air conditioner and wireless LAN router.

If no, go to ["Check point 2-2"](#).



Check point 3. Turn on the power again of air conditioner.

If check point 1 to 2 do not improve the symptom, turn on the power of the air conditioner again and wait for 60 seconds.



Check point 4. Replace wireless LAN adapter.

If check point 3 do not improve the symptom, replace the wireless LAN adapter and cancel the registration of air conditioner on the Mobile app.

After replacing the adapter, perform the pairing on the Mobile app.

For the method of the Mobile app, refer to "[Mobile app setting method](#)" on page 03-80.


**End****Check point 2-2. Check the transmission state**

Check the wireless transmission state of the wireless LAN router (indicator lamp status).

-> If the wireless transmission from the wireless LAN router has not been outgoing, inquire to the wireless LAN router maker.

**End**

4-3. E: 18.X. Communication error

Indicator	Indoor unit	Operation indicator	1 time flash
		Timer indicator	8 time flash
		Economy indicator	Continuous flash
		Wireless LAN indicator	Flashing slowly
		Error code	E: 18
	Mobile app	E: 18.1	
Detective actuator	Wireless LAN router	When the external communication error between indoor unit and wireless LAN adapter and network communication error between wireless LAN router and wireless LAN adapter has occurred simultaneously. 	
	Wireless LAN adapter PCB		
	Indoor unit controller PCB		
Forecast of cause	Connection cable failure of wireless LAN router		
	Wireless LAN router failure		
	Connection between indoor unit and wireless LAN adapter failure		
	Connection between wireless LAN adapter and wireless LAN router failure		
	Wireless LAN adapter PCB failure		
	Controller PCB failure		

Check point 1. Check the connection

- Check any loose or removed connection of between the wireless LAN adapter PCB and controller PCB.
-> If there is abnormal condition, correct it.
- Check the connection condition on the controller PCB.
-> If there is loose connector, open cable or mis-wiring, correct it.



Check point 2. Replace wireless LAN adapter.

If check point 1 do not improve the symptom, replace the wireless LAN adapter and cancel the registration of air conditioner on the Mobile app.
After replacing the adapter, perform the pairing on the Mobile app.

For the method of the Mobile app, refer to ["Mobile app setting method"](#) on page 03-80.



Check point 3. Replace controller PCB

If check point 1 to 2 do not improve the symptom, replace the controller PCB.



Check point 4. Check the connection cable

Check the connection cable on the wireless LAN router.

-> If there is loose connector, open cable or mis-wiring, correct it.

**Check point 5. Check the connection status.**

Check the connection status to the Internet and wireless LAN router.

-> If the wireless LAN router is not connected to the Internet, check the transmission between wireless LAN products (ex. PC or game console, etc.) other than air conditioner and wireless LAN router.

If no, go to ["Check point 5-2"](#).

**Check point 6. Turn on the power again of air conditioner.**

If check point 1 to 2 do not improve the symptom, turn on the power of the air conditioner again and wait for 60 seconds.

**Check point 7. Replace wireless LAN adapter.**

If check point 3 do not improve the symptom, replace the wireless LAN adapter and cancel the registration of air conditioner on the Mobile app.

After replacing the adapter, perform the pairing on the Mobile app.

For the method of the Mobile app, refer to ["Mobile app setting method"](#) on page 03-80.



End

Check point 5-2. Check the transmission state

Check the wireless transmission state of the wireless LAN router (indicator lamp status).

-> If the wireless transmission from the wireless LAN router has not been outgoing, inquire to the wireless LAN router maker.



End

4-4. E: 18.X. Wireless LAN adapter non-energized

Indicator	Indoor unit	Operation indicator	1 time flash
		Timer indicator	8 time flash
		Economy indicator	Continuous flash
		Wireless LAN indicator	No indication
		Error code	E: 18
	Mobile app	No indication	
Detective actuator	Indoor unit controller PCB	When the voltage (DC 12 V) does not output from the controller PCB.	
	Wireless LAN adapter PCB		
Forecast of cause			Indoor unit controller PCB failure
			Wireless LAN adapter PCB failure
			Wiring connection failure

Check point 1. Check the connection.

- Check any loose or removed connection of between the wireless LAN adapter PCB and controller PCB.
-> If there is abnormal condition, correct it.
- Check the connection condition on the controller PCB.
-> If there is loose connector, open cable or mis-wiring, correct it.



Check point 2. Check the wireless LAN adapter PCB and the controller PCB

Check voltage at CN13 (terminal 1—3) of main PCB.

(Power supply to remote controller)

- If it is DC 0 V, controller PCB is failure.
-> Replace controller PCB.
- If it is DC 12 V, wireless LAN adapter PCB is failure.
-> Replace the wireless LAN adapter and cancel the registration of air conditioner on the Mobile app.

After replacing the adapter, perform the pairing on the Mobile app.

For the method of the Mobile app, refer to ["Mobile app setting method"](#) on page 03-80.



End


4-5. Mobile app setting method


■ Air conditioner delete method

When the wireless LAN adapter is replaced, delete of all air conditioner is necessary on the mobile app.


1. Launch the mobile app.




2. Tap the  icon to display the Setting screen.




3. Tap the “Air conditioner editing”.




4. Tap the air conditioner to be deleted.



5. Tap the Delete button.



6. Tap the OK button.




7. Deletion of the air conditioner registered in the mobile app is completed.

5. Service parts information

5-1. Compressor

Diagnosis method of compressor (If outdoor unit LED displays error, refer to troubleshooting)




5-2. Inverter compressor


■ Models: AOUH09KPAS1, AOUH12KPAS1, AOUH18KPAS1, and AOUH24KPAS1

Check point 1. Check connection

- Check terminal connection of compressor (loose or incorrect wiring)



- Check terminal connection of main PCB (loose or incorrect wiring)





↓

Check point 2. Check winding resistance

Check winding resistance of each terminal.

Resistance value

- 09/12 models: $2.180 \Omega \pm 7\%$ at 68°F (20°C)
- 18/24 models: $1.916 \Omega \pm 8\%$ at 68°F (20°C)



→ If the resistance value is 0Ω or infinite, replace compressor.

↓

Check point 3. Replace inverter PCB


If check point 1 to 2 do not improve the symptom, replace main PCB.

■ Models: AOUH30KPAS1 and AOUH36KPAS1

Check point 1. Check the terminal connection.


- Check the following terminal connections of the compressor. (Loosening or incorrect wiring.)

R (U): Red
S (V): White
C (W): Black





- Check the following terminal connections of the Inverter PCB. (Loosening or incorrect wiring.)

P400 (U): Red
P401 (V): White
P402 (W): Black

**Check point 2. Check the winding resistance.**

Check the winding resistance of each terminal.

Resistance value: $1.125 \Omega \pm 7\%$ at 77°F (25°C)



→ If the resistance value is 0Ω or infinite, replace the compressor.

**Check point 3. Replace the Inverter PCB.**

If check point 1 to 2 do not improve the symptom, replace the Inverter PCB.

5-3. Outdoor unit Electronic Expansion Valve (EEV)

Check point 1. Check connections


Check connection of connector. (Loose connector or open cable)

NOTE: For details of wiring diagram, refer to "Wiring diagrams" in Chapter 2. TECHNICAL DATA AND PARTS LIST on page 02-36.

Check point 2. Check coil of EEV

Remove connector, check each winding resistance of coil.

Read wire	Resistance value
1 (Red) - 2 (Blue)	$46 \Omega \pm 4 \Omega$ at 68°F (20°C)
1 (Red) - 3 (Orange)	
1 (Red) - 4 (Yellow)	
1 (Red) - 5 (White)	



→ If Resistance value is abnormal, replace EEV.

Check point 3. Check Voltage from main PCB

Remove connector and check voltage (DC 12 V)

→ If it does not appear, replace main PCB.



Check point 4. Check noise at start up

Turn on the power and check the operation noise.


→ If an abnormal noise does not show, replace main PCB.

Check point 5. Check Opening and Closing Operation of Valve

When valve is closed, it has a temp. difference between inlet and outlet

CLOSE
Example : Hot Gas


Pipe (In)
Hi TEMP.



If it is open, it has no temp. difference between inlet and outlet


OPEN
Example : Hot Gas

Pipe (In)
Hi TEMP.




Check point 6. Check strainer

- Strainer normally does not have temperature difference between inlet and outlet as shown below.



- If there is a difference like shown below, there is a possibility of inside clogged. In this case, replace the strainer.



5-4. Indoor unit fan motor

Check point 1. Check rotation of fan

Rotate the fan by hand when operation is off.
(Check if fan is caught, dropped off or locked motor)
→ If fan or bearing is abnormal, replace it.


Check point 2. Check resistance of indoor fan motor

Refer to below. Circuit-test “Vm” and “GND” terminal

NOTE: Vm: DC voltage, GND: Earth terminal

→ If they are short-circuited (below 300 kΩ), replace indoor fan motor and controller PCB.

Pin number (wire color)	Terminal function (symbol)
1 (Red)	DC voltage (Vm)
2	No function
3	No function
4 (Black)	Ground terminal (GND)
5 (White)	Control voltage (Vcc)
6 (Yellow)	Speed command (Vsp)
7 (Blue)	Feed back (FG)



5-5. Outdoor unit fan motor

Check point 1. Check rotation of fan

Rotate the fan by hand when operation is off.
(Check if fan is caught, dropped off or locked motor)
→ If fan or bearing is abnormal, replace it.


Check point 2. Check resistance of outdoor fan motor

Refer to below. Circuit-test “Vm” and “GND” terminal

NOTE: Vm: DC voltage, GND: Ground terminal

→ If they are short-circuited (below 300 kΩ), replace outdoor fan motor and controller PCB.

Pin number (wire color)	Terminal function (symbol)
1 (Red)	DC voltage (Vm)
2	No function
3	No function
4 (Black)	Ground terminal (GND)
5 (White)	Control voltage (Vcc)
6 (Yellow)	Speed command (Vsp)
7 (Brown)	Feed back (FG)




5-6. Reactor assy

■ Models: AOUH09KPAS1 and AOUH12KPAS1

Check point 1. Appearance check

No fissures, breaks, damage, etc. at the body and winding section, terminals section?

Check point 2. Electric check



- Set the tester to the "Resistance" mode, and check for open/short between both ends of the reactor wire (or connector).
- Judge the result of 1. as follows:


Short	Normal
Open	Abnormal (open)

NOTE: Reference value of DC resistance of reactor used:
415.9 mΩ (at 77°F [25°C])

5-7. Pressure switch

■ Models: AOUH30KPAS1 and AOUH36KPAS1

- Type of contact



- Characteristics of pressure switch


Pressure switch 1	
Contact: Short → Open	4.2 — 4.05 MPa
Contact: Open → Short	3.2 ± 0.15 MPa

P770

5-8. 4-way valve coil (solenoid coil)/4-way valve

Check point 1. Check connection


- Check the connection of connector P60.




Check Point 2 : Check solenoid coil

Remove P60 from PCB and check the resistance value of coil.

Resistance value $\approx 2.085 \text{ k}\Omega$ (09/12 model), $1.970 \text{ k}\Omega$ (18/24/30/36 model)





→ If it is Open or abnormal resistance value, replace solenoid coil.



Check Point 3: Check the 4-way valve operation

Check each piping temperature, and confirm the location of the valve by the temperature difference



→ If the valve location is not proper, replace the 4-way valve.



Check Point 4: Replace Main PCB

If none of Checks 1 to 3 apply, replace the Main PCB.

6. Thermistor resistance values

6-1. Indoor unit

■ Room temperature thermistor

Temperature °F (°C)	Resistance (kΩ)	Voltage (V)
14.0 (-10.0)	58.25	0.73
23.0 (-5.0)	44.03	0.93
32.0 (0.0)	33.62	1.15
41.0 (5.0)	25.93	1.39
50.0 (10.0)	20.18	1.66
59.0 (15.0)	15.84	1.94
68.0 (20.0)	12.54	2.22
77.0 (25.0)	10.00	2.50
86.0 (30.0)	8.04	2.77
95.0 (35.0)	6.51	3.03
104.0 (40.0)	5.30	3.27
113.0 (45.0)	4.35	3.49

■ Heat exchanger temperature thermistor

Temperature °F (°C)	Resistance (kΩ)	Voltage (V)
-22.0 (-30.0)	1,131.91	0.21
-13.0 (-25.0)	804.52	0.29
-4.0 (-20.0)	579.59	0.40
5.0 (-15.0)	422.89	0.53
14.0 (-10.0)	312.27	0.69
23.0 (-5.0)	233.21	0.88
32.0 (0.0)	176.03	1.10
41.0 (5.0)	134.23	1.36
50.0 (10.0)	103.34	1.63
59.0 (15.0)	80.28	1.92
68.0 (20.0)	62.91	2.21
77.0 (25.0)	49.70	2.51
86.0 (30.0)	39.57	2.79
95.0 (35.0)	31.74	3.06
104.0 (40.0)	25.64	3.30
113.0 (45.0)	20.85	3.53
122.0 (50.0)	17.06	3.73
131.0 (55.0)	14.05	3.90
140.0 (60.0)	11.64	4.05
149.0 (65.0)	9.69	4.19

6-2. Outdoor unit

■ Discharge temperature thermistor

Temperature °F (°C)	Resistance (kΩ)	Voltage (V)
-22.0 (-30.0)	1,013.11	0.06
-12.0 (-25.0)	729.09	0.09
-4.0 (-20.0)	531.56	0.12
5.0 (-15.0)	392.31	0.16
14.0 (-10.0)	292.91	0.21
23.0 (-5.0)	221.09	0.28
32.0 (0.0)	168.60	0.36
41.0 (5.0)	129.84	0.46
50.0 (10.0)	100.91	0.57
59.0 (15.0)	79.12	0.71
68.0 (20.0)	62.55	0.86
77.0 (25.0)	49.84	1.03
86.0 (30.0)	40.01	1.23
95.0 (35.0)	32.35	1.43
104.0 (40.0)	26.34	1.65
113.0 (45.0)	21.58	1.88
122.0 (50.0)	17.79	2.11
131.0 (55.0)	14.75	2.34
140.0 (60.0)	12.30	2.57
149.0 (65.0)	10.32	2.79
158.0 (70.0)	8.69	3.00
167.0 (75.0)	7.36	3.19
176.0 (80.0)	6.27	3.37
185.0 (85.0)	5.36	3.54
194.0 (90.0)	4.60	3.69
203.0 (95.0)	3.96	3.83
212.0 (100.0)	3.43	3.96
221.0 (105.0)	2.98	4.07
230.0 (110.0)	2.60	4.17
239.0 (115.0)	2.27	4.26
248.0 (120.0)	2.00	4.33

■ Compressor temperature thermistor

Temperature °F (°C)	Resistance (kΩ)	Voltage (V)
-22.0 (-30.0)	1,013.11	0.06
-12.0 (-25.0)	729.09	0.09
-4.0 (-20.0)	531.56	0.12
5.0 (-15.0)	392.31	0.16
14.0 (-10.0)	292.91	0.21
23.0 (-5.0)	221.09	0.28
32.0 (0.0)	168.60	0.36
41.0 (5.0)	129.84	0.46
50.0 (10.0)	100.91	0.57
59.0 (15.0)	79.12	0.71
68.0 (20.0)	62.55	0.86
77.0 (25.0)	49.84	1.03
86.0 (30.0)	40.01	1.23
95.0 (35.0)	32.35	1.43
104.0 (40.0)	26.34	1.65
113.0 (45.0)	21.58	1.88
122.0 (50.0)	17.79	2.11
131.0 (55.0)	14.75	2.34
140.0 (60.0)	12.30	2.57
149.0 (65.0)	10.32	2.79
158.0 (70.0)	8.70	3.00
167.0 (75.0)	7.36	3.19
176.0 (80.0)	6.27	3.37
185.0 (85.0)	5.36	3.54
194.0 (90.0)	4.60	3.69
203.0 (95.0)	3.96	3.83
212.0 (100.0)	3.43	3.96
221.0 (105.0)	2.98	4.07
230.0 (110.0)	2.60	4.17
239.0 (115.0)	2.27	4.26
248.0 (120.0)	2.00	4.33

TROUBLESHOOTING

TROUBLESHOOTING

■ Heat exchanger temperature thermistor

Temperature °F (°C)	Resistance (kΩ)	Voltage (V)
-22.0 (-30.0)	95.57	0.24
-12.0 (-25.0)	68.89	0.32
-4.0 (-20.0)	50.31	0.43
5.0 (-15.0)	37.19	0.57
14.0 (-10.0)	27.81	0.73
23.0 (-5.0)	21.02	0.92
32.0 (0.0)	16.05	1.14
41.0 (5.0)	12.38	1.39
50.0 (10.0)	9.63	1.65
59.0 (15.0)	7.56	1.93
68.0 (20.0)	5.98	2.21
77.0 (25.0)	4.77	2.49
86.0 (30.0)	3.84	2.77
95.0 (35.0)	3.11	3.02
104.0 (40.0)	2.53	3.26
113.0 (45.0)	2.08	3.48
122.0 (50.0)	1.71	3.67
131.0 (55.0)	1.42	3.85
140.0 (60.0)	1.19	4.00
149.0 (65.0)	1.00	4.13
158.0 (70.0)	0.84	4.25
167.0 (75.0)	0.71	4.35
176.0 (80.0)	0.61	4.43

■ Heat exchanger (Middle) temperature thermistor

Temperature °F (°C)	Resistance (kΩ)	Voltage (V)
-22.0 (-30.0)	95.57	0.24
-12.0 (-25.0)	68.89	0.32
-4.0 (-20.0)	50.31	0.43
5.0 (-15.0)	37.19	0.57
14.0 (-10.0)	27.81	0.73
23.0 (-5.0)	21.02	0.92
32.0 (0.0)	16.05	1.14
41.0 (5.0)	12.38	1.39
50.0 (10.0)	9.63	1.65
59.0 (15.0)	7.56	1.93
68.0 (20.0)	5.98	2.21
77.0 (25.0)	4.77	2.49
86.0 (30.0)	3.84	2.77
95.0 (35.0)	3.11	3.02
104.0 (40.0)	2.53	3.26
113.0 (45.0)	2.08	3.48
122.0 (50.0)	1.71	3.67
131.0 (55.0)	1.42	3.85
140.0 (60.0)	1.19	4.00
149.0 (65.0)	1.00	4.13
158.0 (70.0)	0.84	4.25
167.0 (75.0)	0.71	4.35
176.0 (80.0)	0.61	4.43

■ Outdoor temperature thermistor

Temperature °F (°C)	Resistance (kΩ)	Voltage (V)
-22.0 (-30.0)	224.33	0.73
-12.0 (-25.0)	159.71	0.97
-4.0 (-20.0)	115.24	1.25
5.0 (-15.0)	84.21	1.56
14.0 (-10.0)	62.28	1.90
23.0 (-5.0)	46.58	2.26
32.0 (0.0)	35.21	2.61
41.0 (5.0)	26.88	2.94
50.0 (10.0)	20.72	3.25
59.0 (15.0)	16.12	3.52
68.0 (20.0)	12.64	3.76
77.0 (25.0)	10.00	3.97
86.0 (30.0)	7.97	4.14
95.0 (35.0)	6.40	4.28
104.0 (40.0)	5.18	4.41
113.0 (45.0)	4.21	4.51
122.0 (50.0)	3.45	4.59
131.0 (55.0)	2.85	4.65

■ Heat sink thermistor

Temperature °F (°C)	Resistance (kΩ)	Voltage (V)
-22.0 (-30.0)	94.26	0.08
-12.0 (-25.0)	67.95	0.11
-4.0 (-20.0)	49.62	0.15
5.0 (-15.0)	36.68	0.20
14.0 (-10.0)	27.42	0.26
23.0 (-5.0)	20.73	0.34
32.0 (0.0)	15.83	0.43
41.0 (5.0)	12.21	0.55
50.0 (10.0)	9.50	0.68
59.0 (15.0)	7.46	0.84
68.0 (20.0)	5.90	1.01
77.0 (25.0)	4.71	1.21
86.0 (30.0)	3.78	1.42
95.0 (35.0)	3.06	1.64
104.0 (40.0)	2.50	1.88
113.0 (45.0)	2.05	2.11
122.0 (50.0)	1.69	2.35
131.0 (55.0)	1.40	2.58
140.0 (60.0)	1.17	2.81
149.0 (65.0)	0.99	3.02
158.0 (70.0)	0.83	3.22
167.0 (75.0)	0.70	3.41
176.0 (80.0)	0.60	3.58

4. CONTROL AND FUNCTIONS

CONTENTS

4. CONTROL AND FUNCTIONS

1. Rotation number control of compressor.....	04-1
1-1. Cooling operation	04-1
1-2. Heating operation	04-4
1-3. Dry operation	04-5
1-4. Rotation number of compressor at normal start-up	04-6
1-5. Limitation of compressor rotation number by outdoor temperature.....	04-8
2. Auto changeover operation.....	04-14
3. Fan control.....	04-16
3-1. Indoor fan control.....	04-16
3-2. Outdoor fan control	04-20
4. Louver control	04-25
4-1. Horizontal louver control	04-25
4-2. Vertical louver control	04-26
4-3. Adjust the horizontal louver	04-27
4-4. Swing operation.....	04-27
5. Timer operation control.....	04-28
5-1. Wireless remote control	04-28
5-2. Wired remote control	04-30
6. Defrost operation control	04-33
6-1. Defrost operation in heating operation stopped	04-35
7. Various control	04-36
7-1. Auto restart.....	04-36
7-2. MANUAL AUTO operation.....	04-36
7-3. Forced cooling operation	04-37
7-4. MIN. HEAT operation	04-37
7-5. ECONOMY operation	04-37
7-6. POWERFUL operation	04-38
7-7. Fresh air control.....	04-38
7-8. Compressor preheating operation	04-38
7-9. External electrical heater control	04-40
7-10. Electronic expansion valve control	04-40
7-11. Prevention to restart for 3 minutes (3 minutes st)	04-41
7-12. 4-way valve control	04-41
7-13. Peak cut operation (for 30/36 model)	04-41
7-14. Unit status monitoring and the detected value indication	04-42
8. Various protections.....	04-44
8-1. Discharge gas temperature over-rise prevention control	04-44
8-2. Anti-freezing control (cooling and dry mode)	04-44
8-3. Current release control	04-45
8-4. Cooling pressure over-rise protection (for 09/12/18/24 model).....	04-46

CONTENTS (continued)

8-5. Compressor temperature protection (for 18/24/30/36 model).....	04-47
8-6. High pressure protection (for 30/36 model)	04-47
8-7. Low outdoor temperature protection (for 09/12 model).....	04-47
8-8. High temperature and high pressure release control	04-48

1. Rotation number control of compressor

1-1. Cooling operation

A sensor (room temperature thermistor) built in the indoor unit body will usually perceive difference or variation between a set temperature and present room temperature, and controls the operation rotation number of the compressor.


- If the room temperature is 11°F (6.0°C) higher than a set temperature, the operation rotation number of compressor will attain to maximum performance.
- If the room temperature is 2°F (1.0°C) lower than a set temperature, the compressor will be stopped.
- When the room temperature is within the range of +11°F (6.0°C) to -2°F (1.0°C) of the setting temperature, the rotation number of compressor is controlled within the range shown in the table below. However, the maximum rotation number is limited in the range shown in the figure below based on the indoor fan mode and the outdoor temperature.

• Rotation number range of compressor

Unit: rps

Model name	Minimum rotation number	Maximum rotation number
ASUH09KPAS	14	90
ASUH12KPAS	14	103
ASUH18KPAS	10	74
ASUH24KPAS	10	111
ASUH30KPAS	15	85
ASUH36KPAS	15	98

• Limit of maximum speed based on outdoor temperature



Unit: rps

CONTROL AND
FUNCTIONS

CONTROL AND
FUNCTIONS

Model name	Outdoor temperature zone	Indoor unit fan mode					
		HIGH	MED—HIGH	MED	MED—LOW	LOW	QUIET
ASUH09KPAS	A zone	90	78	73	60	52	30
	B zone	90	78	73	60	52	30
	C zone	90	78	73	60	52	30
	D zone	68	64	60	56	52	30
	E zone	68	64	60	56	52	30
	F zone	68	64	60	56	52	30
ASUH12KPAS	A zone	103	68	64	52	46	28
	B zone	103	68	64	52	46	28
	C zone	103	68	64	52	46	28
	D zone	68	64	60	49	46	28
	E zone	68	64	60	49	46	28
	F zone	68	64	60	49	46	28
ASUH18KPAS	A zone	74	54	50	42	39	26
	B zone	74	54	50	42	39	26
	C zone	74	54	50	42	39	26
	D zone	54	46	46	39	36	20
	E zone	54	46	46	39	36	20
	F zone	54	46	46	39	36	20
ASUH24KPAS	A zone	111	74	50	42	39	30
	B zone	111	74	50	42	39	30
	C zone	111	74	50	42	39	30
	D zone	58	54	46	39	36	24
	E zone	58	54	46	39	36	24
	F zone	58	54	46	39	36	24
ASUH30KPAS	A zone	85	75	70	57	53	39
	B zone	85	75	70	57	53	39
	C zone	85	75	70	57	53	39
	D zone	70	61	57	53	53	33
	E zone	70	61	57	53	53	33
	F zone	70	61	57	53	53	33
ASUH36KPAS	A zone	98	75	70	57	53	39
	B zone	98	75	70	57	53	39
	C zone	98	75	70	57	53	39
	D zone	70	61	57	53	53	33
	E zone	70	61	57	53	53	33
	F zone	70	61	57	53	53	33

1-2. Heating operation

A sensor (room temperature thermistor) built in indoor unit body will usually perceive difference or variation between setting temperature and present room temperature, and controls operation rotation number of compressor.

- If the room temperature is 11°F (6.0°C) lower than a set temperature, the operation rotation number of compressor will attain to maximum performance.
- If the room temperature is 2°F (1.0°C) higher than a set temperature, the compressor will be stopped.
- When the room temperature is within the range of +2°F (1.0°C) to -11°F (6.0°C) of the setting temperature, the rotation number of compressor is controlled within the range shown below.

- **Rotation number range of compressor**

Unit: rps

Model name	Minimum rotation number	Maximum rotation number
ASUH09KPAS ASUH12KPAS	14	110
ASUH18KPAS ASUH24KPAS	10	130
ASUH30KPAS ASUH36KPAS	15	120

1-3. Dry operation

The rotation number of compressor shall change according to the temperature, set temperature, and room temperature variation which the room temperature sensor of the indoor unit has detected as shown in the table below.


Zone is defined by set temperature and room temperature.

- **Rotation number range of compressor**

Unit: rps

Model name	Outdoor temperature zone	Operating rotation number
ASUH09KPAS	X zone	30
	J zone	18
	Y zone	0
ASUH12KPAS	X zone	28
	J zone	18
	Y zone	0
ASUH18KPAS	X zone	26
	J zone	16
	Y zone	0
ASUH24KPAS	X zone	30
	J zone	18
	Y zone	0
ASUH30KPAS ASUH36KPAS	X zone	39
	J zone	17
	Y zone	0


- **Compressor control based on room temperature**



1-4. Rotation number of compressor at normal start-up

■ Models: AOUH09KPAS1 and AOUH12KPAS1

Rotation number of compressor soon after starting is controlled as below.




Rotation number (rps)	I	II	III	IV	V	VI	VII
	45*	56	68	77	84	93	103
Time (sec)	1	2	3	4	5	6	7
	60	140	170	220	280	360	430

*: Cooling operation: 32 (09 model) or 28 (12 model)

■ Models: AOUH18KPAS1 and AOUH24KPAS1


Rotation number of compressor soon after starting is controlled as below.



Rotation number (rps)	I	II	III	IV	V	VI
	35	52	64	71	89	97
Time (sec)	1	2	3	4	5	6
	60	140	170	200	350	410

■ Models: AOUH30KPAS1 and AOUH36KPAS1

Rotation number of compressor soon after starting is controlled as below.



• Normal operation

Rotation number (rps)	I	II	III	IV	V	VI	VII	VIII
	25	42	53	61	65	75	85	92
Time (sec)	1	2	3	4	5	6	7	8
	90	150	270	330	390	450	570	630

• Special operation

Rotation number (rps)	I	II	III	IV	V	VI	VII	VIII
	25	42	53	61	65	75	85	92
Time (sec)	1	2	3	4	5	6	7	8
	225	305	605	665	725	785	855	1,000

NOTES:

- Normal operation:
 - Cooling and dry mode
 - Below 3 hours from the compressor stop and the compressor thermistor $\geq 59^{\circ}\text{F}$ (15°C)
 - After defrost operation
 - Other than when the compressor starts for the first time since the breaker turns on
- Special operation:
 - Other than the normal operation condition
 - When the compressor starts for the first time since the breaker turns on

1-5. Limitation of compressor rotation number by outdoor temperature

■ Models: AOUH09KPAS1 and AOUH12KPAS1

The minimum rotation number of compressor is limited by outdoor temperature as below.

- **Cooling/Dry mode**

100.4°F (38°C)	F zone
66.2°F (19°C)	E zone
50.0°F (10°C)	D zone
32.0°F (0°C)	C zone
14.0°F (-10°C)	B zone
	A zone

Unit: rps

Model name	Outdoor temperature zone	Limitation of compressor rotation number
AOUH09KPAS1	A zone	42
	B zone	42
	C zone	33
	D zone	28
	E zone	16
	F zone	21
AOUH12KPAS1	A zone	42
	B zone	42
	C zone	40
	D zone	40
	E zone	16
	F zone	24

• Heating mode

66.2°F (19°C)	F zone
41.0°F (5°C)	E zone
32.0°F (0°C)	D zone
5.0°F (-15°C)	C zone
-13.0°F (-25°C)	B zone
	A zone

Unit: rps

Model name	Outdoor temperature zone	Limitation of compressor rotation number
AOUH09KPAS1 AOUH12KPAS1	A zone	43
	B zone	43
	C zone	30
	D zone	18
	E zone	16
	F zone	16

■ Models: AOUE18KPAS1 and AOUE24KPAS1

The minimum rotation number of compressor is limited by outdoor temperature as below.

- **Cooling/Dry mode**

100.4°F (38°C)	G zone
66.2°F (19°C)	F zone
50.0°F (10°C)	E zone
32.0°F (0°C)	D zone
14.0°F (-10°C)	C zone
5.0°F (-15°C)	B zone
	A zone

Unit: rps

Model name	Outdoor temperature zone	Limitation of compressor rotation number
AOUE18KPAS1	A zone	44
	B zone	24
	C zone	24
	D zone	24
	E zone	24
	F zone	1
	G zone	30
AOUE24KPAS1	A zone	54
	B zone	24
	C zone	24
	D zone	24
	E zone	24
	F zone	1
	G zone	30

• Heating mode

66.2°F (19°C)	F zone
41.0°F (5°C)	E zone
32.0°F (0°C)	D zone
5.0°F (-15°C)	C zone
-13.0°F (-25°C)	B zone
	A zone

Unit: rps

Model name	Outdoor temperature zone	Limitation of compressor rotation number
AOUH18KPAS1 AOUH24KPAS1	A zone	140
	B zone	140
	C zone	140
	D zone	140
	E zone	140
	F zone	140

CONTROL AND
FUNCTIONS

CONTROL AND
FUNCTIONS

■ Models: AOUH30KPAS1 and AOUH36KPAS1

The minimum rotation number of compressor is limited by outdoor temperature as below.

- **Cooling/Dry mode**

125.6°F (52°C)	J zone
122.0°F (50°C)	I zone
87.8°F (31°C)	H zone
69.8°F (21°C)	G zone
55.4°F (13°C)	F zone
44.6°F (7°C)	E zone
35.6°F (2°C)	D zone
23.0°F (-5°C)	C zone
14.0°F (-10°C)	B zone
	A zone

Unit: rps

Model name	Outdoor temperature zone	Limitation of compressor rotation number
AOUH30KPAS1 AOUH36KPAS1	A zone	55
	B zone	52
	C zone	47
	D zone	39
	E zone	33
	F zone	25
	G zone	18
	H zone	20
	I zone	21
	J zone	24

- Heating mode

60.8°F (16°C)	H zone
53.6°F (12°C)	G zone
44.6°F (7°C)	F zone
35.6°F (2°C)	E zone
19.4°F (-7°C)	D zone
14.0°F (-10°C)	C zone
5.0°F (-15°C)	B zone
	A zone

Unit: rps

Model name	Outdoor temperature zone	Limitation of compressor rotation number
AOUH30KPAS1 AOUH36KPAS1	A zone	58
	B zone	52
	C zone	43
	D zone	38
	E zone	28
	F zone	22
	G zone	19
	H zone	17

2. Auto changeover operation

When the air conditioner is set to AUTO mode by remote controller, operation starts in the optimum mode from among heating, cooling, dry and monitoring modes. During operation, the optimum mode is automatically switched in accordance with temperature changes. The temperature can be set between 64.4°F (18°C) and 86.0°F (30°C) in 1.8°F (1.0°C) steps.

- When operation starts, indoor fan and outdoor fan are operated for around 1 minute. Room temperature and outdoor temperature are sensed, and the operation mode is selected in accordance with the table below.

Room temperature	Operation mode
$T_r > T_s + 3.6^{\circ}\text{F}$ (2°C)	Cooling
$T_s + 3.6^{\circ}\text{F}$ (2°C) $\geq T_r \geq T_s - 3.6^{\circ}\text{F}$ (2°C)	Middle zone
$T_r < T_s - 3.6^{\circ}\text{F}$ (2°C)	Heating

Tr: Room temperature

Ts: Setting temperature


NOTE: When the operation mode is middle zone, indoor unit operation mode is selected as below.

- Same operation mode is selected as outdoor unit.
If outdoor unit is operating in cooling and heating mode, indoor unit will be operated by the same operation mode.
- Selected by outdoor temperature.
If outdoor unit is operating in other than cooling and heating mode, indoor unit will be operated according to the outdoor temperature as below.

Outdoor temp.	Operation mode
77.0°F (25°C) or more	Cooling
Less than 77.0°F (25°C)	Heating

- When the compressor was stopped for 6 consecutive minutes by temperature control function after the cooling or heating mode was selected as above, operation is switched to monitoring mode and the operation mode selection is done again.
- When the middle zone is selected on the predetermining of the operation mode, the operation mode before the changing to the monitoring mode is selected.

Operation flow chart



3. Fan control

Tr: Room temperature

Ts: Setting temperature

3-1. Indoor fan control

■ Fan speed

Indoor fan speed is defined as below.

Operation mode	Fan mode	Speed (rpm)				
		09	12	18	24	30/36
Heating	POWERFUL	1,270	1,270	1,340	1,480	1,450
	HIGH	1,180	1,200	1,180	1,360	1,230
	MED—HIGH	1,040	1,100	1,100	1,270	1,130
	MED	970	1,030	1,030	1,180	1,040
	MED—LOW	890	950	950	1,050	940
	LOW	810	880	870	930	850
	QUIET	630	630	740	820	750
	Cool air prevention	550	550	650	650	590
Cooling/Fan	S-LOW	400	400	520	520	450
	POWERFUL	1,200	1,270	1,380	1,590	1,520
	HIGH	1,110	1,180	1,230	1,520	1,330
	MED—HIGH	1,030	1,030	1,180	1,320	1,210
	MED	920	920	1,130	1,130	1,100
	MED—LOW	840	840	1,030	1,030	1,000
	LOW	760	760	930	930	900
	QUIET	550	550	700	800	750
	Soft quiet	470*1	470*1	650*1	650*1	590*1
Dry	S-LOW	400*2	400*2	520*2	520*2	450*2
		X zone: 550 J zone: 550	X zone: 550 J zone: 550	X zone: 700 J zone: 610	X zone: 800 J zone: 800	X zone: 750 J zone: 750

*1: Fan mode only

*2: Cooling mode only

■ Fan operation


Airflow can be switched in 7 steps such as AUTO, QUIET, LOW, MED—LOW, MED, MED—HIGH, HIGH while indoor unit fan only runs.

When fan mode is set at AUTO, it operates on MED fan speed.

Cooling operation

Switch the airflow AUTO, and indoor fan motor will run according to room temperature, as below.
On the other hand, if switched in HIGH—QUIET, indoor motor will run at a constant airflow of COOL operation modes QUIET, LOW, MED, HIGH as shown in “Fan speed” above.

Airflow change over (Cooling: Auto)



Dry operation


During dry operation, fan speed setting can not be changed as shown in “Fan speed” above.

Heating operation

Switch the airflow AUTO, and the indoor fan motor will run according to a room temperature, as below.

On the other hand, if switched in HIGH—QUIET, the indoor motor will run at a constant airflow of HEAT operation modes QUIET, LOW, MED, HIGH as shown in “Fan speed” above.


Airflow change over (Heating: Auto)



■ Cool air prevention control (heating mode)


The maximum value of the indoor fan speed is set as shown below, based on the detected temperature by the indoor heat exchanger sensor on heating mode.

• Normal operation



*: Lower speed is selected.

7 minutes later:




*: Lower speed is selected.


CONTROL AND
FUNCTIONS

CONTROL AND
FUNCTIONS


- **Powerful operation**



7 minutes later:




- **MIN. HEAT operation**



■ Moisture return prevention control (cooling and dry mode)

Switch the airflow AUTO at cooling mode, and the indoor fan motor will run as shown below.



3-2. Outdoor fan control

■ Outdoor fan motor


This outdoor unit has a DC fan motor. (Control method is different between AC and DC motors.)

■ Fan speed

● Model: AOUH09KPAS1

Fan speed is defined by outdoor temperature and rotation number of compressor.

• Outside air temperature zone selection



Unit: rpm

Fan step	Cooling	Heating	Dry	Cooling or dry at low outdoor temp.			
	Y zone		Y zone	Z zone	F zone	G zone	H zone
S-HIGH2	—	930	—	—	—	—	—
S-HIGH1	950	930	—	—	—	—	—
HIGH	950	930	—	—	—	—	—
10	—	800	—	—	—	—	—
9	950	800	950	280	250	190	190
8	780	800	780	280	250	190	190
7	780	800	780	280	250	190	190
6	780	800	780	280	250	190	190
5	780	690	780	250	230	170	170
4	730	620	730	220	210	170	170
3	680	550	680	220	210	170	170
2	610	480	610	220	210	170	170
1	580	480	580	220	210	170	170


NOTE: After defrost control on the heating mode, the fan speed is kept higher regardless of the compressor frequency.

Fan speed after defrost control: 930 rpm

● Model: AOUH12KPAS1

Fan speed is defined by outdoor temperature and rotation number of compressor.

• Outside air temperature zone selection



Unit: rpm

Fan step	Cooling	Heating	Dry	Cooling or dry at low outdoor temp.			
	Y zone		Y zone	Z zone	F zone	G zone	H zone
S-HIGH2	—	1,020	—	—	—	—	—
S-HIGH1	950	1,020	—	—	—	—	—
HIGH	950	1,020	—	—	—	—	—
10	—	920	—	—	—	—	—
9	950	920	950	950	290	270	270
8	900	920	900	840	290	270	270
7	900	920	900	560	290	270	270
6	900	780	900	350	290	270	270
5	850	730	850	350	260	230	230
4	800	670	800	350	260	200	200
3	680	570	680	350	260	200	200
2	580	470	580	350	260	200	200
1	540	470	540	350	250	200	200


NOTE: After defrost control on the heating mode, the fan speed is kept higher regardless of the compressor frequency.

Fan speed after defrost control: 1,020 rpm

● Model: AOUH18KPAS1

Fan speed is defined by outdoor temperature and rotation number of compressor.

• Outside air temperature zone selection



Unit: rpm

Fan step	Cooling	Heating	Dry	Cooling or dry at low outdoor temp.				
	Y zone		Y zone	Z zone	F zone	G zone	H zone	I zone
S-HIGH2	—	1,140	—	—	—	—	—	—
S-HIGH1	1,050	1,140	—	—	—	—	—	—
HIGH	1,050	1,100	—	—	—	—	—	—
10	—	1,100	—	—	—	—	—	—
9	920	1,100	920	630	320	270	270	210
8	840	920	840	630	260	250	250	210
7	750	920	750	350	260	230	230	210
6	690	710	690	320	230	210	210	200
5	560	620	560	320	200	170	170	170
4	440	560	440	320	200	170	170	170
3	440	420	440	320	200	170	170	170
2	440	420	440	320	200	170	170	170
1	440	420	440	320	200	170	170	170


NOTE: After defrost control on the heating mode, the fan speed is kept higher regardless of the compressor frequency.

Fan speed after defrost control: 1,140 rpm

● Model: AOUH24KPAS1

Fan speed is defined by outdoor temperature and rotation number of compressor.

• Outside air temperature zone selection



Unit: rpm

Fan step	Cooling	Heating	Dry	Cooling or dry at low outdoor temp.				
	Y zone		Y zone	Z zone	F zone	G zone	H zone	I zone
S-HIGH2	—	1,140	—	—	—	—	—	—
S-HIGH1	1,150	1,140	—	—	—	—	—	—
HIGH	1,150	1,100	—	—	—	—	—	—
10	—	1,100	—	—	—	—	—	—
9	1,150	1,100	1,150	850	320	270	270	230
8	1,150	1,050	1,150	850	320	270	270	230
7	1,050	920	1,100	770	280	270	270	230
6	990	710	990	630	230	210	210	210
5	840	620	850	440	200	170	170	170
4	680	560	700	320	200	170	170	170
3	560	420	550	320	200	170	170	170
2	440	420	400	320	200	170	170	170
1	440	420	400	320	200	170	170	170

NOTE: After defrost control on the heating mode, the fan speed is kept higher regardless of the compressor frequency.

Fan speed after defrost control: 1,140 rpm

● Models: AOUH30KPAS1 and AOUH36KPAS1

Fan speed is defined by outdoor temperature and rotation number of compressor.

Unit: rpm

Fan step	Cooling or dry	Heating
13	830	—
12	830	—
11	740	—
10	700	830
9	650	740
8	570	690
7	570	620
6	570	590
5	570	480
4	540	410
3	480	340
2	400	270
1	270	200
S-HIGH	—	830

- When the rotation number of compressor increases, the outdoor fan speed also changes to the higher speed.
- When the rotation number of compressor decreases, the outdoor fan speed also changes to the lower speed.

NOTE: After defrost control on the heating mode, the fan speed is kept higher regardless of the rotation number of compressor.


Fan speed after defrost control: 830 rpm

4. Louver control

4-1. Horizontal louver control

■ Models: ASUH09KPAS, ASUH12KPAS, ASUH18KPAS, and ASUH24KPAS

Each time the button is pressed, the air direction range will change as below:



- Remote controller display is not changed.
- Vertical airflow direction is set automatically as shown, in accordance with the type of operation selected.


Cooling / Dry mode : Horizontal flow 1

Heating mode : Downward flow 6

- During AUTO operation, for the first a few minutes after beginning operation, airflow will be horizontal 1; the air direction cannot be adjusted during this period. The airflow direction setting will temporarily become 1 when the temperature of the airflow is low at the start of the Heating mode.
- After beginning of AUTO/HEAT mode operated and automatic defrosting operation, the airflow will be horizontal 1. However, the airflow direction cannot be adjusted at beginning AUTO operation mode.

■ Models: ASUH30KPAS and ASUH36KPAS

Each time the button is pressed, the air direction range will change as below:



- Remote controller display is not changed.
- Vertical airflow direction is set automatically as shown, in accordance with the type of operation selected.

Cooling / Dry mode : Horizontal flow 1


Heating mode : Downward flow 5

- During AUTO operation, for the first a few minutes after beginning operation, airflow will be horizontal 1; the air direction cannot be adjusted during this period. The airflow direction setting will temporarily become 1 when the temperature of the airflow is low at the start of the Heating mode.
- After beginning of AUTO/HEAT mode operated and automatic defrosting operation, the airflow will be horizontal 1. However, the airflow direction cannot be adjusted at beginning AUTO operation mode.

4-2. Vertical louver control

■ Models: ASUH18KPAS, ASUH24KPAS, ASUH30KPAS, and ASUH36KPAS

Each time the button is pressed, the air direction range will change as below:




Remote controller display is not changed.

4-3. Adjust the horizontal louver

■ Models: ASUH09KPAS and ASUH12KPAS

Move the horizontal louvers to adjust airflow direction you prefer.



4-4. Swing operation

- To select up/down airflow swing operation
When the swing signal is received, the horizontal louver starts to swing.
 - Swinging range
 - Cooling mode/dry mode/fan mode (1 to 3): 1 ↔ 4
 - Heating mode/fan mode (4 to 6): 3 ↔ 6
 - When the indoor fan is S-LOW or stop mode, the swing operation is interrupted and it stops at either upper end or bottom end.
- To select left/right airflow swing operation
When the swing signal is received, the vertical louver starts to swing.
 - Swinging range
 - All mode: 1 ↔ 5
 - When the indoor fan is S-LOW or stop mode, the swing operation is interrupted and it stops at either left end or right end.
- To select up/down and left/right airflow swing operation
When the swing signal is received, both of the vertical and the horizontal louvers start to swing.


5. Timer operation control

5-1. Wireless remote control


On/Off timer	Program timer	Sleep timer	Weekly timer
○	○	○	—

■ On/Off timer

- Off timer: When the clock reaches the set timer, the air conditioner will be turned off.




- On timer: When the clock reaches the set timer, the air conditioner will be turned on.



■ Program timer

- The program timer allows the off timer and the on timer to be used in combination one time.




- Operation will start from the timer setting (either off timer and on timer) whichever is closest to the clock current timer setting. The order of operations is indicated by the allow in the remote controller screen.
- Sleep timer operation cannot be combined with on timer operation.

■ Sleep timer

If the sleep timer is set, the room temperature is monitored and the operation is stopped automatically. If the operation mode or the set temperature is change after the sleep timer is set, the operation is continued according to the changed setting of the sleep timer from that time on.


- In the cooling operation mode

When the sleep timer is set, the setting temperature is increased 1.8°F (1°C). It increases the setting temperature another 1.8°F (1°C) after 1 hour. After that, the setting temperature is not changed and the operation is stopped at the setting time.



- In the heating operation mode

When the sleep timer is set, the setting temperature is decreased 1.8°F (1°C). It decreases the setting temperature another 1.8°F (1°C) every 30 minutes. Upon lowering 7.2°F (4°C), the setting temperature is not changed and the operation is stopped at the setting time.




5-2. Wired remote control


On/Off timer	Program timer	Sleep timer	Weekly timer	Temperature Setback Timer
○	○	○	○	○

■ On/Off timer

- Off timer: When the clock reaches the set timer, the air conditioner will be turned off.




- On timer: When the clock reaches the set timer, the air conditioner will be turned on.



■ Program timer

- The program timer allows the off timer and the on timer to be used in combination one time.




- Operation will start from the timer setting (either off timer and on timer) whichever is closest to the clock current timer setting. The order of operations is indicated by the allow in the remote controller screen.
- Sleep timer operation cannot be combined with on timer operation.

■ Sleep timer

If the sleep timer is set, the room temperature is monitored and the operation is stopped automatically. If the operation mode or the set temperature is change after the sleep timer is set, the operation is continued according to the changed setting of the sleep timer from that time on.


- In the cooling operation mode

When the sleep timer is set, the setting temperature is increased 1.8°F (1°C). It increases the setting temperature another 1.8°F (1°C) after 1 hour. After that, the setting temperature is not changed and the operation is stopped at the setting time.



- In the heating operation mode

When the sleep timer is set, the setting temperature is decreased 1.8°F (1°C). It decreases the setting temperature another 1.8°F (1°C) every 30 minutes. Upon lowering 7.2°F (4°C), the setting temperature is not changed and the operation is stopped at the setting time.




■ Weekly timer

On and off timer can be combined, and up to 4 reservations per day and 28 reservations per week. Before setting the program, set the week and time of the air conditioner at first. If the week and time are not set, the weekly timer will not operate correctly at the setting time.

■ Temperature Setback Timer

- The temperature setback timer only changes the set temperature for 7 days, it cannot be used to start or stop air conditioner operation.
- The temperature setback timer can be set to operate up to two times per day but only one temperature setting can be used.
- During COOLING/DRY mode, the air conditioner will operate at a minimum of 64°F (18°C) even if the SET BACK temperature is set to 63°F (17°C) or lower.

Case of Temperature Setback Timer on the Cooling operation. (Setting temperature :72°F [22°C], SET BACK temperature :78°F [26°C])



CONTROL AND
FUNCTIONS

CONTROL AND
FUNCTIONS

6. Defrost operation control

Tn: Outdoor unit heat exchanger temperature

Ta: Outdoor temperature

Tn10: Temperature at 10 minutes after compressor start

Tnb: Temperature before 5 minutes

• Triggering condition

The defrost operation starts when outdoor unit heat exchanger temperature sensor detects the temperature lower than the values shown below.

– 1st time defrosting after starting operation

Compressor integrating operation time	Less than 17 min.	17 to 57 min.	More than 57 min.
Condition	Does not operate	$T_n \leq 15.8^{\circ}\text{F} (-9^{\circ}\text{C})$ and $T_n - T_a \geq 9.0^{\circ}\text{F} (5^{\circ}\text{C})$	$T_n \leq 23.0^{\circ}\text{F} (-5^{\circ}\text{C})$

– 2nd time and after

• Models: AOUH09KPAS1 and AOUH12KPAS1

Compressor integrating operation time	Less than 25 min.	More than 25 min.
Condition	Does not operate	$T_n - T_{n10} < -9.0^{\circ}\text{F} (-5^{\circ}\text{C})$ ($T_n \leq 21.2^{\circ}\text{F} [-6^{\circ}\text{C}]$) $T_n - T_{nb} < -3.6^{\circ}\text{F} (-2^{\circ}\text{C})$ ($T_n \leq 21.2^{\circ}\text{F} [-6^{\circ}\text{C}]$) $T_n \leq 1.4^{\circ}\text{F} (-17^{\circ}\text{C})$ ($T_a \geq 14.0^{\circ}\text{F} [-10^{\circ}\text{C}]$) $T_n \leq 19.4^{\circ}\text{F} (-7^{\circ}\text{C})$ or $T_n \leq -4.0^{\circ}\text{F} (-20^{\circ}\text{C})$ ($T_a < 14.0^{\circ}\text{F} [-10^{\circ}\text{C}]$)

• Models: AOUH18KPAS1 and AOUH24KPAS1

Compressor integrating operation time	Less than 30 min.	More than 30 min.
Condition	Does not operate	$T_n - T_{n10} < -9.0^{\circ}\text{F} (-5^{\circ}\text{C})$ ($T_n \leq 21.2^{\circ}\text{F} [-6^{\circ}\text{C}]$) $T_n - T_{nb} < -3.6^{\circ}\text{F} (-2^{\circ}\text{C})$ ($T_n \leq 21.2^{\circ}\text{F} [-6^{\circ}\text{C}]$) $T_n \leq 1.4^{\circ}\text{F} (-17^{\circ}\text{C})$ ($T_a \geq 14.0^{\circ}\text{F} [-10^{\circ}\text{C}]$) $T_n \leq 19.4^{\circ}\text{F} (-7^{\circ}\text{C})$ or $T_n \leq -4.0^{\circ}\text{F} (-20^{\circ}\text{C})$ ($T_a < 14.0^{\circ}\text{F} [-10^{\circ}\text{C}]$)

• Models: AOUH30KPAS1 and AOUH36KPAS1

Compressor integrating operation time	Less than 35 min.	More than 35 min.
Condition	Does not operate	$T_n - T_{n10} < -9.0^{\circ}\text{F} (-5^{\circ}\text{C})$ ($T_n \leq 14.0^{\circ}\text{F} [-10^{\circ}\text{C}]$) $T_n - T_{nb} < -3.6^{\circ}\text{F} (-2^{\circ}\text{C})$ ($T_n \leq 14.0^{\circ}\text{F} [-10^{\circ}\text{C}]$) $T_n \leq -13.0^{\circ}\text{F} (-25^{\circ}\text{C})$ ($T_a \geq -4.0^{\circ}\text{F} [-20^{\circ}\text{C}]$) $T_n \leq 19.4^{\circ}\text{F} (-7^{\circ}\text{C})$ or $T_n \leq -13.0^{\circ}\text{F} (-25^{\circ}\text{C})$ ($T_a < -4.0^{\circ}\text{F} [-20^{\circ}\text{C}]$)

– Integrating defrost (Constant monitoring)

Compressor integrating operation time	More than 240 min. (For long continuous operation)	More than 215 min. (For long continuous operation)	Less than 10 min.* (For intermittent operation)
Condition	$T_n \leq 26.6^{\circ}\text{F} (-3^{\circ}\text{C})$	$T_n \leq 23.0^{\circ}\text{F} (-5^{\circ}\text{C})$	Count of the compressor off: 40 times

*: If the compressor continuous operation time is less than 10 minutes, the number of the compressor off is counted. If any defrost operated, the compressor off count is cleared.

• Release condition

– Models: AOUH09KPAS1 and AOUH12KPAS1

The defrost operation is released when either one of the conditions below is satisfied.

Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start)	60.8°F (16°C) or more
Compressor operation time	15 minutes

– Models: AOUH18KPAS1 and AOUH24KPAS1

Depending on the triggering condition, different release conditions apply.

• Normal defrost operation

The defrost operation is released when either one of the conditions below is satisfied.

Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start)	60.8°F (16°C) or more ($T_a \leq 33.8^{\circ}\text{F} [1^{\circ}\text{C}]$) 50.0°F (10°C) or more ($T_a > 33.8^{\circ}\text{F} [1^{\circ}\text{C}]$)
Compressor operation time	15 minutes

• Integrating defrost (constant monitoring)

The defrost operation is released when either one of the conditions below is satisfied.

Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start)	60.8°F (16°C) or more
Compressor operation time	15 minutes

– Models: AOUH30KPAS1 and AOUH36KPAS1

The defrost operation is released when either one of the conditions below is satisfied.

Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start)	53.6°F (12°C) or more
Compressor operation time	15 minutes

6-1. Defrost operation in heating operation stopped

If the outdoor unit is frosted when stopping the heating operation, it stops after performing the automatic defrosting operation.

In this time, if the indoor unit operation lamp flashes slowly (6 sec on/2 sec off), the outdoor unit allow the heat exchanger to defrost, and then stop.

• Triggering condition

When all of the following conditions are satisfied in heating operation

- Compressor operation integrating time: 30 minutes or more
- Compressor continuous operation time: 10 minutes or more
- Outdoor unit heat exchanger temperature: 24.8°F (-4°C) or less

• Release condition

– Models: AOUH09KPAS1 and AOUH12KPAS1

The defrost operation is released when either one of the conditions below is satisfied.

Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start)	60.8°F (16°C) or more
Compressor operation time	15 minutes

– Models: AOUH18KPAS1 and AOUH24KPAS1

Depending on the triggering condition, different release conditions apply.

• Normal defrost operation

The defrost operation is released when either one of the conditions below is satisfied.

Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start)	60.8°F (16°C) or more ($T_a \leq 33.8^\circ\text{F}$ [1°C]) 50.0°F (10°C) or more ($T_a > 33.8^\circ\text{F}$ [1°C])
Compressor operation time	15 minutes

• Integrating defrost (constant monitoring)

The defrost operation is released when either one of the conditions below is satisfied.

Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start)	60.8°F (16°C) or more
Compressor operation time	15 minutes

– Models: AOUH30KPAS1 and AOUH36KPAS1

The defrost operation is released when either one of the conditions below is satisfied.

Outdoor unit heat exchanger temperature (after 1 minute or later since compressor start)	53.6°F (12°C) or more
Compressor operation time	15 minutes

7. Various control

7-1. Auto restart

When the power was interrupted by a power failure etc. during operation, the operation contents at that time are memorized and when the power is recovered, operation is automatically started with the memorized operation contents.

Operation contents memorized when the power is interrupted	
Operation mode	
Setting temperature	
Fan mode setting	
Timer mode and set time (set by wireless remote controller)	
Airflow direction setting	
Swing	
ECONOMY operation	
MIN. HEAT operation	
Remote control setting	
WLAN indicator lamp setting	

7-2. MANUAL AUTO operation

When the wireless remote controller is lost or battery power dissipated, this function will work without the remote controller.

When MANUAL AUTO button is pressed more than 3 seconds and less than 10 seconds, MANUAL AUTO operation starts as shown in the table below. To stop operation, press the MANUAL AUTO button for 3 seconds.

Operation mode	Auto changeover
Fan mode	AUTO
Timer mode	Continuous (no timer setting available)
Setting temperature	75.2°F (24°C)
Horizontal louver setting	Standard
Vertical louver setting	According to memory position
SWING	Off
ECONOMY	Off

7-3. Forced cooling operation

The outdoor unit may not operate depending on the room temperature.

When FORCED COOLING OPERATION button is pressed more than 10 seconds, forced cooling operation starts as shown in the table below.

Operation mode	Cooling
Fan mode	HIGH
Timer mode	Continuous (no timer setting available)
Setting temperature	75.2°F (24°C)
Horizontal louver setting	Standard
Vertical louver setting	According to memory position
SWING	Off
ECONOMY	Off
Human sensor	Off

- During the forced cooling operation, it operates regardless of room temperature sensor.
- The operation indicator lamp and the timer indicator lamp blink simultaneously during the forced cooling operation.
They blink for 1 second ON and 1 second OFF on both the operation indicator lamp and the timer indicator lamp (same as test operation).

By performing one of the following action, test operation will be canceled:

- Pressing the remote controller START/STOP button
- Pressing FORCED COOLING OPERATION button for 3 seconds
- 60 minutes passed after starting forced cooling operation

NOTE: When HEAT operation is selected on the remote controller during forced cooling operation, heating test run will begin in about 3 minutes.

7-4. MIN. HEAT operation

MIN. HEAT operation performs as below setting when pressing MIN. HEAT button.

Operation mode	Heating
Setting temperature	50°F (10°C)
Fan mode	AUTO
LED display	Economy
Defrost operation	Operate as normal

7-5. ECONOMY operation

The ECONOMY operation starts by pressing ECONOMY button on the remote controller.

The ECONOMY operation is almost the same operation as below settings.

Mode	Cooling/Dry	Heating
Target temperature	Setting temperature +2°F (1°C)	Setting temperature -2°F (1°C)

7-6. POWERFUL operation

The POWERFUL operation starts by pressing POWERFUL button on the remote controller.
The indoor unit and outdoor unit operate at maximum power as shown in the table below.


		ASUH09-24KPAS	ASUH30-36KPAS
Rotation number of compressor		Maximum	
Fan mode		POWERFUL	
Horizontal louver setting	Cooling	3	
	Dry		
	Heating	6	5

Release condition:

- Cooling/Dry
Room temperature \leq Setting temperature -1°F (-0.5°C) or Operation time has passed 20 minutes.
- Heating
Room temperature \geq Setting temperature $+1^{\circ}\text{F}$ ($+0.5^{\circ}\text{C}$) or Operation time has passed 20 minutes.

7-7. Fresh air control

The fan motor for Fresh Air is operated in synchronization with the indoor fan operation as below.



7-8. Compressor preheating operation

⚠ CAUTION


To perform the preheat operation, turn on the power for the outdoor unit at least 12 hours before the operation. Especially in cold climate regions, the compressor may fail if the outdoor unit is on for less than 12 hours.

Compressor preheating operation prevents the damage caused by the refrigerant in the compressor from soaking into the oil. By preheating the compressor, warm airflow is quickly discharged when the operation is started.


- **Models: AOUH09KPAS1 and AOUH12KPAS1**

- **Triggering condition**

- 30 minutes after compressor stopped.
- Outdoor unit heat exchanger temperature (Tn)




When the jumper wire (JM2) is disconnected:




- **Models: AOUH18KPAS1 and AOUH24KPAS1**

- **Triggering condition**

- 30 minutes after compressor stopped.
- Outdoor unit heat exchanger temperature (Tn)



When the jumper wire (J600) is disconnected:




- **Models: AOUH30KPAS1 and AOUH36KPAS1**

- **Triggering condition 1**

- Outdoor temperature $\leq 68^{\circ}\text{F}$ (20°C)
When outdoor temperature reaches 78.8°F (26°C), compressor preheating stops.
- 30 minutes after compressor stopped


- **Triggering condition 2**



Tn: Outdoor unit heat exchanger temp.

7-9. External electrical heater control

The external electrical heater is operated as below.



NOTES:

- When the compressor stop, external electric heater is off.
- It operates only in heating mode and when the indoor fan operates. (However, S-LOW is excluded.)

7-10. Electronic expansion valve control

The most proper opening of the electronic expansion valve is calculated and controlled under the present operating condition based on the table below.

- **Models: AOUH09KPAS1, AOUH12KPAS1, AOUH18KPAS1, and AOUH24KPAS1**

Operation mode	Pulse range
Cooling/dry mode	Between 52 and 480 pulses
Heating mode	

- **Models: AOUH30KPAS1 and AOUH36KPAS1**

Operation mode	Pulse range
Cooling/dry mode	Between 47 and 480 pulses
Heating mode	Between 39 and 480 pulses

NOTE: At the time of supplying the power to the outdoor unit, the initialization of the electronic expansion valve is operated (528 pulses are input to the closing direction).

7-11. Prevention to restart for 3 minutes (3 minutes st)

When the compressor fails to start for the number of times below, it does not enter operation status for 3 minutes.

- **Models: AOUH09KPAS1 and AOUH12KPAS1**

Retry number	10
Retry set number	10

- **Models: AOUH18KPAS1 and AOUH24KPAS1**

Retry number	50
Retry set number	3

- **Models: AOUH30KPAS1 and AOUH36KPAS1**

Retry number	10
Retry set number	3

When the compressor fails to start in the retry set number above, the compressor is stopped.

7-12. 4-way valve control

- If heating mode is selected at the compressor start, 4-way valve is energized for heating.
- When the air conditioner is switched between cooling and heating mode, compressor is stopped, and the 4-way valve is switched when the following time passes and the compressor is started.

09/12/18/24 model	140 seconds
30/36 model	3 minutes

7-13. Peak cut operation (for 30/36 model)

The current value is limited to reduce the power consumption by external input.

Peak cut level	Level 1	Level 2	Level 3	Level 4
Peak cut for rated capacity	Forced thermostat off	50%	75%	100%

NOTES:

- During defrost operation, peak cut operation becomes invalid.
- Even during the peak cut operation, the operations of current overload, economy, and low noise are effective and the outdoor unit operates by lowest current of them.

7-14. Unit status monitoring and the detected value indication

The wired remote controller can monitor the indoor and outdoor units' status and display the detected result as a relevant ID.

For details of the display method, refer to the Chapter of "Display Sensor Values" in the *Installation Manual* of Wired Remote Controller (Touch Panel).

The status can be monitored and displayed on the wired remote controller by assigning an arbitrary ID. For available ID list, refer to the table below.

NOTE: Operating time for each part cannot be reset when the part is replaced. Take notes of the operating time before replacing to count the operating time of the replaced part.

Available Sensor ID				
Sensor ID		Item	Unit	Remarks
00: Indoor unit				
00	000	Suction temp.	01: °F or °C	
00	001	Room temp.	01: °F or °C	When the wired remote controller thermistor is enabled, temperature of the wired remote controller thermistor is displayed.
00	002	Wired remote controller detected temp.	01: °F or °C	
00	006	Heat exchanger middle temp.	01: °F or °C	
00	020	Fan rotation number	03: rpm	
00	080	Indoor unit total energized hours	11: h	
00	081	Total filtering hours	11: h	
00	082	Indoor unit fan total operation hours	11: h	
00	140	Operation or Stop (External input)	00: —	0: Off, 1: On —: When the function setting 46 is not set NOTE: Available only for external input port of the indoor unit
00	142	Forced stop (External input)	00: —	0: Off, 1: On —: When the function setting 46 is not set NOTE: Available only for external input port of the indoor unit
00	143	Operation or Stop 2 (External input)	00: —	0: Off, 1: On —: When the function setting 46 is not set NOTE: Available only for external input port of the indoor unit
00	155	Operation or Stop On/Off (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.
00	156	Error On/Off (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.
00	157	Indoor unit fan interlocking On/Off (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.
00	158	Cooling thermostat On/Off (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.

Available Sensor ID				
Sensor ID		Item	Unit	Remarks
00	159	Requested cooling strength On/Off (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.
00	160	External heater On/Off (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.
00	161	Heating operation status (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.
00	162	External output command by remote controller (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.
00	163	Set-point temp. not reached in server room function On/Off (External output)	00: —	0: Off, 1: On NOTE: The value is output even if the function setting or rotary switch is not set.
01: Outdoor unit				
01	000	Outdoor temp.	01: °F or °C	
01	001	Discharge temp.	01: °F or °C	
01	003	Heat exchanger middle temp.	01: °F or °C	
01	004	Heat exchanger outlet temp.	01: °F or °C	
01	007	Compressor temp.	01: °F or °C	
01	050	Fan 1 rotation number	03: rpm	
01	055	Compressor rotation number	04: rps	
01	060	Expansion valve (Upstream during heating)	05: pls	
01	080	4-way valve output status	07: Cooling/ Heating	0: Cooling, 1: Heating
01	100	Operating current	09: A	
01	110	Outdoor unit total power-on hours	11: h	
01	111	Compressor total heating operation hours	11: h	
01	112	Compressor total cooling operation hours	11: h	
01	113	Compressor total operation hours	11: h	
01	114	Outdoor unit fan 1 total operation hours	11: h	
01	145	Outdoor low noise input (External input)	00: —	0: Off, 1: On
01	146	Outdoor peak cut (External input)	00: —	0: Off 1: Mode 4 (100%) 2: Mode 3 (75%) 3: Mode 2 (50%) 4: Mode 1 (Forced thermostat off)
01	148	Switching cooling and heating mode (External input)	00: —	0: Cooling, 1: Heating
01	149	Emergency stop (External input)	00: —	0: Off, 1: On
01	155	Compressor status (External output)	00: —	0: Off, 1: On
01	156	Error status (External output)	00: —	0: Off, 1: On

8. Various protections

8-1. Discharge gas temperature over-rise prevention control

The discharge gas temperature sensor (discharge thermistor: outdoor unit side) detects the discharge gas temperature.

- When the discharge temperature becomes higher than the trigger condition, the rotation number of compressor is decreased as the table below, and it continues to decrease until the discharge temperature becomes lower than the trigger condition.
- When the discharge temperature becomes lower than the release condition, control of rotation number of compressor is released.
- When the discharge temperature becomes higher than the compressor protection temperature, the compressor is stopped and the indoor unit indicator lamp starts blinking.

- **Models: AOUH09KPAS1, AOUH12KPAS1, AOUH18KPAS1, and AOUH24KPAS1**

Trigger condition	219.2°F (104°C)
Rotation number of compressor	-20 rps/120 seconds
Release condition	213.8°F (101°C)
Compressor protection temperature	230.0°F (110°C)

- **Models: AOUH30KPAS1 and AOUH36KPAS1**

Trigger condition	219.2°F (104°C)
Rotation number of compressor	-14 rps/120 seconds
Release condition	213.8°F (101°C)
Compressor protection temperature	230.0°F (110°C)

8-2. Anti-freezing control (cooling and dry mode)

The rotation number of compressor is decrease in cooling and dry mode when the indoor unit heat exchanger temperature sensor detects the temperature lower than the trigger condition.

When the indoor unit heat exchanger temperature reaches release condition, the anti-freezing control is stopped.

Trigger condition		39.2°F (4°C)
Release condition	Outdoor temp. \geq 50°F (10°C)*1	44.6°F (7°C)
	Outdoor temp. \geq 53.6°F (12°C)*2	
	Outdoor temp. $<$ 50°F (10°C)*1	55.4°F (13°C)
	Outdoor temp. $<$ 53.6°F (12°C)*2	

*1: During the outdoor temperature dropping

*2: During the outdoor temperature rising

8-3. Current release control

The rotation number of compressor is controlled so that the outdoor unit input current does not exceeds current limit value set according to the outdoor temperature.

The rotation number of compressor returns according to the operation mode, when the current becomes lower than the release value.

■ Model: AOUH09KPAS1

Operation mode	Outdoor temp. (Ta)	Trigger condition	Release condition
Cooling	$114.8^{\circ}\text{F} (46^{\circ}\text{C}) \leq \text{Ta}$	3.5 A	3.0 A
	$104.0^{\circ}\text{F} (40^{\circ}\text{C}) \leq \text{Ta} < 114.8^{\circ}\text{F} (46^{\circ}\text{C})$	4.0 A	3.5 A
	$\text{Ta} < 104.0^{\circ}\text{F} (40^{\circ}\text{C})$	5.5 A	5.0 A
Heating	$62.6^{\circ}\text{F} (17^{\circ}\text{C}) \leq \text{Ta}$	5.5 A	5.0 A
	$\text{Ta} < 62.6 (17^{\circ}\text{C})$	7.0 A	6.5 A

■ Model: AOUH12KPAS1

Operation mode	Outdoor temp. (Ta)	Trigger condition	Release condition
Cooling	$114.8^{\circ}\text{F} (46^{\circ}\text{C}) \leq \text{Ta}$	4.0 A	3.5 A
	$104.0^{\circ}\text{F} (40^{\circ}\text{C}) \leq \text{Ta} < 114.8^{\circ}\text{F} (46^{\circ}\text{C})$	5.0 A	4.5 A
	$\text{Ta} < 104.0^{\circ}\text{F} (40^{\circ}\text{C})$	6.0 A	5.5 A
Heating	$62.6^{\circ}\text{F} (17^{\circ}\text{C}) \leq \text{Ta}$	5.5 A	5.0 A
	$53.6^{\circ}\text{F} (12^{\circ}\text{C}) \leq \text{Ta} < 62.6^{\circ}\text{F} (17^{\circ}\text{C})$	6.0 A	5.5 A
	$\text{Ta} < 53.6^{\circ}\text{F} (12^{\circ}\text{C})$	7.0 A	6.5 A

■ Model: AOUH18KPAS1

Operation mode	Outdoor temp. (Ta)	Trigger condition	Release condition
Cooling	$114.8^{\circ}\text{F} (46^{\circ}\text{C}) \leq \text{Ta}$	7.0 A	6.5 A
	$\text{Ta} < 114.8^{\circ}\text{F} (46^{\circ}\text{C})$	9.0 A	8.5 A
Heating	$62.6^{\circ}\text{F} (17^{\circ}\text{C}) \leq \text{Ta}$	7.0 A	6.5 A
	$53.6^{\circ}\text{F} (12^{\circ}\text{C}) \leq \text{Ta} < 62.6^{\circ}\text{F} (17^{\circ}\text{C})$	9.0 A	8.5 A
	$\text{Ta} < 53.6^{\circ}\text{F} (12^{\circ}\text{C})$	11.0 A	10.5 A

■ Model: AOUH24KPAS1

Operation mode	Outdoor temp. (Ta)	Trigger condition	Release condition
Cooling	$114.8^{\circ}\text{F} (46^{\circ}\text{C}) \leq \text{Ta}$	7.0 A	6.5 A
	$104.0^{\circ}\text{F} (40^{\circ}\text{C}) \leq \text{Ta} < 114.8^{\circ}\text{F} (46^{\circ}\text{C})$	9.5 A	9.0 A
	$\text{Ta} < 104.0^{\circ}\text{F} (40^{\circ}\text{C})$	13.5 A	13.0 A
Heating	$62.6^{\circ}\text{F} (17^{\circ}\text{C}) \leq \text{Ta}$	7.0 A	6.5 A
	$53.6^{\circ}\text{F} (12^{\circ}\text{C}) \leq \text{Ta} < 62.6^{\circ}\text{F} (17^{\circ}\text{C})$	9.0 A	8.5 A
	$\text{Ta} < 53.6^{\circ}\text{F} (12^{\circ}\text{C})$	13.0 A	12.5 A

■ Model: AOUH30KPAS1

Operation mode	Outdoor temp. (Ta)	Trigger condition	Release condition
Cooling	$125.6^{\circ}\text{F} (52^{\circ}\text{C}) \leq T_a$	8.0 A	7.5 A
	$122.0^{\circ}\text{F} (50^{\circ}\text{C}) \leq T_a < 125.6^{\circ}\text{F} (52^{\circ}\text{C})$	12.0 A	11.5 A
	$100.4^{\circ}\text{F} (38^{\circ}\text{C}) \leq T_a < 122.0^{\circ}\text{F} (50^{\circ}\text{C})$	14.0 A	13.5 A
	$T_a < 100.4^{\circ}\text{F} (38^{\circ}\text{C})$	16.5 A	16.0 A
Heating	$53.6^{\circ}\text{F} (12^{\circ}\text{C}) \leq T_a$	12.0 A	11.5 A
	$44.6^{\circ}\text{F} (7^{\circ}\text{C}) \leq T_a < 53.6^{\circ}\text{F} (12^{\circ}\text{C})$	12.5 A	12.0 A
	$T_a < 44.6^{\circ}\text{F} (7^{\circ}\text{C})$	16.0 A	15.5 A

■ Model: AOUH36KPAS1

Operation mode	Outdoor temp. (Ta)	Trigger condition	Release condition
Cooling	$125.6^{\circ}\text{F} (52^{\circ}\text{C}) \leq T_a$	8.0 A	7.5 A
	$122.0^{\circ}\text{F} (50^{\circ}\text{C}) \leq T_a < 125.6^{\circ}\text{F} (52^{\circ}\text{C})$	12.0 A	11.5 A
	$100.4^{\circ}\text{F} (38^{\circ}\text{C}) \leq T_a < 122.0^{\circ}\text{F} (50^{\circ}\text{C})$	14.0 A	13.5 A
	$T_a < 100.4^{\circ}\text{F} (38^{\circ}\text{C})$	16.5 A	16.0 A
Heating	$53.6^{\circ}\text{F} (12^{\circ}\text{C}) \leq T_a$	12.0 A	11.5 A
	$44.6^{\circ}\text{F} (7^{\circ}\text{C}) \leq T_a < 53.6^{\circ}\text{F} (12^{\circ}\text{C})$	15.5 A	15.0 A
	$T_a < 44.6^{\circ}\text{F} (7^{\circ}\text{C})$	16.0 A	15.5 A

8-4. Cooling pressure over-rise protection (for 09/12/18/24 model)

When the outdoor unit heat exchanger temperature reaches trigger condition below, the compressor is stopped and trouble display is performed.

Trigger condition	149.0°F (65°C)
-------------------	----------------

8-5. Compressor temperature protection (for 18/24/30/36 model)

When the compressor temperature sensor detects higher than the trigger condition below, the compressor is stopped. When the compressor temperature sensor detects the release condition, the protection is released.

Trigger condition	226.4°F (108°C)
Release condition	176.0°F (80°C) (3 minutes after compressor stop)

8-6. High pressure protection (for 30/36 model)

Trigger condition	Pressure switch: Off (Open: Higher than 4.2 MPa) Compressor stop
Release condition	Pressure switch: On (Close: Lower than 3.2 MPa) (3 minutes after compressor stop) Compressor restart

8-7. Low outdoor temperature protection (for 09/12 model)


When the outdoor temperature sensor detects lower than the trigger condition below, the compressor is stopped.

Operation mode	Cooling/Dry
Trigger condition	5°F (-15°C)
Release condition	14°F (-10°C)

8-8. High temperature and high pressure release control

The compressor is controlled as follows.


■ Models: AOUH09KPAS1, AOUH12KPAS1, AOUH18KPAS1, and AOUH24KPAS1



Zone	Operation	
Zone A	Compressor is stopped.	
Zone B	The rotation number of compressor is decreased.	-25 rps/120 sec.
Zone C		-3 rps/60 sec.
Zone D	The protection is released and the operation is returned to normal mode.	
Zone E		


■ Models: AOUH30KPAS1 and AOUH36KPAS1

• Cooling mode



Zone	Operation	
Zone A	Compressor is stopped.	
Zone B	The rotation number of compressor is decreased.	-7 rps/120 sec.
Zone C	The protection is released and the operation is returned to normal mode.	
Zone D		

• Heating mode



Zone	Operation	
Zone A	Compressor is stopped.	
Zone B	The rotation number of compressor is decreased.	-15 rps/120 sec.
Zone C		-2 rps/120 sec.
Zone D	The protection is released and the operation is returned to normal mode.	
Zone E		

5. FIELD WORKING

CONTENTS

5. FIELD WORKING

1. Function settings (for indoor unit).....	05-1
1-1. Function settings by using remote controller	05-1
1-2. Custom code setting for wireless remote controller	05-10
2. Function settings (for 30–36 outdoor units)	05-11
2-1. Control PCB and switch buttons location.....	05-11
2-2. Local setting procedure	05-13
3. External input and output (for indoor unit)	05-15
3-1. External input.....	05-16
3-2. External output	05-19
3-3. Setting of external input and output	05-21
3-4. Details of control input function.....	05-23
3-5. Details of control output function	05-27
4. External input and output (for 30–36 outdoor units).....	05-48
4-1. External input.....	05-48
4-2. External output	05-50

1. Function settings (for indoor unit)

To adjust the functions of this product according to the installation environment, various types of function settings are available.

NOTE: Incorrect settings can cause a product malfunction.

1-1. Function settings by using remote controller

Some function settings can be changed on the remote controller. After confirming the setting procedure and the content of each function setting, select appropriate functions for your installation environment.

■ Setting procedure by using wireless remote controller

The function number and the associated setting value are displayed on the LCD of the remote controller. Follow the instructions written in the installation manual, and select appropriate setting according to the installation environment.

Before connecting the power supply of the indoor unit, reconfirm following items:

- Cover for the electrical enclosure on the outdoor unit is in place.
- There is no wiring mistake.
- Piping air tightness test and vacuuming have been performed firmly.
- All the necessary wiring work for outdoor unit has been finished.

After reconfirming the items listed above, connect the power supply of the indoor unit.

NOTES:


- Settings will not be changed if invalid numbers or setting values are selected.
- When optional wired remote controller is used, refer to the installation manual enclosed with the remote controller.

Entering function setting mode:

While pressing the FAN SPEED button and TEMP. (△) button simultaneously, press the RESET button to enter the function setting mode.

Selecting the function number and setting value:

1. Press MODE button.
2. Press the TEMP. (△) (▽) buttons to select the function number. (Press MODE button to switch between the left and right digits.)
3. Press the FAN SPEED button to proceed to value setting. (Press FAN SPEED button again to return to the function number selection.)
4. Press the TEMP. (△) (▽) buttons to select the setting value. (Press MODE button to switch between the left and right digits.)
5. Press the POWERFUL button once. Confirm that you hear the beep.
6. Press the START/STOP button once to fix the Function setting. Confirm that you hear the beep.
7. Press the RESET button to cancel the function setting mode.
8. After completing the function setting, be sure to disconnect the power supply and then reconnect it.



⚠ CAUTION

After disconnecting the power supply, wait 30 seconds or more before reconnecting it. The function setting will not become active unless the power supply is disconnected and then reconnected.

■ Contents of function setting

Each function setting listed in this section is adjustable in accordance with the installation environment.

NOTE: Setting will not be changed if invalid numbers or setting values are selected.

● Function setting list

	Function no.	Functions
1)	11	Filter sign
2)	30/31	Room temperature control for indoor unit sensor
3)	35/36	Room temperature control for wired remote controller sensor
4)	40	Auto restart
5)	42	Room temperature sensor switching
6)	44	Remote controller custom code
7)	46	External input control
8)	48	Room temperature sensor switching (Aux.)
9)	49	Indoor unit fan control for energy saving for cooling
10)	60	Switching functions for external output terminal
11)	61	Control switching of external heaters
12)	62	Operating temperature switching of external heaters
13)	66	Outdoor temperature zone boundary temperature A
14)	67	Outdoor temperature zone boundary temperature B
15)	71	Standby time for auxiliary equipment operation
16)	72	Heat pump backup setting
17)	73	Emergency heat for external output terminal
18)	94	Fixed operation mode switching
19)	95	Heat insulation condition (building insulation)
20)	96	Special cooling operation (For 18-36 model)

1) Filter sign

Select appropriate intervals for displaying the filter sign on the indoor unit according to the estimated amount of dust in the air of the room.

If the indication is not required, select "No indication" (03).

Function number	Setting value	Setting description	Factory setting
11	00	Standard (400 hours)	
	01	Long interval (1,000 hours)	
	02	Short interval (200 hours)	
	03	No indication	◆

2) Room temperature control for indoor unit sensor

NOTE: Before performing this setting, refer to Function 95.

Depending on the installed environment, correction of the room temperature sensor may be required. Select the appropriate control setting according to the installed environment.

The temperature of the room temperature sensor is corrected as follows:

Corrected temp. = Temp. of the room temp. sensor - Correction temp. value

Example of correction:

When the temperature of the room temp. sensor is 78°F and the setting value is "03" (-2°F), the corrected temp. will be 80°F (78°F - [-2°F]).

The temperature correction values show the difference from the Standard setting "00" (manufacturer's recommended value).

*When Function 95-01 (High insulation) is set, the Standard setting "00" will be the same as "No correction 0.0°F (0.0°C)" (01).

Function number		Setting value	Setting description		Factory setting
30 (For cooling)	31 (For heating)	00	Standard setting*		◆
		01	No correction 0.0°F (0.0°C)		
		02	-1°F (-0.5°C)	More cooling Less heating	
		03	-2°F (-1.0°C)		
		04	-3°F (-1.5°C)		
		05	-4°F (-2.0°C)		
		06	-5°F (-2.5°C)		
		07	-6°F (-3.0°C)		
		08	-7°F (-3.5°C)		
		09	-8°F (-4.0°C)		
		10	+1°F (+0.5°C)	Less cooling More heating	
		11	+2°F (+1.0°C)		
		12	+3°F (+1.5°C)		
		13	+4°F (+2.0°C)		
		14	+5°F (+2.5°C)		
		15	+6°F (+3.0°C)		
		16	+7°F (+3.5°C)		
		17	+8°F (+4.0°C)		

3) Room temperature control for wired remote controller sensor

NOTE: Before performing this setting, refer to Function 95.

Depending on the installed environment, correction of the wire remote temperature sensor may be required. Select the appropriate control setting according to the installed environment.

To change this setting, set Function 42 to “Both” (01).

Ensure that the Thermo Sensor icon is displayed on the remote controller screen.

*When Function 95-01 (High insulation) is set, the Standard setting “00” will be the same as “No correction 0.0°C” (01).

Function number		Setting value	Setting description	Factory setting
35 (For cooling)	36 (For heating)	00	Standard setting*	◆
		01	No correction 0.0°F (0.0°C)	
		02	-1°F (-0.5°C)	More cooling Less heating
		03	-2°F (-1.0°C)	
		04	-3°F (-1.5°C)	
		05	-4°F (-2.0°C)	
		06	-5°F (-2.5°C)	
		07	-6°F (-3.0°C)	
		08	-7°F (-3.5°C)	
		09	-8°F (-4.0°C)	
		10	+1°F (+0.5°C)	Less cooling More heating
		11	+2°F (+1.0°C)	
		12	+3°F (+1.5°C)	
		13	+4°F (+2.0°C)	
		14	+5°F (+2.5°C)	
		15	+6°F (+3.0°C)	
		16	+7°F (+3.5°C)	
		17	+8°F (+4.0°C)	

4) Auto restart

Enables or disables automatic restart after a power interruption.

Function number	Setting value	Setting description	Factory setting
40	00	Enable	◆
	01	Disable	

NOTE: Auto restart is an emergency function such as for power outage etc. Do not attempt to use this function in normal operation. Be sure to operate the unit by remote controller or external device.

5) Room temperature sensor switching

(Only for wired remote controller)

When using the wired remote controller temperature sensor, change the setting to “Both” (01).

Function number	Setting value	Setting description	Factory setting
42	00	Indoor unit	◆
	01	Both	

00: Sensor on the indoor unit is active.

01: Sensors on both indoor unit and wired remote controller are active.

NOTE: Remote controller sensor must be turned on by using the remote controller.

6) Remote controller custom code

(Only for wireless remote controller)

The indoor unit custom code can be changed. Select the appropriate custom code.

Function number	Setting value	Setting description	Factory setting
44	00	A	◆
	01	B	
	02	C	
	03	D	

7) External input control

“Operation/Stop” mode or “Forced stop” mode can be selected.

Function number	Setting value	Setting description	Factory setting
46	00	Operation/Stop mode 1 (Remote controller enabled)	◆
	01	(Setting prohibited)	
	02	Forced stop mode	
	03	Operation/Stop mode 2 (Remote controller disabled)	

8) Room temperature sensor switching (Aux.)

To use the temperature sensor on the wired remote controller only, change the setting to “Wired remote controller” (01).

This function will only work if the function setting 42 is set at “Both” (01).

When the setting value is set to “Both” (00), more suitable control of the room temperature is possible by setting function setting 30 and 31 too.

Function number	Setting value	Setting description	Factory setting
48	00	Both	◆
	01	Wired remote controller	

9) Indoor unit fan control for energy saving for cooling

Enables or disables the power-saving function by controlling the indoor unit fan rotation when the outdoor unit is stopped during cooling operation.

Function number	Setting value	Setting description	Factory setting
49	00	Disable	
	01	Enable	
	02	Remote controller	◆

00: When the outdoor unit is stopped, the indoor unit fan operates continuously following the setting on the remote controller.

01: When the outdoor unit is stopped, the indoor unit fan operates intermittently at a very low speed.

02: Enable or disable this function by remote controller setting.

NOTE: Set to “00” or “01” when connecting a remote controller that cannot set the Fan control for energy saving function or connecting a network converter. To confirm if the remote controller has this setting, refer to the operating manual of each remote controller.

10) Switching functions for external output terminal

Functions of the external output terminal can be switched. For details, refer to “External input and output”.

Function number	Setting value	Setting description	Factory setting
60	00	Operation status	◆
	01—04	Cooling thermostat On	
	05	Heating operation	
	06	Operation/Stop	
	07—08	Cooling thermostat On	
	09	Error status	
	10	Indoor unit fan operation status	
	11	External heater	
	12	Setpoint Attainment status (For 18-36 model)	

11) Control switching of external heaters

Sets the control method for external heater to be used.

For details, refer to “External heater output” in ["Details of control output function"](#) on page 05-27.

Function number	Setting value	Setting description	Factory setting
61	00	Auxiliary heater control 1	◆
	01	Auxiliary heater control 2	
	02	Heat pump prohibition control	
	03	Auxiliary heater control by outdoor temperature 1	
	04	Auxiliary heater control by outdoor temperature 2	
	05	Auxiliary heater control by outdoor temperature 3	
	06	Auxiliary heat pump control	
	07	Auxiliary heat pump control by outdoor temperature 1	
	08	Auxiliary heat pump control by outdoor temperature 2	
	09	Auxiliary heat pump control by outdoor temperature 3	

12) Operating temperature switching of external heaters

Sets the temperature conditions when the external heater is ON.

For details, refer to “External heater output” in ["Details of control output function"](#) on page 05-27.

Function number	Setting value	Setting description		Factory setting
		Heater: On	Heater: Off	
62	00	-5.4 °F (-3 °C)	-1.8 °F (-1 °C)	◆
	01	-3.6 °F (-2 °C)	-1.8 °F (-1 °C)	
	02	-3.6 °F (-2 °C)	-1.8 °F (-1 °C)	
	03	-5.4 °F (-3 °C)	-1.8 °F (-1 °C)	
	04	-7.2 °F (-4 °C)	-1.8 °F (-1 °C)	
	05	-9.0 °F (-5 °C)	-1.8 °F (-1 °C)	

13) Outdoor temperature zone boundary temperature A

Setting required if changing of the outdoor temperature setting for heat pump prohibition zone is required when auxiliary heater control by outdoor temperature 1 and 2 are performed on the indoor unit.

For details, refer to "External heater output" in ["Details of control output function"](#) on page 05-27.

Function number	Setting value	Setting description	Factory setting
66	00	-4.0°F (-20°C)	◆
	01	-0.4°F (-18°C)	
	02	3.2°F (-16°C)	
	03	6.8°F (-14°C)	
	04	10.4°F (-12°C)	
	05	14.0°F (-10°C)	
	06	17.6°F (-8°C)	
	07	21.2°F (-6°C)	
	08	24.8°F (-4°C)	

14) Outdoor temperature zone boundary temperature B

Setting required if changing of the outdoor temperature setting for heat pump only zone is required when auxiliary heater control by outdoor temperature 1 and 3 is performed on the indoor unit.

For details, refer to "External heater output" in ["Details of control output function"](#) on page 05-27.

Function number	Setting value	Setting description	Factory setting
67	00	42.8°F (6°C)	◆
	01	14.0°F (-10°C)	
	02	17.6°F (-8°C)	
	03	21.2°F (-6°C)	
	04	24.8°F (-4°C)	
	05	28.4°F (-2°C)	
	06	32.0°F (0°C)	
	07	35.6°F (2°C)	
	08	39.2°F (4°C)	
	09	42.8°F (6°C)	
	10	46.4°F (8°C)	
	11	50.0°F (10°C)	
	12	53.6°F (12°C)	
	13	57.2°F (14°C)	
	14	60.8°F (16°C)	
	15	64.4°F (18°C)	

15) Standby time for auxiliary equipment operation

Sets the standby time until the auxiliary equipment operation starts during primary equipment operation.

For details, refer to ["Details of control output function"](#) on page 05-27.

Function number	Setting value	Setting description	Factory setting
71	00	Disable	◆
	01	1 minute	
	02	2 minutes	
	•	•	
	•	•	
	•	•	
	98	98 minutes	
	99	99 minutes	

16) Heat pump backup setting

Enables or disables the heat pump backup operation.

Function number	Setting value	Setting description	Factory setting
72	00	Disable	◆
	01	Enable	

17) Emergency heat for external output terminal

Enables or disables emergency heat input.

Function number	Setting value	Setting description	Factory setting
73	00	Disable	◆
	01	Enable	

NOTE: When this function is used, IR Receiver Unit or Wired Remote Controller is necessary.

18) Fixed operation mode switching

Sets the operation mode to heat pump, heating only, or cooling only.

Function number	Setting value	Setting description	Factory setting
94	00	Heat pump	◆
	01	Heating only	
	02	Cooling only	

NOTE: Do not use “Heating only” mode (01) of Function 94 and “Enabled” (01) of Function 96 simultaneously.

19) Heat insulation condition (building insulation)

Heat insulation conditions differ according to the installed environment.

“Standard insulation” (00) allows system to rapidly respond to the cooling or heating load changes.

“High insulation” (01) is when the heat insulation structure of the building is high and does not require system to rapidly respond to cooling or heating load changes.

When “High insulation” (01) is selected:

- Overheating (overcooling) is prevented at the start-up.
- All room-temperature control settings (Function 30, 31, 35, and 36) will reset to “No correction 0.0°F (0.0°C)”.

Function number	Setting value	Setting description	Factory setting
95	00	Standard insulation	◆
	01	High insulation	

NOTE: When changing Function 95, perform this setting before other room-temperature control settings (Function 30, 31, 35, and 36). If Function 95 is not set first, room-temperature control settings (Function 30, 31, 35, and 36) will be reset and you must re-do them again.

20) Special cooling operation (For 18-36 model)

Stabilizes the cooling operation when the outdoor temperature is low.

- Operation mode: Fixed at COOL
- Airflow: Fixed at HIGH
- Set temperature: 76°F (24°C) to 88°F (30°C)
- Outdoor unit operation range: -4°F (-20°C) to 122°F (50°C)*
* Suction temperature

Function number	Setting value	Setting description	Factory setting
96	00	Disable	◆
	01	Enable	

NOTES:

- Do not enable this function when the Function 94 setting is “Heating only” (01).
- Connect the optional wired remote controller to change the setting value to “Enable” (01).
- Do not use the wireless remote controller after changing the setting value to “Enable” (01).
- If the wired remote controller becomes noncommunicable after setting “Enable” (01), the cooling operation starts automatically.
- If dew condenses on the indoor unit surface after setting “Enable” (01), set the setting value back to “Disable” (00).

1-2. Custom code setting for wireless remote controller


To interconnect the air conditioner and the wireless remote controller, assignment of the custom code for the wireless remote controller is required.

NOTE: Air conditioner cannot receive a signal if the air conditioner has not been set for the custom code.

When 2 or more air conditioners are installed in a room, and the remote controller is operating an air conditioner other than the one you wish to set, change the custom code of the remote controller to operate only the air conditioner you wish to set. (4 selections possible.)

Confirm the setting of the remote controller custom code and the function setting. If these do not match, the remote controller cannot be used to operate for the air conditioner.

1. Press the START/STOP button until only the clock is displayed on the remote controller display.
2. Press the MODE button for at least 5 seconds to display the current custom code. (Initially set to A .)
3. Press the TEMP. (\wedge) (\vee) buttons to change the custom code between $\text{A} \rightarrow \text{b} \rightarrow \text{c} \rightarrow \text{d}$. Match the code on the display to the air conditioner custom code. (Initially set to A .)
4. Press the MODE button again to return to the clock display. The custom code will be changed.



NOTES:

- If no button is pressed within 30 seconds after the custom code is displayed, the system returns to the original clock indicator. In this case, start again from step 1.
- The air conditioner custom code is set to A prior to shipment. To change the custom code, contact your retailer.
- If you do not know the assigned code for the air conditioner, try each of the custom code ($\text{A} \rightarrow \text{b} \rightarrow \text{c} \rightarrow \text{d}$) until you find the code which operates the air conditioner.

2. Function settings (for 30–36 outdoor units)

Perform appropriate function setting locally according to the installation environment.


NOTE: Incorrect settings can cause a product malfunction.

⚠ CAUTION


- Before setting up the switch buttons, discharge the static electricity from your body.
- Never touch the terminals or the patterns on the parts that are mounted on the PCB.

2-1. Control PCB and switch buttons location

Control PCB of the outdoor unit is located as shown in the following figure.



Switch buttons and the functions



LED lamp			Function or operation method
(1)	POWER/MODE	Green	Lights on while power on. Blinks to show the local setting on the outdoor unit or the error code.
(2)	ERROR	Red	Blinks during error operation.
(3)	PUMP DOWN (L1)	Orange	Lights on during pump down operation.
(4)	LOW NOISE MODE (L2 and L3)	Orange	Lights on during "Low noise mode" when local setting is activated. (Light pattern of L2 and L3 indicates the low noise level.)
(5)	PEAK CUT MODE (L4, L5, and L6)	Orange	Lights on during "Peak cut mode" when local setting is activated. (Light pattern of L4, L5, and L6 indicates the peak cut level.)

Switch button		Function or operation method
S134	MODE	Switches between "Local setting" and "Error code display".
S133	SELECT	Switches between the individual "Local settings" and the "Error code displays".
S132	ENTER	Switches between the individual "Local settings" and the "Error code displays".
S131	EXIT	Returns to "Operation status display".
S130	PUMP DOWN	Starts the pump down operation.

2-2. Local setting procedure

NOTE: Before performing the function setting, be sure to stop the operation of the air conditioner.

Low noise mode

1. Press the MODE switch button (S134) for 3 seconds or more to switch to "Local setting mode".
2. After confirming the LED lamp of POWER/MODE blinks 9 times, press the ENTER switch button (S132).

POWER MODE	ERROR	PUMP DOWN (L1)	LOW NOISE		PEAK CUT		
			(L2)	(L3)	(L4)	(L5)	(L6)
Blinks (9 times)	○	○	○	○	○	○	○

Sign "○": Lights off

3. Press the SELECT switch button (S133), and adjust the LED lamp as shown below. Then the LED lamp indicates the current setting.

LOW NOISE MODE	LOW NOISE	
	(L2)	(L3)
	○	Blink

4. Press the ENTER switch button (S132).

LOW NOISE MODE	LOW NOISE	
	(L2)	(L3)
	○	●

Sign "●": Lights on

5. Press the SELECT switch button (S133), and adjust the LED lamps as shown below.

MODE 1: Low MODE 2: Lower	PEAK CUT		
	(L4)	(L5)	(L6)
	○	○	Blink
	○	Blink	○

6. Press the ENTER switch button (S132) and fix it.

MODE 1: Low MODE 2: Lower	PEAK CUT		
	(L4)	(L5)	(L6)
	○	○	●
	○	●	○

7. To return to "Operating status display (Normal operation)", press the EXIT switch button (S131).

In case of missing how many times you pressed the SELECT and ENTER switch buttons:

1. To return to "Operation status display (Normal operation)", press the EXIT switch button once.
2. Restart from the beginning of setting procedure.

■ Peak cut mode

1. Press the MODE switch button (S134) for 3 seconds or more to switch to “Local setting mode”.
2. After confirming the LED lamp of POWER/MODE blinks 9 times, press the ENTER switch button (S132).

POWER MODE	ERROR	PUMP DOWN (L1)	LOW NOISE (L2) (L3)		PEAK CUT (L4) (L5) (L6)		
Blinks (9 times)	○	○	○	○	○	○	○

Sign “○”: Lights off

3. Press the SELECT switch button (S133), and adjust the LED lamp as shown below. Then the LED lamp indicates the current setting.

PEAK CUT MODE	LOW NOISE	
	(L2)	(L3)
	Blink	○

4. Press the ENTER switch button (S132).

PEAK CUT MODE	LOW NOISE	
	(L2)	(L3)
	●	○

Sign “●”: Lights on

5. Press the SELECT switch button (S133), and adjust the LED lamps as shown below.

	PEAK CUT		
	(L4)	(L5)	(L6)
0 % of rated input ratio	○	○	Blink
50 % of rated input ratio	○	Blink	○
75 % of rated input ratio	○	Blink	Blink
100 % of rated input ratio	Blink	○	○


6. Press the ENTER switch button (S132) and fix it.

	PEAK CUT		
	(L4)	(L5)	(L6)
0 % of rated input ratio	○	○	●
50 % of rated input ratio	○	●	○
75 % of rated input ratio	○	●	●
100 % of rated input ratio	●	○	○

7. To return to “Operating status display (Normal operation)”, press the EXIT switch button (S131).

NOTE: When pressed number is lost during setting, you must redo the setting procedure. Return to “Operation status display (Normal operation)” by pressing the EXIT switch button once, and restart from the beginning of the setting procedure.

3. External input and output (for indoor unit)



Connecting point		Input/Output	Function	Input select	Input signal
Indoor unit	CN46	Input	Operation/Stop	Dry contact	Edge
			Forced stop		
	CN47	Output	Operation/Stop	—	—
			Error status		
			Indoor unit fan operation status		
			Cooling thermostat On		
			Heating thermostat On		
			External heater output		
			Set point attainment status (For 18-36 model)		
External Input and Output PCB (UTY-XCSXZ2)	CN313/CN314	Input	Operation/Stop	Dry contact/Apply voltage	Edge/Pulse
			Forced stop		
	CN313		Forced thermostat off		Edge
	CN310 CN311 CN312	Output	Operation status	—	—
			Error status		
			Indoor unit fan operation status		
			External heater output		
			Remote controller output		
			Cooling high/low output		
			Heating thermostat On		

NOTE: For details of the switching function, refer to ["Setting of external input and output"](#) on page 05-21.


3-1. External input

With using external input function, some functions on this product can be controlled from an external device.

- "Operation/Stop" mode or "Forced stop" mode can be selected with function setting of indoor unit.
- A twisted pair cable (22 AWG) should be used. Maximum length of cable is 492 ft (150 m).
- Use an external input and output cable with appropriate external dimension, depending on the number of cables to be installed.
- The wire connection should be separate from the power cable line.

Indoor unit

Indoor unit functions such as Operation/Stop can be done by using indoor unit connectors.



*1: The switch can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

External Input and Output PCB


The indoor unit Operation/Stop can be set by using the input connector on the PCB.

• Input select

Use either one of these types of connectors according to the application. (Both types of connectors cannot be used simultaneously.)

– Dry contact


In case of internal power supply, set the slide switch of SW301 to "NON VOL" side.



*1: The switches can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

– Apply voltage

In case of external power supply, set the slide switch of SW301 to "VOL" side.




*1: The switches can be used on the following condition: DC 12 V to 24 V, 1 mA to 15 mA.

*2: Make the power supply DC 12 V to 24 V, 10 mA or more.

■ Input signal type

- **Indoor unit**


Input signal type is only "Edge".



- **External Input and Output PCB**

The input signal type can be selected.

Signal type (edge or pulse) can be switched by the DIP switch 2 (SW302) on the External Input and Output PCB.



NOTE: The input signal supports the following switch type:

- Edge: Alternate type switch
- Pulse: Momentary type switch

3-2. External output


Use an external output cable with appropriate external dimension, depending on the number of cables to be installed.

Indoor unit

- A twisted pair cable (22 AWG) should be used. Maximum length of cable is 82 ft (25 m).
- Output voltage: High DC 12 V \pm 2 V, Low 0 V.
- Permissible current: 50 mA
- For details, refer to ["Setting of external input and output"](#) on page 05-21.


- **When indicator, etc. are connected directly**

Example: Function setting number 60 is set to "00"




- **When connecting with a device equipped with a power supply**

Example: Function setting number 60 is set to "00"




External Input and Output PCB

- A twisted pair cable (22AWG) should be used. Maximum length of cable is 82 ft (25 m).
- Output voltage: High DC 12 V \pm 2 V, Low 0 V.
- Permissible current: 50 mA
- For details, refer to ["Setting of external input and output"](#) on page 05-21.
- **When indicator or other components are connected directly:**
Example: Rotary SW on External Input and Output PCB is set to "1".



- **When connecting with a device equipped with a power supply:**
Example: Rotary SW on External Input and Output PCB is set to "1".



3-3. Setting of external input and output

- Indoor unit

Input		
Connection point	Function setting number 46	Function
CN46	00	Operation/Stop mode 1 (R.C. enabled)
	01	(Setting prohibited)
	02	Forced stop mode
	03	Operation/Stop mode 2 (R.C. disabled)

Output		
Connection point	Function setting number 60	Function
CN47	00	Operation/Stop
	01 to 04	Cooling thermostat On
	05	Heating thermostat On
	06	Operation/Stop
	07 to 08	Cooling thermostat On
	09	Error status
	10	Indoor unit fan operation status
	11	External heater output
	12	Setpoint attainment status (For 18-36 model)

• External Input and Output PCB

Switch setting		Ex IN		Ex OUT		
Rotary switch	SW302	CN313	CN314	CN310	CN311	CN312
1	Edge	Operation/Stop	Not available	Operation/Stop	Error status	Indoor unit fan operation status
	Pulse	Operation	Stop			
2	Edge*1	Forced thermostat off	Not available	Error status	Indoor unit fan operation status	External heater output
3		Mechanical cooling off	Not available	Error status	Indoor unit fan operation status	External heater output
4		Forced thermostat off	Not available	Error status	Remote controller output	External heater output
5		Mechanical cooling on*2	Not available	Cooling high/low output	Remote controller output	External heater output
6		Mechanical cooling on*2	Not available	Error status	Remote controller output	Cooling high/low output
7		Forced thermostat off	Not available	Error status	Indoor unit fan operation status	External heater output
8		Forced thermostat off	Not available	Error status	Indoor unit fan operation status	Heating thermostat on
9		Mechanical cooling off	Not available	Error status	Heating thermostat on	External heater output
A		Forced thermostat off	Not available	Heating thermostat on	Remote controller output	External heater output
B		Forced thermostat off	Not available	Operation/Stop	Indoor unit fan operation status	External heater output
C		Forced thermostat off	Not available	Operation/Stop	Error status	External heater output
D		Forced thermostat off	Not available	Operation/Stop	Indoor unit fan operation status	Error status

NOTES:


- When the rotary switch is selected to "1", the operation of the connector input of the indoor unit and the External Input and Output PCB input are the same. The operation content depends on the setting of function setting number 46.
- *1: The external input other than "Operation/Stop" is available only when the SW302 is set to "Edge".
- *2: The external input of "Mechanical cooling on" is available only when the function setting number 60 is set to "03" or "04".

3-4. Details of control input function

■ Operation/Stop mode 1


- In the case of "Edge" input

Function setting	External Input and Output PCB		External input		Input signal	Command
	Rotary switch	SW302				
46-00	—		Input of indoor unit	CN46	Off → On	Operation
	—		Input of indoor unit	CN46	On → Off	Stop
	1	Edge	External Input and Output PCB	CN313	Off → On	Operation
					On → Off	Stop



- In the case of "Pulse" input

Function setting	External Input and Output PCB		External input		Input signal	Command
	Rotary switch	SW302				
46-00	1	Pulse	External Input and Output PCB	CN313	Pulse	Operation
				CN314		Stop




NOTES:

- The last command has priority.
- The indoor units within the same remote controller group operates in the same mode.

■ Forced stop


- In the case of "Edge" input

Function setting	External Input and Output PCB		External input		Input signal	Command
	Rotary switch	SW302				
46-02	—		Input of indoor unit	CN46	Off → On	Forced stop (R.C. disabled)
					On → Off	Normal (R.C. enabled)
	1	Edge	External Input and Output PCB	CN313	Off → On	Forced stop (R.C. disabled)
					On → Off	Normal (R.C. enabled)



- In the case of "Pulse" input

Function setting	External Input and Output PCB		External input		Input signal	Command
	Rotary switch	SW302				
46-02	1	Pulse	External Input and Output PCB	CN313	Pulse	Forced stop (R.C. disabled)
				CN314		Normal (R.C. enabled)




NOTES:

- When the forced stop is triggered, indoor unit stops and Operation/Stop operation by the remote controller is restricted.
- When forced stop function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

■ Operation/Stop mode 2


- In the case of “Edge” input

Function setting	External Input and Output PCB		External input		Input signal	Command
	Rotary switch	SW302				
46-03	—		Input of indoor unit	CN46	Off → On	Operation (R.C. enabled)
					On → Off	Stop (R.C. disabled)
	1	Edge	External Input and Output PCB	CN313	Off → On	Operation (R.C. enabled)
					On → Off	Stop (R.C. disabled)



- In the case of “Pulse” input


Function setting	External Input and Output PCB		External input		Input signal	Command
	Rotary switch	SW302				
46-03	1	Pulse	External Input and Output PCB	CN313	Pulse	Operation (R.C. enabled)
				CN314		Stop (R.C. disabled)



NOTE: When “Operation/Stop” mode 2 function is used with forming a remote controller group, connect the same equipment to each indoor unit within the group.

■ Forced thermostat off

External Input and Output PCB	External input		Input signal	Command
Rotary switch				
2, B, C, D	External Input and Output PCB	CN313	Off → On	Thermostat off
			On → Off	Normal operation
4, 7, 8, A	External Input and Output PCB	CN313	Off → On	Thermostat off
			On → Off	Normal operation




3-5. Details of control output function

■ Operation status

Function setting	External Input and Output PCB	External output		Output signal	Status
	Rotary switch				
60-00 60-06	1, 2, 8	Output of indoor unit	CN47	Off → On	Operation
				On → Off	Stop
—	1, B, C, D	External Input and Output PCB	CN310	Off → On	Operation
				On → Off	Stop


The output is low when the unit is stopped.



■ Error status

Function setting	External Input and Output PCB	External output		Output signal	Status
	Rotary switch				
60-09	—	Output of indoor unit	CN47	Off → On	Error
				On → Off	Normal
—	2, 3, 4, 6, 7, 8, 9	External Input and Output PCB	CN310	Off → On	Error
				On → Off	Normal
—	1, C	External Input and Output PCB	CN311	Off → On	Error
				On → Off	Normal
—	D	External Input and Output PCB	CN312	Off → On	Error
				On → Off	Normal


The output is on when an error is generated for the indoor unit.



Indoor unit fan operation status

Function setting	External Input and Output PCB	External output		Output signal	Status
	Rotary switch				
60-10	C	Output of indoor unit	CN47	Off → On	Fan run
				On → Off	Fan stop
—	2, 3, 7, 8, B, D	External Input and Output PCB	CN311	Off → On	Fan run
				On → Off	Fan stop
—	1	External Input and Output PCB	CN312	Off → On	Fan run
				On → Off	Fan stop

Output signal	Condition
On	The indoor unit fan is operating.
Off	The fan is stopped or during cold air prevention. During thermostat off when in dry mode operation.



■ External heater output


Control	Primary heater	Auxiliary heater	Function setting
			Indoor unit
			Control switching external heaters No. 61
Auxiliary heater control 1	Heat pump	External device*	61-00
Auxiliary heater control 2	Heat pump	External device	61-01
Heat pump prohibition control	External device	None	61-02
Auxiliary heater control by outdoor temperature 1	Heat pump	External device	61-03
Auxiliary heater control by outdoor temperature 2	Heat Pump	External device	61-04
Auxiliary heater control by outdoor temperature 3	Heat Pump	External device	61-05
Auxiliary heat pump control	External device	Heat pump	61-06
Auxiliary heat pump control by outdoor temperature 1	External device	Heat pump	61-07
Auxiliary heat pump control by outdoor temperature 2	External device	Heat pump	61-08
Auxiliary heat pump control by outdoor temperature 3	External device	Heat pump	61-09

NOTES:

- After turning off the heater, 3 minutes of standby time is required by next power-on of the heater.
- For items marked “—” in the table, any of validate or invalidate of the setting are acceptable.
- *: External device means Hot water, Electrical heater, etc.

● Installation configuration of individual connection

External heating device is installed individually. (No use of indoor unit fan)




⚠ WARNING

- Design and install an external heater appropriately, with consideration for its protection and local codes.
- Inappropriate designing and installation of external heater may cause a fire by emitted heat from the external heater.
- Fujitsu General Ltd. is not responsible for inappropriate designing or installation of external heating device.

● Auxiliary equipment control by room temperature

Auxiliary equipment control is switchable by room temperature. Auxiliary equipment switching is performed for each room temperature divided to following 3 zones.



Zone	Application	When temperature dropping		When temperature rising	
		Primary	Auxiliary	Primary	Auxiliary
A	Both of primary and auxiliary equipment is unnecessary.	Off	Off	Off	Off
B	Primary heater only. When room temperature stays in zone B for a long time, auxiliary equipment also operates.	On	Off* ¹	—	—
C	Auxiliary equipment also operates.	On	On* ²	On	On* ²

*1: For standby time for auxiliary equipment operation, refer to indoor unit function number 71 "[Contents of function setting](#)" on page 05-2.


*2: When indoor unit function number 61 is set to "00", auxiliary equipment operates according to the following conditions.

- $T_s - T_r > 21.6^{\circ}\text{F}$ (-12.0°C): Auxiliary equipment turn off.
- $T_s - T_r > 18.0^{\circ}\text{F}$ (-10.0°C): Auxiliary equipment turn on.

● Auxiliary heater control 1

Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off Fan stop protection

- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".



Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature


Example: When set temperature (Ts) is 72°F (22°C) (Factory setting),

- and room temperature (Tr) increases above 53.6°F (12°C), signal output is on.
- and room temperature (Tr) increases above 69.8°F (21°C), signal output is off.
- and room temperature (Tr) decreases below 66.2°F (19°C), signal output is on.
- and room temperature (Tr) decreases below 50°F (10°C), signal output is off.

● Auxiliary heater control 2

Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off Fan stop protection

- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".




Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature

● Heat pump prohibition control


Perform heating by external heater only. Indoor unit is continuous thermostat off.

Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off

- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".



• Operation status



NOTE: In following operations, compressor will be on.

- Other than heating
- Test run


● Auxiliary heater control by outdoor temperature 1

This control selects heat pump or external heater according to the outdoor temperature. When outdoor temperature is high, the heating is performed by using heat pump only.

Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off Heat pump only zone


- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".
- Outdoor temperature zone boundary A and B: Adjustable individually by function setting number 66 and 67.

• External heater output




Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature

• Outdoor temperature zone



*: Adjustable by function setting 66 and 67

- Operation status



* The outdoor temperature zone transition from one to another will stay in that zone for minimum of 30 min.

NOTE: In following operations, compressor will be on in heat pump prohibition zone.

- Other than heating
- Test run


● Auxiliary heater control by outdoor temperature 2

This control selects heat pump or external heater according to the outdoor temperature. Even when outdoor temperature is high, the heating is performed by using both of heat pump and external heater.

Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off


- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting “Thon”.
- Outdoor temperature zone boundary A: Adjustable by function setting number 66.

• External heater output




Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature

• Outdoor temperature zone



*: Adjustable by function setting 66

- Operation status



* The outdoor temperature zone transition from one to another will stay in that zone for minimum of 30 min.

NOTE: In following operations, compressor will be on in heat pump prohibition zone.

- Other than heating
- Test run


● Auxiliary heater control by outdoor temperature 3

This control selects heat pump or external heater according to the outdoor temperature. Even when outdoor temperature is high, the heating is performed by using both of heat pump and external heater.

Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off


- Temperature of heater on (Thon): Adjustable by function number 62 (Operating temperature switching of external heaters).
- All control temperatures will shift by adjusting "Thon".
- Outdoor temperature zone boundary B: Adjustable by function setting number 37.

• External heater output




Tr: Room temperature
Ts: Set temperature
Thon: Heater on temperature

• Outdoor temperature zone



*: Adjustable by function setting 67

• Operation status



* The outdoor temperature zone transition from one to another will stay in that zone for minimum of 30 min.

NOTE: In following operations, compressor will be on in heat pump prohibition zone.


- Other than heating
- Test run

● Auxiliary heat pump control

• External heater output


Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off

- Temperature of heater on (Thon): Set temperature (Ts) -0.9°F (-0.5°C)
- Temperature of heater off: Set temperature (Ts) +0.9°F (+0.5°C)



• Auxiliary heat pump On/Off

- Temperature of heat pump on (Thon): Adjustable by function number 62 (Operating temperature switching of heat pump).
- All control temperatures will shift by adjusting “Thon”.




● Auxiliary heat pump control by outdoor temperature 1

• External heater output


Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off

- Temperature of heater on (Thon): Set temperature (Ts) -0.9°F (-0.5°C)
- Temperature of heater off: Set temperature (Ts) +0.9°F (+0.5°C)




• Auxiliary heat pump On/Off

- Temperature of heat pump on (Thon): Adjustable by function number 62 (Operating temperature switching of heat pump).
- All control temperatures will shift by adjusting “Thon”.




• Outdoor temperature zone



*: Adjustable by function setting 66

- Operation status



* The outdoor temperature zone transition from one to another will stay in that zone for minimum of 30 min.

NOTE: In following operations, compressor will be on in heat pump prohibition zone.


- Other than heating
- Test run

● Auxiliary heat pump control by outdoor temperature 2

• External heater output


Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off

- Temperature of heater on (Thon): Set temperature (Ts) -0.9°F (-0.5°C)
- Temperature of heater off: Set temperature (Ts) +0.9°F (+0.5°C)




• Auxiliary heat pump On/Off

- Temperature of heat pump on (Thon): Adjustable by function number 62 (Operating temperature switching of heat pump).
- All control temperatures will shift by adjusting “Thon”.




• Outdoor temperature zone



*: Adjustable by function setting 67

- Operation status



* The outdoor temperature zone transition from one to another will stay in that zone for minimum of 30 min.

NOTE: In following operations, compressor will be on in heat pump prohibition zone.


- Other than heating
- Test run

● Auxiliary heat pump control by outdoor temperature 3

• External heater output


Operation	Condition
Heater on	Heater is on as shown in following diagram of heating temperature.
Heater off	<ul style="list-style-type: none"> Heater is off as shown in following diagram of heating temperature. Other than heating mode Error occurred Forced thermostat off

- Temperature of heater on (Thon): Set temperature (Ts) -0.9°F (-0.5°C)
- Temperature of heater off: Set temperature (Ts) +0.9°F (+0.5°C)




• Auxiliary heat pump On/Off

- Temperature of heat pump on (Thon): Adjustable by function number 62 (Operating temperature switching of heat pump).
- All control temperatures will shift by adjusting “Thon”.




*: When room temperature stays in this zone for a specific time, auxiliary heater is turned on. For details, refer to function number 71.

• Outdoor temperature zone



*: Adjustable by function setting 66 and 67

• Operation status



* The outdoor temperature zone transition from one to another will stay in that zone for minimum of 30 min.

NOTE: In following operations, compressor will be on in heat pump prohibition zone.

- Other than heating
- Test run


■ Setpoint attainment status (For 18-36 model)

NOTE: This function is valid only when function setting 96 is "Enable" (01).

When the room temperature does not reach the setpoint at a room due to the lower cooling performance caused by external factor such as the outdoor temperature change, signal is output to tell the attainment status of setpoint.

Function setting	External Input and Output PCB	External output		Output signal	Command
	Rotary switch				
60-12	D	Output of indoor unit	CN47	On → Off	Normal
				Off → On	Setpoint attainment

Output signal	Condition
Off	Reached the setpoint. ($T_r \leq T_{sa} + 1^\circ\text{F}$ [0.5°C])
On	Unreached the setpoint. ($T_r > T_{sa} + 5^\circ\text{F}$ [2.5°C]) However, even if the setpoint unreached, the signal will not be output for 7 minutes after power is turned on.




*: When starting operation or resetting, judges the zone to descending direction.

■ Heating thermostat on for humidifier

Situation	Indoor unit				
	Mode	Function setting	Rotary SW	External output	
		Heating thermostat on no. 60		Heating thermostat on	Indoor unit fan operation status
Example of individual connection	5	60-05	7	CN47	Not used
	6	60-06	8	CN312	
	7	60-07	9	CN311	
	8	60-08	A	CN310	


• Example of individual connection



• Operation status

The heating thermostat output for CNB01 (1-2 or 1-3 or 1- or 1-5) will be on when comp on or external heater on.

The heating thermostat output will be off when comp off and external heater off.



4. External input and output (for 30–36 outdoor units)

With using external input and output functions, this product can be operated inter-connectedly with an external device.

Connector	Input	Output	Remarks
P580	Low noise mode	—	See external input/output settings for details.
PA580	Peak cut mode	—	
P590	—	Error status	
PA590	—	Compressor status	

4-1. External input

With using external input function, on/off status of “Low noise mode” and “Peak cut mode” can be specified by the external signal.


■ Low noise mode

In following condition, the operating noise of the outdoor unit reduces comparing from the one in normal operating condition:


The air conditioner is set to the “Low noise mode” when closing the contact input of a commercial timer or on/off switch to a connector on the control PCB of the outdoor unit.

NOTE: Product performance may drop depending on some conditions such as the outdoor temperature.

• Circuit diagram example



- Contact capacity: DC 24 V or more, 10 mA or more.
- *: Make the distance from the PCB to the connected unit within 33 ft (10 m).
- Construct a circuit as shown in this figure with using optional parts mentioned below.
- Input signal: On in “Low noise mode”
- Input signal: Off in normal operation
- To set the level of “Low noise mode,” refer to **“Low noise mode”** on page 05-13 (under “Local setting procedure”).




• Optional part

Part name	Model name	Exterior
External Connect Kit	UTY-XWZXZ3	External input wire


■ Peak cut mode

By performing following on-site work, operation that suppresses the current value can be enabled: The air conditioner is set to the “Peak cut mode” when closing the contact input of a commercial timer or on/off switch to a connector on the control PCB of the outdoor unit.

• Circuit diagram example



- Contact capacity: DC 24 V or more, 10 mA or more.
- *: Make the distance from the PCB to the connected unit within 33 ft (10 m).
- Construct a circuit as shown in this figure with using optional parts mentioned below.
- Input signal: On in “Peak cut mode”
- Input signal: Off in normal operation
- To set the level of “Peak cut mode,” refer to **“Peak cut mode”** on page 05-14 (under “Local setting procedure”).



• Optional part

Part name	Model name	Exterior
External Connect Kit	UTY-XWZXZ3	External input wire


4-2. External output

With using external output function, some status signals are transmitted to the control PCB, and the related LED lamp indicates the status of this product.


■ Error status output

Signal on air conditioner error status is generated when a malfunction occurs.


• Circuit diagram example



- Output voltage (Vcc): DC 12 V 50 mA or less
- *: Make the distance from the PCB to the connected unit within 33 ft (10 m).




• Optional part

Part name	Model name	Exterior
External Connect Kit	UTY-XWZXZ3	External output wire 


■ Compressor status output

Signal on compressor operation status is generated when the compressor is running.

• Circuit diagram example



- Output voltage (Vcc): DC 12 V 50 mA or less
- *: Make the distance from the PCB to the connected unit within 33 ft (10 m).



• Optional part

Part name	Model name	Exterior
External Connect Kit	UTY-XWZXZ3	External output wire

