

jaga CLIMATE DESIGNERS

BRIZA 22 - HYBRID BUILT-IN HIGH-PERFORMANCE

INSTALLATION MANUAL: WALL- AND CEILING MODEL




TABLE OF CONTENTS

1. USED SYMBOLS.....	3
2. WARNINGS AND SAFETY	4
3. PACKAGING AND COMPONENTS.....	4
4. INSTALLATION	4
5. GENERAL INFORMATION	5
6. PRODUCT DESCRIPTION	6
7. TECHNICAL DATA WALL MOUNTING	7
8. TECHNICAL DATA CEILING MOUNTING	10
9. OPERATING LIMITS	12
10. INSTALLATION	13
11. START UP.....	17
12. MAINTENANCE.....	18
13. WARRANTY	19
14. DISSASSEMBLY INSTRUCTIONS	19

DECLARATION OF CONFORMITY

CEO JAGA N.V.
Jan Kriekels



26/03/2018

JAGA N.V. - Verbindingslaan 16 - B 3590, declares under its sole responsibility that the product to which this declaration relates: **BRIZA 12, BRIZA 22** is in conformity with the following standards or documents provided that these are used in accordance with our instructions: **NBN EN 60335-1 BASED ON EN60335-1:2012 + A11:2014 / NBN EN 60335-2-80 BASED ON EN 60335-2-80:2003 + A1:2004 + A2:2009**

Following the provision of Directives as amended:

- Low Voltage 2014/35/EC
- EMC 2014/30/EC
- Machinery 2006/42/EC



1. USED SYMBOLS



the DANGER sign warns the operator and maintenance staff about risks that may cause death, physical injury or illnesses of any kind.



DANGER: ELECTRICAL HAZARD



DANGER: SHARP EDGES



DANGER: HOT SURFACES



DANGER: MOVING PARTS



ATTENTION: IMPORTANT WARNING



the ENVIROMENTAL SAFEGUARD sign provides instructions on how to use the unit in an ECO-friendly manner.



Important info

The unit must be installed by a certified installer in accordance with the installation instructions and the local building codes. Please follow this instruction manual and file it somewhere safe! The unit must always be accessible for maintenance and inspection.

The warranty is void when:

- the installation, maintenance or operation instructions in this manual are not respected.
- modifications have been made to the product, before, during or after product installation.
- maintenance has been carried out by unauthorized people.
- maintenance has been carried out by someone other than Jaga.
- access to the unit has been restricted due to on-site conditions.
- the initial start-up has been carried out before a general cleaning of both the fan and the coil.

2. WARNINGS AND SAFETY

Handling guidelines:

The unit must be handled with care in order to avoid damage to the unit's interior and exterior parts. The unit might have sharp edges; use gloves during installation/adjustment. All the operations listed below must be carried out in accordance with local health and safety regulations.

Storage conditions:

Up to four packaged units may be stacked on top of each other. All units must be stored in a dry area.

Technical spaces and positioning:



Incorrect installation of the unit may cause noise and vibrations issues.

3. PACKAGING AND COMPONENTS

Follow these instructions when removing the packaging:

- check for any visible damage
- open the packaging
- check if the manual is in the package
- remove the packaging material and put it in the appropriate collection point or recycling facility, in compliance with the local regulations.



Dispose of the packaging materials in compliance with the national or local regulations.



Do not leave the packaging within reach of children.

4. INSTALLATION

- installation must be carried out by certified technicians. Incorrect installation could cause product failure, a reduced performance or an increased noise level.
- the unit must be installed in accordance with the local building codes.
- Always use personal protective equipment.
- the unit must remain accessible for inspection and maintenance, the trench must be removable at all times.

4.1. ACOUSTIC INSULATION

Sound absorption

Sound is reflected by hard materials. Soft, porous materials are best suited for sound absorption. A combination of different materials can reduce the reflection of sound.

Contact noise insulation

Sound travels very easily through hard materials. Soft rubber material can be used to reduce contact noise. The effect of this insulation strongly depends on:

- installation method: make sure that vibrations cannot be transferred between different elements, e.g. between the built-in heaters and other metallic parts, through pipes, along air ducts etc.
- installation of acoustic insulation in hollow acoustic spaces. Avoid cavities between insulation and pipes.

5. GENERAL INFORMATION



DANGER!

The unit is not intended for industrial applications.

Do not insert objects into the supply and return air openings.



IMPORTANT!

- the unit will only function correctly if the installation and operation manual is strictly followed.
- all clearances indicated in the manual must be respected in order to guarantee performance, and to allow installation and maintenance.
- in case valve packages are to be installed, make sure that there is enough room left.
- periodic access to the unit is required for inspection, maintenance and repairs.
- pay attention to the signs and symbols indicated on the fan coil units.

Unit identification:

The serial number is tagged on unit's right side (on the left if the connections are on the unit's right side).

Information regarding unintended use:

The unit has been designed to function as a fan coil for both heating and cooling applications; any other use is strictly forbidden. Installing the unit in an explosive environment is prohibited.

Decommissioning:

When the unit is not used for long periods of time, it must be disconnected from the mains electrical connection.

If the unit is not used during the winter period, the water in the system may freeze. A suitable quantity of anti-freeze liquid should be mixed with the water.



Mixing the water with glycol modifies the unit's performance. Pay attention to the safety instructions on the packaging regarding glycol.

Restart after prolonged shutdown:

Before restarting:

- clean or replace the stainless steel fan guard.
- clean the coil.
- clean or unclog the condensate drain.
- bleed the air from the hydronic system.
- it is advisable to run the unit at maximum speed and to check for abnormalities.


Operational limits:

An installation that does not meet the specified operational limits releases Jaga NV from all liability with respect to damage to objects or people.


- mains voltage: 208V - 1 ph - 60Hz
- maximum water inlet temperature: 90°C
- maximum exchanger pressure: 20 bar
- supply voltage: 208V $\pm 10\%$

6. PRODUCT DESCRIPTION

6.1. WALL - OVERVIEW PARTS




6.2. CEILING - OVERVIEW PARTS



7. TECHNICAL DATA - WALL MOUNTING

7.1. GENERAL DIMENSIONS




*: mounting position


MODEL	03	04	06	08	10
L (INCH)	29 17/32	37 13/32	49 7/32	61 1/32	74 5/16
I (INCH)	27 5/16	35 7/16	47 1/4	59 1/16	72 5/16
WEIGHT (LBS)	47.4	59.5	78.3	97	121

7.2. BUILT-IN DIMENSIONS


Briza 22 BT - 'Bottom top grill'




Briza 22 bf - 'bottom front grill'




Briza 22 ff - 'Front top grill'




Briza 22 ff - 'Front front grill'



7.3. DIMENSIONS: MAINTENANCE OPENING







Briza 22 BT - 'bottom top grill' / briza 22 BF - 'bottom front grill'







Briza 22 BT - 'bottom top grill' / briza 22 BF - 'bottom front grill'

7.4. DIMENSIONS: HYDRAULIC CONNECTION AND CONDENSATE DRAIN

7.4.1. 2-pipe connection




7.4.2. 4-pipe connection




8. TECHNICAL DATA - CEILING MOUNTING

8.1. GENERAL DIMENSIONS




MODEL	03	04	06	08	10
L (INCH)	29 $\frac{1}{32}$	37 $\frac{1}{32}$	49 $\frac{3}{32}$	61 $\frac{1}{32}$	74 $\frac{5}{64}$
WEIGHT (LBS)	47.4	59.5	78.3	97	121


8.2. BUILT-IN DIMENSIONS



8.3. DIMENSIONS: MAINTENANCE OPENING






Briza 22 BT - 'Bottom top grill'







Briza 22 FT - 'Front top grill'

8.4. DIMENSIONS: HYDRAULIC CONNECTION AND CONDENSATE DRAIN

8.4.1. 2-pipe connection



8.4.2. 4-pipe connection



10. OPERATING LIMITS

If the appliance is supplied with chilled water, the condensation forming on the heat exchanger will be drained via the condensation drain connection.

At very low chilled water temperature and very high humidity, condensation may form on components other than the heat exchanger. This is not collected in the condensation drain, but might drip from under the appliance.





To avoid this, a minimum permitted water temperature must be taken into account in function of the relative humidity and temperature of the ambient air.



10.1. PERMITTED MINIMUM WATER TEMPERATURE (°C)

		AMBIENT TEMPERATURE / DRY BULB TEMPERATURE (°F)					
		69.8 °F	73.4 °F	77 °F	80.6 °F	84.2 °F	87.8 °C
RH (%)	40 %	37.4 °F	37.4 °F	37.4 °F	37.4 °F	37.4 °F	39.2 °F
	50 %	37.4 °F	37.4 °F	37.4 °F	37.4 °F	39.2 °F	42.8 °F
	60 %	37.4 °F	37.4 °F	39.2 °F	39.2 °F	42.8 °F	46.4 °F
	70 %	37.4 °F	39.2 °F	41 °F	42.8 °F	46.4 °F	50 °F
	80 %	39.2 °F	41 °F	42.8 °F	46.4 °F	50 °F	/
	90 %	41 °F	42.8 °F	46.4 °F	50 °F	/	/
	100 %	42.8 °F	46.4 °F	50 °F	/	/	/

Permitted minimum water temperature

9. INSTALLATION

-  For general safety information see: warnings and safety - page 61
-  Always use the main switch to de-energize the power supply !
-  **ATTENTION!** The device must remain accessible at all times for maintenance. in the case of Bottom or ceiling installation, the enclosure must always be disassembled for service purposes.
-  The unit has sharp edges; always wear gloves.





Mark the fastening points, using those on the unit or according to the dimensions specified on page 8 and 10 in this manual. Slightly tilt towards the condensate drain to help the water drain. Respect the free space around the unit as shown on page 7-11. The type of wall/ceiling determines what type of screw or plug should be used. For installation on drybottom: make sure that the holes line up with supporting studs.



10.2. HYDRAULIC CONNECTION



It is very important for the water connections to be installed with care by qualified personnel.




Connect the unit to the hydraulic system with the indicated inlet/outlet connections. Make sure the connections are air tight with a sealant. All heat exchangers (including the additional one) are equipped with an air vent near the top connection and a water drain near the lower connection.



Coils can be partially drained; it is recommended to bleed air inside the coil to be drained completely.

Setting up the condensate drain:

The condensation drainage system must be set up with an adequate inclination to make sure the water drains properly.



The condensate drain system must be set up with an adequate p-trap in order to prevent the infiltration of odours. Always install a plug for cleaning in the lower part of the p-trap in order to allow quick disassembly. Position the drain pipes without mechanical stress on the drain connection of the unit.

10.3. ELECTRICAL CONNECTION - GENERAL




IMPORTANT!

The electrical connection of the unit must be carried out by qualified personnel, in compliance with the regulations applicable in the country where the unit is installed. Non-conforming electrical connections releases Jaga N.V. from liability concerning damage to objects and persons.




DANGER!

- Always install a general automatic switch in a protected area near the unit, which has a characteristic delayed curve, sufficient capacity and breaking power. There must be a minimum distance of 3 mm between the contacts.
- Earth connection is compulsory by law to ensure user safety while the unit is in use.
- Check that the voltage and the frequency of the electrical system correspond to 208V ($\pm 10\%$) single phase at 60Hz; that the available installed power is sufficient for running the equipment and that the supply cables are of adequate section for the maximum current required.
- Make sure the electrical supply system complies with current National safety regulations.
- The connections must be implemented in accordance with the diagrams supplied with the unit.
Use an H05RN-F type, flexible, double insulated, bipolar + earth cable with a 1.5 mm² section to connect the unit to the mains.
- If the unit is mounted on a metal surface, the earth connection must be installed in compliance with local regulations. The earth conductor must be longer than the other conductors so that it is the last one to release in the event the connection comes loose.





10.4. FILTER REPLACEMENT


MODEL	03	04	06	08	10
CODE	8721.402	8721.403	8721.404	8721.405	8721.406




Remove the screw and open the locks on the side of the device.




Take the filter out of the unit.



Place a the new filter in the unit.



Relock the filter by turning the locks and replace the screw.



11. INITIAL START



IMPORTANT!

Start-up and Commissioning of the fancoil must be carried out by skilled staff, qualified to work on this type of product.



DANGER!

Before start-up, make sure the installation has been carried out in compliance with in this manual.

Before start-up the fancoil unit, check if:

1. the unit is positioned correctly
2. the supply and return pipes are properly connected and insulated
3. the pipes are clean and air is removed
4. the inclination of the unit towards the drain and the p-trap are correct
5. the coils are clean
6. the wiring connections are correct and properly tightened
7. the supply voltage is correct
8. the electric power consumption is correct and does not exceed the maximum value indicated in the catalog

Run the fan for minimal 3 hours and check for abnormalities.

12. MAINTENANCE



DANGER!

- maintenance must be carried out by qualified technicians.
- do not insert sharp objects into the supply and return grilles
- the unit has sharp edges; use gloves during maintenance!



DANGER!

Always use the main disconnect switch to isolate the unit from the mains before carrying out any maintenance or inspection work. Make sure that no one accidentally turns on the power to the unit; lock the master switch in the off position.

12.1. SPECIAL NOTE

Maintenance and cleaning of the stainless steel protection grille:

a dirty grille obstructs the air flow, so clean the grille at regular intervals, depending on the room's purpose and how it's used. The grille should never be disassembled for maintenance and can be easily cleaned by using a vacuum cleaner.

Cleaning the unit:

always disconnect the power supply before servicing the fan!!

- cleaning at regular intervals is important, depending on the room's purpose and how it's used
- clean with a vacuum cleaner or air compressor. Do not use solvent- or detergent based products.

12.2. ROUTINE MAINTENANCE

Every 6 months: Check the condition of the coil and condensate drain:

If necessary:

- remove any dirt from the coil surface
- remove dust using an air compressor
- wash with water and brush gently
- dry by using compressed air
- keep the condensate drain free from any obstructions that may prevent normal water flow

Bleed air from the system.

1. start the circulation pump and open the supply valve for a few minutes.
2. stop the circulation pump.
3. loosen the vent screw on the inlet collector and bleed the air.
4. repeat steps 1 to 3 until there is no more air escaping the system

12.3. ELECTRICAL CIRCUIT

The following steps are recommended to perform maintenance on the electrical circuit:

- check the unit's power consumption using a clip-on meter and compare the reading with the values shown in the documentation;
- inspect the electrical contacts for corrosion and loose wires.

13. WARRANTY

The fan coil unit is intended strictly for conditioning the indoor climate. Any unintended use is strictly forbidden and voids all warranty on the product. Installation, maintenance and operation of the unit is only allowed for authorized staff.

Please follow these instructions carefully

The warranty is void when:

- the installation procedure has not been followed,
- the fan coil has not been periodically cleaned,
- the unit has been used in an improper or irresponsible manner,
- repairs have been carried out by others than Jaga,
- product modifications have been carried out by others, before or after the installation,
- the product is not accessible for cleaning or maintenance.

If you have any questions or complaints, please contact your supplier or installer. The copyright of these instructions is the property of Jaga.

14. DISSASSEMBLY INSTRUCTIONS



SAFEGUARD THE ENVIROMENT

Jaga cares about protecting the environment.

When the unit is dismantled it is important to strictly follow these procedures:

- the unit must be dismantled by a firm that is authorized to dispose of scrap machinery/products

The unit as a whole is composed of secondary raw materials and the following conditions must be met:

- if the unit contains antifreeze, then dispose of the antifreeze as indicated in the glycol supplier's instructions.
- the electronic components are considered special waste, and must be recycled as such
- the pipe insulation and the sound-absorbing lining must be removed and processed as urban waste

Please follow and file these instructions!

NOTES

[illegible]

Jaga Canada Climate Systems
www.jaga-canada.com

april 1, 2020 11:21 a.m. - Jaga Inc.