




BOSCH

Installation Instructions

Split System Heat Pump

Bosch IDS BOVA15

IDS Light Condensing Units | 2-5 Ton Capacity | R410A



BTC 761701317 B / 07.2022



Table of Contents

| | | | |
|---|-----------|--|-----------|
| 1 Key to Symbols and Safety Instructions | 4 | 12 Electrical - High Voltage | 17 |
| 1.1 Key to Symbols | 4 | 12.1 High Voltage Power Supply | 17 |
| 1.2 Safety | 4 | 12.2 High Voltage Disconnect Switch | 17 |
| 2 Unit Location Considerations | 6 | 12.3 High Voltage Ground | 17 |
| 2.1 Unit Dimensions | 6 | 13 Start Up | 18 |
| 2.2 Refrigerant Piping Limits | 6 | 13.1 System Start Up | 18 |
| 2.3 Location Restrictions | 7 | 14 System Charge Adjustment | 19 |
| 3 Unit Preparation | 8 | 14.1 Charging: Weigh-In Method | 19 |
| 3.1 Prepare the Unit for Installation | 8 | 14.2 Subcooling Charging And Refrigerant Adjustment In Cooling (Above 55°F Outdoor Temp.) | 19 |
| 4 Setting the Unit | 8 | 15 System Operation and Troubleshooting | 22 |
| 4.1 Pad Installation | 8 | 15.1 Control Logic Description | 22 |
| 5 Refrigerant Line Considerations | 9 | 15.2 Sensors (Thermistors/Pressure Transducer) | 22 |
| 5.1 Refrigerant Line and Service Valve Connection Sizes | 9 | 15.3 Pressure Equalizer Valve (PEV) | 22 |
| 5.2 Required Refrigerant Line Length | 9 | 15.4 Defrost Description | 22 |
| 5.3 Refrigerant Line Insulation | 9 | 15.5 Compressor Crankcase Heater Description | 23 |
| 5.4 Reuse Existing Refrigerant Lines | 9 | 15.6 Reversing Valve Operation | 23 |
| 6 Refrigerant Line Routing | 10 | 15.7 Protection Functions | 23 |
| 6.1 Precautions | 10 | 15.8 Fault Code Table | 24 |
| 7 Refrigerant Line Brazing | 11 | 15.9 Parameter Point Check Table | 25 |
| 7.1 Braze The Refrigerant Lines | 11 | 15.10 Control Board Overviews | 26 |
| 8 Refrigerant Line Leak Check | 13 | 15.11 Error Code Troubleshooting | 28 |
| 8.1 Check For Leaks | 13 | 15.12 Temperature and Resistance Relationship Tables (for Sensors) | 37 |
| 9 Evacuation | 13 | 15.13 Temperature and Resistance Relationship Tables (for T5 Sensor) | 38 |
| 9.1 Evacuate the Refrigerant Lines and Indoor Coil | 13 | 16 Wiring Diagram | 39 |
| 10 Service Valves | 14 | 16.1 BOVA24/36-15 (2/3 Ton) | 39 |
| 10.1 Open the Service Valves | 14 | 16.2 BOVA60-15 (4/5 Ton) | 40 |
| 11 Electrical - Low Voltage | 15 | 17 Care and Maintenance | 41 |
| 11.1 Low Voltage Maximum Wire Length | 15 | 17.1 Cleaning Precautions | 41 |
| 11.2 Low Voltage Hook-Up Diagrams | 15 | 17.2 Maintenance – Pre-Season Inspection | 41 |
| 11.3 Thermostat Wiring Diagrams | 15 | | |

1 Key to Symbols and Safety Instructions

1.1 Key to Symbols

Warnings



Warnings in this document are identified by a warning triangle printed against a grey background. Keywords at the start of a warning indicate the type and seriousness of the ensuing risk if measures to prevent the risk are not taken.

The following keywords are defined and can be used in this document:

- ▶ **DANGER** indicates a hazardous situation which, if not avoided, will result in death or serious injury.
- ▶ **WARNING** indicates a hazardous situation which, if not avoided, could result in death or serious injury.
- ▶ **CAUTION** indicates a hazardous situation which, if not avoided, could result in minor to moderate injury.
- ▶ **NOTICE** is used to address practices not related to personal injury.

Important information



This symbol indicates important information where there is no risk to people or property.

1.2 Safety

Please read before proceeding



WARNING: ELECTRICAL HAZARD 380 VOLTS DC

- ▶ Failure to follow this warning could result in property damage, severe personal injury, or death.
- ▶ WAIT THREE (3) MINUTES after disconnecting power prior to touching electrical components as they may hold a dangerous charge of 380 VDC, then verify DC Voltage is less than 42VDC at inverter TEST POINTS P-N.

NOTICE:

- ▶ This document is customer property and is to remain with this unit. Please return to service information pack upon completion of work.
- ▶ These instructions do not cover all variations in systems or provide for every possible contingency to be met in connection with the installation.
- ▶ Should further information be desired or should particular problems arise which are not covered sufficiently for the purchaser's purposes, the matter should be referred to your installing dealer or local distributor.



The manufacturer recommends installing only approved matched indoor and outdoor systems. All of the manufacturer's split systems are AHRI rated only with TXV indoor systems. Some of the benefits of installing approved matched indoor and outdoor split systems are maximum efficiency, optimum performance and the best overall system reliability.



This document contains a wiring diagram and service information. This is customer property and is to remain with this unit. Please return to service information pack upon completion of work.



WARNING:

- ▶ This information is intended for use by individuals possessing adequate backgrounds of electrical and mechanical experience. Any attempt to repair a central air conditioning product may result in personal injury and/or property damage.


WARNING: HAZARDOUS VOLTAGE

- ▶ Failure to follow this warning could result in property damage, severe personal injury, or death.
- ▶ Disconnect all electric power, including remote disconnects before servicing. Follow proper lockout/tagout procedures to ensure the power cannot be inadvertently energized.


CAUTION: GROUNDING REQUIRED

- ▶ Failure to inspect or use proper service tools may result in equipment damage or personal injury. Reconnect all grounding devices. All parts of this product that are capable of conducting electrical current are grounded. If grounding wires, screws, straps, clips, nuts, or washers used to complete a path to ground are removed for service, they must be returned to their original position and properly fastened.


WARNING: REFRIGERANT OIL

- ▶ Any attempt to repair a central air conditioning product may result in property damage, severe personal injury, or death. These units use R-410A refrigerant which operates at 50 to 70% higher pressures than R-22. Use only R-410A approved service equipment. Refrigerant cylinders are painted a "Rose" color to indicate the type of refrigerant and may contain a "dip" tube to allow for charging of liquid refrigerant into the system. All R-410A systems with variable speed compressors use a POE oil (VG74 or equivalent) that readily absorbs moisture from the atmosphere. To limit this "hygroscopic" action, the system should remain sealed whenever possible. If a system has been open to the atmosphere for more than 4 hours, the compressor oil must be replaced. Never break a vacuum with air and always change the driers when opening the system for component replacement.


WARNING: SERVICE VALVES

- ▶ Failure to follow this warning will result in abrupt release of system charge and may result in personal injury and/or property damage. Extreme caution should be exercised when opening the Liquid Line Service valve. Turn valve stem counterclockwise only until the stem contacts the rolled edge.


WARNING: BRAZING REQUIRED

- ▶ Failure to inspect lines or use proper service tools may result in equipment damage or personal injury. If using existing refrigerant lines make certain that all joints are brazed, not soldered.


WARNING: HOT SURFACE

- ▶ May cause minor to severe burning. Failure to follow this Caution could result in property damage or personal injury. Do not touch top of compressor.


WARNING: HIGH CURRENT LEAKAGE

- ▶ Failure to follow this warning could result in property damage, severe personal injury, or death. Grounding is essential before connecting electrical supply.


CAUTION: CONTAINS REFRIGERANT

- ▶ Failure to follow proper procedures can result in personal illness or injury or severe equipment damage. System contains oil and refrigerant under high pressure. Recover refrigerant to relieve pressure before opening system.


WARNING:

- ▶ This product can expose you to chemicals including Lead and Lead components, which are known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.


CAUTION: INDOOR UNIT REQUIRED

- ▶ The indoor units must be matched with TXV. The model of TXV can be changed according to the system capacity.

2 Unit Location Considerations

2.1 Unit Dimensions

| Models | H x W x L (inches) |
|-----------|---------------------------|
| BOVA24-15 | 24-15/16 x 28 x 28 |
| BOVA36-15 | 24-15/16 x 28 x 28 |
| BOVA60-15 | 33-3/16 x 29-1/8 x 29-1/8 |

Table 1

The unit's weight values are on the carton box.

When mounting the outdoor unit on a roof, be sure the roof will support the unit's weight. Properly selected isolation is recommended to prevent sound or vibration transmission to the building structure.




Figure 1

2.2 Refrigerant Piping Limits

| System Capacity Model | Liquid Line | Suction Line | Total Equivalent Length - Feet | | | |
|-----------------------|-------------|--------------|------------------------------------|----|-----|-----|
| | | | 25 | 50 | 75 | 100 |
| | Inch O.D. | | Maximum Vertical Separation - Feet | | | |
| 24K | 3/8 * | 3/4 Std. | 25 | 50 | 45 | 40 |
| | | 5/8 Opt. | 25 | 50 | 45 | 40 |
| 36K | 3/8 * | 3/4 Std. | 25 | 50 | 50 | 50 |
| | | 5/8 Opt. | 25 | 50 | 50 | 50 |
| 48K | 3/8 * | 7/8 Std. | 25 | 50 | 50 | 40 |
| | | 3/4 Opt. | 25 | 50 | 50 | 40 |
| 60K | 3/8 * | 7/8 Std. | 25 | 50 | 50 | 40 |
| | | 3/4 Opt. | 25 | 50 | 50 | 40 |
| | | 1 1/8 Opt. | 25 | 40 | N/A | N/A |

Table 2

* Standard line size is recommended;
N/A: Application not recommended;
Refrigerant charge: refer to Sec. 14

- ▶ Maximum line equivalent length = 100 feet.
- ▶ Maximum vertical equivalent length = 50 feet.
- ▶ Use only the line diameters indicated in Table 2.
- ▶ If the suction linesets are greater than 50 feet, do not use a larger suction line than recommended.




Figure 2

2.3 Location Restrictions

Ensure the top discharge area is unrestricted for at least 60 inches above the unit.

Do not locate outdoor unit near bedrooms since normal operational sounds may be objectionable.

Position unit to allow adequate space for unobstructed airflow, wiring, refrigerant lines, and serviceability.

Allow a minimum of 12 in. clearance on one side of control board access panel to a wall and a minimum of 24 in. on the adjacent side of control board access panel.

Maintain a distance of 24 in. between units.

Position unit where water, snow, or ice from roof or overhang cannot fall directly on unit.

See Fig. 3 and Fig. 4.




Figure 3




Figure 4

Cold climate considerations (heat pump only)



Precautions must be taken for units being installed in areas where snow accumulation and prolonged below-freezing temperatures occur.

- ▶ Units should be elevated 3-12 inches above the pad or rooftop, depending on local weather. This additional height will allow drainage of snow and ice melted during defrost cycle prior to its refreezing. Ensure that drain holes in unit base pan are not obstructed, which could prevent the drainage of defrost water (Fig. 5).
- ▶ If possible, avoid locations that are prone to snow drifts. If not possible, a snow drift barrier should be installed around the unit to prevent a build-up of snow on the sides of the unit.




Figure 5

Corrosive Environment

Exposure to a corrosive environment may shorten the life of the equipment, corrode metal parts, and/or negatively affect unit performance. Corrosive elements include, but are not limited to: sodium chloride, sodium hydroxide, sodium sulfate, and other compounds commonly found in ocean water, sulfur, chlorine, fluorine, fertilizers, and various chemical contaminants from industry/manufacturing plants. If installed in areas which may be exposed to corrosive environments, special attention should be given to the equipment placement and maintenance.

- ▶ Lawn sprinklers/hoses/waste water should not spray directly on the unit cabinet for prolonged periods of time.
- ▶ In coastal areas: locate the unit on the side of the building away from the waterfront.
- ▶ Fencing or shrubbery may provide some shielding protection to the unit, however minimum unit clearances must still be maintained.
- ▶ Approximately every three months, wash the outdoor coil and any exposed cabinet surfaces.

3 Unit Preparation

3.1 Prepare the Unit for Installation

- ▶ Check for damage and report promptly to the carrier any damage found to the unit (Fig. 6).
- ▶ The charge port can be used to ensure the refrigerant charge has been retained during shipment.




Figure 6

4 Setting the Unit

4.1 Pad Installation

When installing the unit on a support pad, such as a concrete slab, consider the following:

- ▶ The pad must be at least 1-2" larger than the unit on all sides.
- ▶ The pad must be separated from any structure.
- ▶ The pad must be level.
- ▶ The pad must be high enough above grade to allow for drainage.
- ▶ The pad location must comply with National, State, and local codes.



These instructions are intended to provide a method to tie-down system to cement slab as a securing procedure for high wind areas. Check local codes for tie-down methods and protocols.




Figure 7




Figure 8

5 Refrigerant Line Considerations

5.1 Refrigerant Line and Service Valve Connection Sizes

| Models | Suction Line | Liquid Line | Suction Line Connection | Liquid Line Connection |
|-----------|----------------------|-------------|-------------------------|------------------------|
| | Dimensions in inches | | | |
| BOVA24-15 | 3/4 | 3/8 | 3/4 | 3/8 |
| BOVA36-15 | 3/4 | 3/8 | 3/4 | 3/8 |
| BOVA60-15 | 7/8 | 3/8 | 7/8 | 3/8 |

Table 3

5.2 Required Refrigerant Line Length

Determine required line length (Fig. 9). Refer to Section 2.2.




Figure 9

5.3 Refrigerant Line Insulation

i The Suction Line must always be insulated. DO NOT allow the Liquid Line and Suction Line to come in direct (metal to metal) contact.




Figure 10

5.4 Reuse Existing Refrigerant Lines



CAUTION: MINOR TO MODERATE BURNS

- ▶ If using existing refrigerant lines, make certain that all joints are brazed, not soldered.

For retrofit applications, where the existing refrigerant lines will be used, the following precautions should be taken:

- ▶ Ensure that the refrigerant lines are the correct size. Refer to Section 2.2 and Table 2.
- ▶ Ensure that the refrigerant lines are free of leaks, acid, and oil.



The manufacturer recommends installing only approved matched indoor and outdoor systems. All of the manufacturer's split systems are AHRI rated only with TXV indoor systems. The benefits of installing approved matched indoor and outdoor split systems are maximum efficiency, optimum performance and the best overall system reliability.

6 Refrigerant Line Routing

6.1 Precautions



Comply with National, State, and local codes when isolating linesets from joists, rafters, walls, or other structural elements.



Take precautions to prevent noise within the building structure due to vibration transmission from the refrigerant lines. For example:

- ▶ When the refrigerant lines have to be fastened to floor joists or other framing in a structure, use isolation type hangers.
- ▶ Isolation hangers should also be used when refrigerant lines are run in stud spaces or enclosed ceilings.
- ▶ Where the refrigerant lines run through a wall or sill, they should be insulated and isolated.
- ▶ Isolate the lines from all ductwork.
- ▶ Minimize the number of 90° turns.




Figure 11




Figure 12




Figure 13

7 Refrigerant Line Brazing

7.1 Braze The Refrigerant Lines

1. Remove caps or plugs. Use a deburring tool to deburr the pipe ends. Clean both internal and external surfaces of the tubing using an emery cloth.




Figure 14

2. Remove the pressure tap cap from both service valves.




Figure 15

3. Purge the refrigerant lines and indoor coil with dry nitrogen.




Figure 16

4. Wrap a wet rag around the valve body to avoid heat damage and continue the dry nitrogen purge (Fig. 17).

Braze the refrigerant lines to the service valves.

Braze the filter drier to the Liquid Line.




Figure 17

5. Replace the pressure tap caps after the service valves have cooled.




Figure 18

i All units come standard with a bi-flow filter drier. Braze the filter drier to the liquid line, using caution not to push the refrigerant line too hard past the stop within the filter drier (this could damage the drier).

Continue the dry nitrogen purge. Do not remove the wet rag until all brazing is completed.

i Remove the wet rag before stopping the dry nitrogen purge.

8 Refrigerant Line Leak Check

8.1 Check For Leaks

1. Pressurize the refrigerant lines and evaporator coil to 150 PSIG using dry nitrogen.




Figure 19

2. Check for leaks by using a soapy solution or bubbles at each brazed location.




Figure 20

9 Evacuation

9.1 Evacuate the Refrigerant Lines and Indoor Coil



Do not open the service valves until the refrigerant lines and indoor coil leak check and evacuation are complete.

1. Evacuate until the micron gauge reads no higher than 350 microns, then close the valve to the vacuum pump.




Figure 21

2. Observe the micron gauge. Evacuation is complete if the micron gauge does not rise above 500 microns in one (1) minute.

Once evacuation is complete, turn off the vacuum pump and micron gauge, and close the valves on the manifold gauge set.




Figure 22

10 Service Valves

10.1 Open the Service Valves



WARNING: MODERATE TO SEVERE BURNS

- Extreme caution should be exercised when opening the Liquid Line Service Valve. Turn counterclockwise until the valve stem just touches the rolled edge. No torque is required. Failure to follow this warning will result in abrupt release of system charge and may result in personal injury and /or property damage.



Leak check and evacuation must be completed before opening the service valves. The brazed lineset valves should be used for leak checking and vacuuming. Using the separate suction port for this process will result in loss of charge.



The Suction Service Valve must be opened first BEFORE opening the Liquid Service Valve.




Figure 23

1. Remove Service Valve Cap (Fig. 23).
2. Fully insert hex wrench into the stem and back out counterclockwise until valve stem just touches the rolled edge (approximately five (5) turns.)
3. Replace the Valve Stem Cap to prevent leaks. Tighten finger tight plus an additional 1/6 turn.
4. Repeat STEPS 1 - 3 for Liquid Service Valve.

11 Electrical - Low Voltage

11.1 Low Voltage Maximum Wire Length

Table 4 defines the maximum total length of low voltage wiring from the outdoor unit, to the indoor unit, and to the thermostat.

| 24 Volts - Wire size | Max. Wire Length |
|----------------------|------------------|
| 18 AWG | 150 Ft. |
| 16 AWG | 225 Ft. |
| 14 AWG | 300 Ft. |

Table 4

11.2 Low Voltage Hook-Up Diagrams




Figure 24 Low Voltage Unit Connections

11.3 Thermostat Wiring Diagrams

- ▶ Be sure power supply agrees with equipment nameplate.
- ▶ Power wiring and grounding of equipment must comply with local codes.
- ▶ Low voltage wiring to be No. 18 AWG minimum conductor.
- ▶ "-----" Field installed electric auxiliary heat connection
- ▶ Single-stage auxiliary heating supported by 2H thermostat
- ▶ Twin-stage auxiliary heating supported by 3H thermostat
- ▶ W1: The first stage of field installed electric auxiliary heat.
- ▶ W2: The second stage of field installed electric auxiliary heat.
- ▶ The outdoor unit W signal is connected to the electric auxiliary heat or the first stage electric auxiliary heat.

i Dashed lines in the following thermostat wiring diagrams refer to optional wiring (wiring for Passive Dehumidification Function and/OR Electric Heat). For thermostat wiring please refer to the Owner's Manual of the thermostat.

i B terminal to be connected with thermostat (O/B) wiring. Reversing valve energizes in heating.

Figure 25

i Figures 25-30 refer to thermostat wiring diagrams for the BOVA15 and BVA15 manufacturer matched indoor and outdoor systems.




Figure 26 Thermostat Wiring Diagram for BOVA15/BVA15 Matched System

12 Electrical - High Voltage

12.1 High Voltage Power Supply



WARNING: LIVE ELECTRICAL COMPONENTS!

- ▶ During installation, testing, servicing, and trouble shooting of this product, it may be necessary to work with live electrical components. Failure to follow all electrical safety precautions when exposed to live electrical components could result in death or serious injury.

The high voltage power supply must match the equipment nameplate (208/230V, 1PH, 60Hz).



Power wiring must comply with national, state, and local codes.

Follow instructions on unit wiring diagram located on the inside of the control box access panel and refer to wiring diagram in this IOM.

12.2 High Voltage Disconnect Switch

Install a separate disconnect switch at the outdoor unit.

Field supplied flexible electrical conduit must be used for high voltage wiring.




Figure 27

12.3 High Voltage Ground

Ground the outdoor unit per national, state, and local code requirements.




Figure 28

13 Start Up

13.1 System Start Up

1. Ensure Sections 7, 8, 9, 10, 11, and 12 have been completed.
2. Set System Thermostat to OFF.



Figure 29

3. Turn on disconnect to apply power to the indoor and outdoor units.




Figure 30

4. Upon initial unit installation, wait one (1) hour before starting the unit if compressor crankcase heater is used and the outdoor ambient temperature is below 70 °F.



Figure 31

5. Set system thermostat to ON.



Figure 32

14 System Charge Adjustment


14.1 Charging: Weigh-In Method

Use weigh-in method the initial installation, or anytime a system charge is being replaced. Weigh-in method can also be used when power is not available to the equipment site or operating conditions (indoor/outdoor temperatures) are not in range to verify with the subcooling charging method.

| Model | Factory Charge | Charge multiplier for interconnecting refrigerant tube length |
|-----------|----------------|---|
| 2 Ton | 5 lbs 7 oz | 0.6 oz/ft |
| 3 Ton | 6 lbs 11 oz | 0.6 oz/ft |
| 4 & 5 Ton | 9 lbs 8 oz | 0.6 oz/ft |

Table 5

 Refer to Table 3 on Page 9 for Line Size considerations.

 The factory charge in the outdoor unit is sufficient for 15 feet of standard size interconnecting liquid line.

New Installations—Calculating additional charge for lineset greater than 15 ft.


1. Total Line Length (ft) = _____ (a)
2. Standard Lineset (ft) = 15 (b)
3. (a) minus (b) = _____ (c)
4. Refrigerant Multiplier = 0.6 oz/ft (d)
5. Refrigerant Adder (c*d) = _____ (e)*

*If lineset is less than 15 ft, (e) = 0

Sealed-System Repairs—Calculating total system charge.

1. Total Line Length (ft) = _____ (a)
2. Standard Lineset (ft) = 15 (b)
3. (a) minus (b) = _____ (c)
4. Refrigerant Multiplier = 0.6 oz/ft (d)
5. Refrigerant Adder (c*d) = _____ (e)*
6. Factory Charge (namplate) = _____ (f)
7. Total System Charge (e+f) = _____

*If lineset is less than 15 ft, (e) = 0


 The only mode approved for validating system charge is while in Cooling "Force Mode". Outdoor temperature must be between 55°F and 120°F with indoor temperature kept between 70°F and 80°F.

14.2 Subcooling Charging And Refrigerant Adjustment In Cooling (Above 55°F Outdoor Temp.)

1. Check the outdoor ambient temperatures.

Subcooling (**in cooling mode**) is the only recommended method of charging above 55°F outdoor ambient temperatures.

For outdoor ambient temperatures below 55°F use weigh-in charge method.

 It is important to return in the spring or summer to accurately charge the system in the cooling mode when outdoor ambient temperature is above 55°F.




Figure 33

For best results, the indoor temperature should be kept between 70°F and 80°F during the install.




Figure 34

2. Ensure Sections 7,8,9,10,11,12 and 13 have been completed.

3. Stabilize the system.

After **starting the system in cooling mode**, short press "FORCE" button, and "┐" symbol should appear. System may take 10 minutes to ramp up. Operate the system for a minimum of twenty (20) minutes.

i After a twenty (20) minute stabilization period operating at 100% capacity (i.e. once the compressor reaches the frequency shown in Table 6), maintain continuous operation while adjusting refrigerant charge. After adjusting, operate system for a minimum of five (5) minutes for system to stabilize, otherwise repeat step 3.

| Compressor Frequency in Force Mode in Cooling | | | | |
|---|------|------|------|------|
| ODU Capacity | 2TON | 3TON | 4TON | 5TON |
| Frequency (HZ) | 46 | 66 | 54 | 60 |

Table 6



Figure 35

4. Calculate superheat value (According to Table 7)

- ▶ Measured Suction Line Temp = _____ °F
- ▶ Measured Suction Line Pressure = _____ PSIG
- ▶ Calculate superheat value = _____ °F

i For indoor unit with adjustable TXV, set subcooling and adjust superheat via adjustable TXV according to Table 9. For indoor unit with non-adjustable TXV, check the superheat and set correct subcooling according to superheat, refer to Table 9.

5. Calculate subcooling value (According to Table 8)

- ▶ Measured Liquid Line Temp. = _____ °F
- ▶ Measured Liquid Line Pressure = _____ PSIG
- ▶ Calculate subcooling value = _____ °F




Figure 36

i If calculated subcooling value is lower than the design subcooling value (Table 9), please add refrigerant. Repeat steps 3 through 5.

i If the superheat is out of range, refer to Troubleshooting section of this IOM.

| Suction Temp (°F) | Final Superheat (°F) | | | | | | | | |
|-------------------|------------------------------|-----|-----|-----|-----|-----|-----|-----|-----|
| | 6 | 8 | 10 | 12 | 14 | 16 | 18 | 20 | 22 |
| | Suction Gauge Pressure (PSI) | | | | | | | | |
| 40 | 105 | 101 | 97 | 93 | 89 | 86 | 82 | 78 | 75 |
| 42 | 109 | 105 | 101 | 97 | 93 | 89 | 86 | 82 | 78 |
| 44 | 114 | 109 | 105 | 101 | 97 | 93 | 89 | 86 | 82 |
| 46 | 118 | 114 | 109 | 105 | 101 | 97 | 93 | 89 | 86 |
| 48 | 123 | 118 | 114 | 109 | 105 | 101 | 97 | 93 | 89 |
| 50 | 128 | 123 | 118 | 114 | 109 | 105 | 101 | 97 | 93 |
| 52 | 133 | 128 | 123 | 118 | 114 | 109 | 105 | 101 | 97 |
| 54 | 138 | 133 | 128 | 123 | 118 | 114 | 109 | 105 | 101 |
| 56 | 143 | 138 | 133 | 128 | 123 | 118 | 114 | 109 | 105 |
| 58 | 148 | 143 | 138 | 133 | 128 | 123 | 118 | 114 | 109 |
| 60 | 153 | 148 | 143 | 138 | 133 | 128 | 123 | 118 | 114 |
| 62 | 159 | 153 | 148 | 143 | 138 | 133 | 128 | 123 | 118 |
| 64 | 164 | 159 | 153 | 148 | 143 | 138 | 133 | 128 | 123 |
| 66 | 170 | 164 | 159 | 153 | 148 | 143 | 138 | 133 | 128 |
| 68 | 176 | 170 | 164 | 159 | 153 | 148 | 143 | 138 | 133 |
| 70 | 182 | 176 | 170 | 164 | 159 | 153 | 148 | 143 | 138 |
| 72 | 188 | 182 | 176 | 170 | 164 | 159 | 153 | 148 | 143 |

Table 7 R-410A Refrigerant chart - Final Superheat


| Liquid Temp (°F) | Final Subcooling (°F) | | | | | | | |
|------------------|-----------------------------|-----|-----|-----|-----|-----|-----|-----|
| | 6 | 7 | 8 | 9 | 10 | 11 | 12 | 13 |
| | Liquid Gauge Pressure (PSI) | | | | | | | |
| 55 | 173 | 176 | 179 | 182 | 185 | 188 | 191 | 195 |
| 60 | 188 | 191 | 195 | 198 | 201 | 204 | 208 | 211 |
| 65 | 204 | 208 | 211 | 215 | 218 | 221 | 225 | 229 |
| 70 | 221 | 225 | 229 | 232 | 236 | 239 | 243 | 247 |
| 75 | 239 | 243 | 247 | 251 | 255 | 259 | 262 | 266 |
| 80 | 259 | 262 | 266 | 270 | 275 | 279 | 283 | 287 |
| 85 | 279 | 283 | 287 | 291 | 295 | 300 | 304 | 309 |
| 90 | 300 | 304 | 309 | 313 | 318 | 322 | 327 | 331 |
| 95 | 322 | 327 | 331 | 336 | 341 | 346 | 351 | 355 |
| 100 | 346 | 351 | 355 | 360 | 365 | 370 | 376 | 381 |
| 105 | 370 | 376 | 381 | 386 | 391 | 397 | 402 | 407 |
| 110 | 397 | 402 | 407 | 413 | 418 | 424 | 430 | 435 |
| 115 | 424 | 430 | 435 | 441 | 447 | 453 | 459 | 465 |
| 120 | 453 | 459 | 465 | 471 | 477 | 483 | 489 | 496 |
| 125 | 483 | 489 | 496 | 502 | 508 | 515 | 521 | 528 |

Table 8 R-410A Refrigerant chart - Final Subcooling


| Design Subcooling | | |
|-------------------|---------------|--------------|
| Model | Subcooling/°F | Superheat/°F |
| 2 Ton | 6 - 12 | 6 - 18 |
| 3 Ton | 8 - 15 | 6 - 18 |
| 4 Ton & 5 Ton | 6 - 12 | 6 - 18 |

Table 9

6. Adjust refrigerant level to attain proper gauge pressure.

 **Add refrigerant** if the subcooling reading from Table 8 is lower than the designed value (Table 9).

- ▶ Connect gauges to refrigerant bottle and unit as illustrated (Fig.37).
- ▶ Purge all hoses.
- ▶ Open tank.
- ▶ Stop adding refrigerant when subcooling matches the design value (Table 9).

 **Recover refrigerant** if the subcooling reading from Table 8 is higher than the design value (Table 9).




Figure 37

7. Stabilize the system.
 - ▶ Wait 5 minutes for the system condition to stabilize between adjustments.

 When the subcooling matches the design value (Table 9), the system is properly charged.

- ▶ Remove gauges.
 - ▶ Replace service port caps to prevent leaks. Tighten finger tight plus an additional 1/6 turn.
8. Record System Information for reference (Table 10).
Record system pressures and temperatures after charging is complete.

| Description | Value |
|----------------------------|-------|
| Outdoor model number | |
| Measured Outdoor Ambient | °F |
| Measured Indoor Ambient | °F |
| Measured Liquid Line Temp | °F |
| Measured Suction Line Temp | °F |
| Liquid Gauge Pressure | PSIG |
| Suction Gauge Pressure | PSIG |

Table 10

15 System Operation and Troubleshooting

15.1 Control Logic Description

- ▶ The variable speed system adopts the same 24VAC control as any conventional heat pump.
- ▶ The compressor's speed is controlled based on coil pressures monitored by the unit's pressure transducer. To ensure stable and adequate capacity, the compressor speed will modulate relative to evaporator pressure during cooling operation and relative to condensing pressure during heating operation. The target pressure can automatically adjust based on compressor operation so optimal capacity can be achieved. Target pressure can be manually adjusted (SW4) to achieve improved dehumidification and capacity demands.




Figure 38

| Switch | Description | |
|--------|-------------|-----------------------------------|
| SW4-1 | ON | Unused |
| | OFF* | Must be set at "OFF" position |
| SW4-2 | ON | Unused |
| | OFF* | Must be set at "OFF" position |
| SW4-3 | ON | Adaptive capacity output disabled |
| | OFF* | Adaptive capacity output enabled |
| SW4-4 | ON | Accelerated cooling/heating |
| | OFF* | Normally cooling/heating |

Table 11

*Factory Default

- ▶ Adaptive capacity function is a "self-learning function" which allows a range of target coil temperatures to adapt for better unit operation and reduced short cycling.
- ▶ Accelerated cooling/heating function changes the initial target coil temperature to provide "enhanced comfort" by increasing unit capacity.

15.2 Sensors (Thermistors/Pressure Transducer)

- ▶ T3 = Outdoor Coil Temperature (Table 15)
 - High/Low temperature protection
 - Outdoor fan control (cooling mode)
 - Defrost control (heating mode)
- ▶ T4 = Ambient Temperature (Table 15)
 - Operating condition permission
 - Defrosting condition permission
 - Outdoor fan control (heating mode)
- ▶ T5 = Compressor Discharge Temperature (Table 16)
 - High/Low temperature protection
 - Electronic Expansion Valve (EEV) (ODU/heating mode only)
- ▶ T3L = Liquid Line Temperature (Table 15)
- ▶ TF = Control Board Temperature (Table 16)
 - Inverter High Temperature Protection
- ▶ Pressure transducer
 - Compressor frequency control
 - Electronic Expansion Valve (EEV) control (heating mode only)
 - High pressure protection (heating mode)
 - Low pressure protection (cooling mode)

15.3 Pressure Equalizer Valve (PEV)

Used to balance the pressure in the system before compressor start up.

15.4 Defrost Description

- ▶ The Demand Defrost Control (DDC) monitors the ODU coil temperature using thermistor (T3). A second thermistor (T4) monitors outdoor ambient temperature. Based on these parameters, as well as accumulative run time and high pressure, the DDC calculates proper initiation of defrost.
- ▶ Any one of the below three conditions is required to enter defrost:
 1. The calculated temperature difference between the outdoor temperature (T4) and the coil temperature (T3) is called Delta T. After Delta T is achieved and continues for 3 minutes.
 - $T4 \geq 39^{\circ}\text{F}$, $\Delta T = 21^{\circ}\text{F}$
 - $T4 \geq 30^{\circ}\text{F}$, $\Delta T = 19^{\circ}\text{F}$
 - $T4 \geq 19^{\circ}\text{F}$, $\Delta T = 17^{\circ}\text{F}$
 - When $T4 < 19^{\circ}\text{F}$, $T3 < 9^{\circ}\text{F}$, accumulative compressor run time ≥ 80 minutes.
 2. After "Minimum Run Time" (MRT) is achieved. MRT is based on outdoor ambient temperature (T4), for example:
 - MRT is 4 hours when: $T4 < 23^{\circ}\text{F}$
 - MRT is 2 hours when: $23^{\circ}\text{F} \leq T4 < 42^{\circ}\text{F}$
 3. After the high pressure saturation temperature drops below 82°F for 20 minutes.
- ▶ Defrost will terminate once outdoor coil temperature (T3) reaches 64°F for a period of 1 minute or defrost time has exceeded 8 minutes.

- Defrost Termination Settings (SW5) offers different defrost termination options for enhanced defrost for different geographical and outdoor conditions.




Figure 39

| Defrosting Choice | SW5-1 | SW5-2 | Remarks |
|-------------------|----------------------------------|------------------------------------|---------|
| ON | Operating time is reduced by 10% | Defrosting extended for 60 seconds | |
| OFF | Normal | Normal | Default |
| Remarks | Enter defrost | Quit defrost | |

Table 12

- Manual Defrost:
 1. System must have a call for heat and have been operating for a minimum of 8 minutes.
 2. Press "Force" button on inverter board for 6 seconds to begin forced defrost.
 3. Wait approximately 40 seconds for defrost to initiate.
 4. Once defrost initiates, the display will indicate "dF".
 5. Defrost test will terminate automatically, after which the display will indicate running speed.
 6. If a second defrost test is required, repeat steps 2-5 after 5 minutes.

15.5 Compressor Crankcase Heater Description

Refrigerant migration during the OFF cycle can result in noisy start-ups, therefore a CrankCase Heater (CCH) is used to minimize refrigerant migration thereby minimizing start-up noise and/or bearing "wash out". All CCHs must be installed on the lower half of the compressor shell. Its purpose is to warm the compressor during the OFF cycle, driving refrigerant from compressor. After extended shutdown periods in cold weather, it is recommended to allow CCH to be energized for at least 12 hours prior to compressor operation by applying line voltage to heat pump with thermostat OFF.

- CCH operation energizes:
 1. First time line voltage is applied and compressor discharge temperature $T5 < 53.6^{\circ}\text{F}$.
 2. Compressor stops running for 3 hours (outdoor ambient temperature $T4 < 41^{\circ}\text{F}$ OR compressor discharge temperature $T5 < 53.6^{\circ}\text{F}$).
- CCH operation de-energizes:
 1. Compressor discharge temperature $T5 \geq 60.8^{\circ}\text{F}$.
 2. Compressor start running.

15.6 Reversing Valve Operation

- Reversing valve energizes during heat mode and de-energizes in cool mode.

i During a heat call on first time operation the unit will run about 1 minute in cooling to build up pressure for reversing valve to change.

15.7 Protection Functions

- Outdoor coil temperature protection (T3)
 - i. If $T3 > 141.8^{\circ}\text{F}$, compressor is de-energized.
 - ii. If $T3 < 129.2^{\circ}\text{F}$, compressor is energized.
- Ambient temperature protection (T4)
 - i. If $40^{\circ}\text{F} \leq T4 < 120^{\circ}\text{F}$, unit can operate in cooling.
 - ii. If $5^{\circ}\text{F} \leq T4 < 86^{\circ}\text{F}$, unit can operate in heating.
 - iii. If $T4 < 7^{\circ}\text{F}$, heat pump will provide 24V control to indoor unit energizing electric heat (if installed).

i See BOVA15 Product Specification for extended performance data.

- Discharge Temperature (DT) protection (T5)
 - i. If $DT > 230^{\circ}\text{F}$ during cooling mode, the compressor will stop.
 - ii. If $DT < 185^{\circ}\text{F}$ during cooling mode, the compressor will restart.
 - iii. If $DT > 230^{\circ}\text{F}$ during heating mode, the compressor will stop.
 - iv. If $DT < 185^{\circ}\text{F}$ during heating mode, the compressor will restart.
- High Pressure (HP) protection (mechanical open/close pressure switch)
 - i. High Pressure Switch opens at $P > 580$ PSIG, the compressor and outdoor fan stop.
 - ii. High Pressure Switch closes at $P < 435$ PSIG, the compressor and outdoor fan restart.
- Low Pressure (LP) protection
 - i. If Low Pressure < 43.5 PSI for 5 minutes during cooling mode, the compressor and outdoor fan will stop. The system will attempt to run again after 6 minutes.
 - ii. If condensing temp. $Tc < \text{outdoor ambient temp. } T4$ during heating mode, the compressor and outdoor fan will stop.
- Module (inverter) protection (TF)
 - i. If $TF > 176^{\circ}\text{F}$, the compressor and outdoor fan will stop.
 - ii. If $TF < 154^{\circ}\text{F}$, the compressor and outdoor fan will restart.

15.8 Fault Code Table

| Code | Fault Description (Sensor) |
|-------|--|
| C3 | The coil sensor is seated fault in cooling (T3) |
| E4 | Temperature sensor fault (T3, T4, T3L,T5,TF) |
| E5 | High/low voltage protection |
| E6 | DC fan motor fault |
| E7 | Compressor discharge sensor is seated fault (T5) |
| E9 | EEPROM fault |
| H0 | Communication fault in main control chip |
| H5* | 5 times (P2) protection in 100 minutes, system lockout |
| H8 | Pressure transducer fault (PT) |
| P0 | Control board temperature protection (TF) |
| P1 | High pressure switch protection (HPS) |
| P2 | Low pressure protection in cooling or heating (PT) |
| P3 | Compressor over current protection |
| P4 | High compressor discharge temperature protection (T5) |
| P5 | Condensor coil temperature protection in cooling (T3) |
| P8 | DC fan motor hurricane/typhoon protection |
| PH | Low discharge superheat protection |
| F1 | High pressure switch protection (HPS) |
| L0-L9 | The IPM module protection |
| AtL | Ambient temperature Limited |

System Protection Status Codes**

| | |
|----|---|
| ┆ | Forced operation mode |
| L | Running indication under T3 limited condition |
| D | Running indication under T5 limited condition |
| P | Running indication under compressor ratio limited condition |
| F | Running indication under TF limited condition |
| C | Running indication under current limited condition |
| U | Running indication under low voltage limited condition |
| A | Running indication under return oil mode |
| dF | Running indication under defrost mode |

Table 13

* Fault requires hard restart

** If the first digit shown on the control board LED is one of the following protection codes (followed by two numerical digits which show the current compressor frequency in Hz), the unit will continue to run but in a limited condition. The only exception is when the system is in defrost mode, which only displays "dF" (without any numerical digits following).

15.9 Parameter Point Check Table

- ▶ To display system parameters, press the “Check” button to index through the series of parameters available. The first time you press the “Check” button, it will display the sequence, and after 1 second it will display the value of the parameter. If you press the “Check” button again, it will display the next sequence. Refer to Figure 44 and 45 for check button location on the control board.
- ▶ Normal Status, last two digits will display under the following conditions
 - i. Unit not operating (Standby Mode); “outdoor ambient temperature”.
 - ii. Unit operating; displays “compressor operating frequency”.
- ▶ After 20 seconds on same parameter, the display will revert back to normal status.
- ▶ If a system protection is active, first digit will display “status code”.

| No. | Point check content | Example | Remark |
|-----|---|---------|---|
| 0 | Outdoor unit capacity | H3 | H3=Heat Pump 3 ton |
| 1 | Outdoor unit mode | 2 | "0 standby, 2 cooling, 3 heating" |
| 2 | Outdoor unit set compressor speed (Hz) | 66 | |
| 3 | T3 (outdoor coil temp.) (°F) | | |
| 4 | T4 (outdoor ambient temp.) (°F) | | |
| 5 | T5 (compressor discharge temp.) (°F) | | |
| 6 | Reserve | | |
| 7 | T3L (liquid line temp.) (°F) | | |
| 8 | Tf (module temp.) (°F) | | |
| 9 | Pe (evaporating pressure) (PSI) | | Low Suction Pressure |
| 10 | Pc (condensing pressure) (PSI) | | High Head Pressure |
| 11 | Tes target of the evaporating temp. (only use for cooling mode) (°F) | | |
| 12 | Te (evaporating temp.) (°F) | | |
| 13 | Tcs target of the condensing temp. (only use for heating mode) (°F) | | |
| 14 | Tc (condensing temp.) (°F) | | |
| 15 | Target of the compressor discharge superheat (only use for heating mode) (°F) | | |
| 16 | Compressor discharge superheat (°F) | | |
| 17 | Openings of EEV | | |
| 18 | Fan speed | | |
| 19 | Compressor current (A) | | |
| 20 | AC voltage of power input (V) | | |
| 21 | DC voltage (V) of compressor input | | |
| 22 | Continuous running time of the compressor (min) | | |
| 23 | Last fault code | 00 | |
| 24 | Software version | 01 | |
| 25 | Remark “--” | -- | -- |

Table 14

15.10 Control Board Overviews

Main Control Board for 24/36 ODU Model




Figure 40

Main Control Board for 48/60 ODU Model




Figure 41

15.11 Error Code Troubleshooting



WARNING: HAZARDOUS VOLTAGE

- ▶ When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.



WARNING: HAZARDOUS VOLTAGE

- ▶ When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.

C3 (Condenser coil sensor (T3) is not reading correctly in cooling)




Figure 42

E4 (Temperature sensor fault (T3, T4, T5, T3L))




Figure 43




Figure 44




Figure 45

**WARNING: HAZARDOUS VOLTAGE**

- When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.




Figure 46




Figure 47




Figure 48





Figure 49



WARNING: HAZARDOUS VOLTAGE

▶ When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.




Figure 50

**WARNING: HAZARDOUS VOLTAGE**

- When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.




Figure 51




Figure 52



WARNING: HAZARDOUS VOLTAGE

- ▶ When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.



WARNING: HAZARDOUS VOLTAGE

- ▶ When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.




Figure 53




Figure 54

**WARNING: HAZARDOUS VOLTAGE**

- ▶ When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.


P5 (Condenser coil temperature (T3) protection in cooling)

Figure 55


P8 (DC outdoor fan motor protection)

Figure 56



WARNING: HAZARDOUS VOLTAGE

► When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.




Figure 57




Figure 58

**WARNING: HAZARDOUS VOLTAGE**

- ▶ When measuring resistance, make sure the unit is powered off and wait 3 min before taking measurement.




Figure 59

15.12 Temperature and Resistance Relationship Tables (for Sensors)

| TEMP F | TEMP C | RESISTANCE kΩ | VOLTS DC | TEMP F | TEMP C | RESISTANCE kΩ | VOLTS DC |
|--------|--------|---------------|----------|--------|--------|---------------|----------|
| -5 | -20.6 | 107.732 | 4.65 | 90 | 32.2 | 7.225 | 2.36 |
| 0 | -17.8 | 93.535 | 4.60 | 95 | 35.0 | 6.401 | 2.21 |
| 5 | -15.0 | 79.521 | 4.54 | 100 | 37.8 | 5.683 | 2.07 |
| 10 | -12.2 | 67.795 | 4.47 | 105 | 40.6 | 5.057 | 1.93 |
| 15 | -9.4 | 57.948 | 4.39 | 110 | 43.3 | 4.509 | 1.79 |
| 20 | -6.7 | 49.652 | 4.30 | 115 | 46.1 | 4.028 | 1.67 |
| 25 | -3.9 | 42.645 | 4.21 | 120 | 48.9 | 3.606 | 1.55 |
| 30 | -1.1 | 36.710 | 4.10 | 125 | 51.7 | 3.233 | 1.43 |
| 40 | 4.4 | 27.386 | 3.86 | 130 | 54.4 | 2.902 | 1.32 |
| 45 | 7.2 | 23.732 | 3.73 | 135 | 57.2 | 2.610 | 1.22 |
| 50 | 10.0 | 20.610 | 3.59 | 140 | 60.0 | 2.350 | 1.13 |
| 55 | 12.8 | 17.939 | 3.45 | 145 | 62.8 | 2.119 | 1.04 |
| 60 | 15.6 | 15.648 | 3.30 | 150 | 65.6 | 1.914 | 0.96 |
| 65 | 18.3 | 13.681 | 3.15 | 155 | 68.3 | 1.731 | 0.88 |
| 70 | 21.1 | 11.987 | 2.99 | 160 | 71.1 | 1.574 | 0.82 |
| 75 | 23.9 | 10.527 | 2.83 | 165 | 73.9 | 1.416 | 0.75 |
| 80 | 26.7 | 9.265 | 2.67 | 170 | 76.7 | 1.276 | 0.68 |
| 85 | 29.4 | 8.172 | 2.52 | | | | |

Table 15 for T3, T4, T3L

15.13 Temperature and Resistance Relationship Tables (for T5 Sensor)

| TEMP F | TEMP C | RESISTANCE kΩ | VOLTS DC | TEMP F | TEMP C | RESISTANCE kΩ | VOLTS DC |
|--------|--------|---------------|----------|--------|--------|---------------|----------|
| -5 | -20.6 | 600.134 | 4.93 | 140 | 60.0 | 13.643 | 3.14 |
| 0 | -17.8 | 505.551 | 4.92 | 145 | 62.8 | 12.359 | 3.03 |
| 5 | -15 | 427.463 | 4.91 | 150 | 65.6 | 11.214 | 2.91 |
| 10 | -12.2 | 362.739 | 4.89 | 155 | 68.3 | 10.227 | 2.80 |
| 15 | -9.4 | 308.891 | 4.87 | 160 | 71.1 | 9.308 | 2.68 |
| 20 | -6.7 | 265.398 | 4.85 | 165 | 73.9 | 8.485 | 2.56 |
| 25 | -3.9 | 227.481 | 4.83 | 170 | 76.7 | 7.746 | 2.45 |
| 30 | -1.1 | 195.601 | 4.80 | 175 | 79.4 | 7.105 | 2.34 |
| 35 | 1.7 | 168.707 | 4.77 | 180 | 82.2 | 6.504 | 2.23 |
| 40 | 4.4 | 146.695 | 4.74 | 185 | 85.0 | 5.963 | 2.13 |
| 45 | 7.2 | 127.258 | 4.70 | 190 | 87.8 | 5.474 | 2.02 |
| 50 | 10.0 | 110.707 | 4.66 | 195 | 90.6 | 5.032 | 1.92 |
| 55 | 12.8 | 96.572 | 4.61 | 200 | 93.3 | 4.645 | 1.83 |
| 60 | 15.6 | 84.465 | 4.56 | 205 | 96.1 | 4.280 | 1.73 |
| 65 | 18.3 | 74.411 | 4.51 | 210 | 98.9 | 3.949 | 1.64 |
| 70 | 21.1 | 65.408 | 4.45 | 215 | 101.7 | 3.648 | 1.56 |
| 75 | 23.9 | 57.634 | 4.39 | 220 | 104.4 | 3.383 | 1.48 |
| 80 | 26.7 | 50.904 | 4.32 | 225 | 107.2 | 3.133 | 1.40 |
| 85 | 29.4 | 45.258 | 4.24 | 230 | 110.0 | 2.904 | 1.32 |
| 90 | 32.2 | 40.152 | 4.16 | 235 | 112.8 | 2.694 | 1.25 |
| 95 | 35.0 | 35.699 | 4.08 | 240 | 115.6 | 2.503 | 1.18 |
| 100 | 37.8 | 31.807 | 3.99 | 245 | 118.3 | 2.334 | 1.12 |
| 105 | 40.6 | 28.398 | 3.89 | 250 | 121.1 | 2.172 | 1.06 |
| 110 | 43.3 | 25.506 | 3.80 | 255 | 123.9 | 2.024 | 1.00 |
| 115 | 46.1 | 22.861 | 3.70 | 260 | 126.7 | 1.888 | 0.95 |
| 120 | 48.9 | 20.529 | 3.59 | 265 | 129.4 | 1.767 | 0.90 |
| 125 | 51.7 | 18.47 | 3.48 | 270 | 132.2 | 1.651 | 0.85 |
| 130 | 54.4 | 16.708 | 3.37 | 275 | 135.0 | 1.544 | 0.80 |
| 135 | 57.2 | 15.085 | 3.26 | 280 | 137.8 | 1.446 | 0.76 |

Table 16 for T5

16 Wiring Diagram

16.1 BOVA24/36-15 (2/3 Ton)




Figure 60

16.2 BOVA60-15 (4/5 Ton)




Figure 61

17 Care and Maintenance

17.1 Cleaning Precautions


WARNING:

- ▶ Any maintenance and cleaning of outdoor unit must be performed by qualified service personnel only.
- ▶ Any unit repairs must be performed by qualified service personnel only.


CAUTION: ELECTRIC SHOCK


- ▶ Always turn off your heat pump and disconnect the power supply before cleaning or maintenance.

NOTICE:


- ▶ Do not use chemicals or chemically treated cloths to clean the unit .
- ▶ Do not use benzene, paint thinner, polishing powder or other solvents to clean the unit.

17.2 Maintenance – Pre-Season Inspection

At the beginning of each heating or cooling season, do the following:



Turn off the unit and
disconnect the power



Check for damaged wires



Check for leaks



Make sure nothing is blocking all air inlets and outlets
and clean the coils as necessary

Figure 62

NOTES:

NOTES:

United States and Canada
Bosch Thermotechnology Corp.
65 Grove St.
Watertown, MA 02472

Tel: 866-642-3198
Fax: 954-776-5529
www.bosch-thermotechnology.us

BTC 761701317 B / 07.2022

Bosch Thermotechnology Corp. reserves the right
to make changes without notice due to continuing
engineering and technological advances.

Versión en Español



Version Française

