

Air-Conditioners

SERVICE MANUAL


Series PVA

Model name

<Indoor unit>

PVA-A12, 18, 24, 30, 36, 42AA7

Multi-Position Air Handler



INDOOR UNIT

Contents

1. SAFETY PRECAUTION	2
1-1. Always observe for safety	2
1-2. Cautions related to new refrigerant	2
2. PART NAMES AND FUNCTIONS	3
3. SPECIFICATION	4
4. FAN PERFORMANCE AND CORRECTED AIR FLOW	7
PVA-A12AA7	7
PVA-A18AA7	8
PVA-A24AA7	9
PVA-A30AA7	10
PVA-A36AA7	11
PVA-A42AA7	12
PVA-A12, 18, 24, 30, 36, 42AA7	13
Air Filter	13
5. SOUND PRESSURE LEVELS	14
5-1. Sound pressure level	14
5-2. NC curves	14
6. OUTLINES & DIMENSIONS	17
7. WIRING DIAGRAM	19
PVA-A12, 18, 24, 30, 36, 42AA7	19
8. REFRIGERANT SYSTEM DIAGRAM	20
9. HEATER CONTROL	21
9-1. Control Specifications And Function Setting	21
9-2. Fan control	23
9-3. CN24RELAY-KIT-CM3 (Optional Parts) installation	24
10. HUMIDIFIER CONTROL	26
10-1. Control Specifications	26
10-2. Installation	26
11. ERV (ENERGY RECOVERY VENTILATION) CONTROL	27
11-1. Control Specifications	27
11-2. Installation	27
12. TROUBLESHOOTING	28
12-1. Cautions on troubleshooting	28
12-2. Self-check function, Function Table	29
12-3. Self-diagnosis action table	31
12-4. Troubleshooting by inferior phenomena	35
12-5. Test point diagram	36
12-6. Trouble criterion of main parts	38
12-7. Thermistor	38
12-8. DC Fan motor (FAN MOTOR/INDOOR CONTROLLER BOARD)	39
12-9. Functions of dip switch and jumper wire	40
13. DISASSEMBLY PROCEDURE	41
13-1. Control box	41
13-2. Thermistor (Return Air)	42
13-3. Coil Assembly	43
13-4. Blower/Fan Assembly	45

1 SAFETY PRECAUTION

1-1. Always observe for safety

Before obtaining access to terminal, all supply circuits must be disconnected.

1-2. Cautions related to new refrigerant

Cautions for units utilising refrigerant R410A

Use new refrigerant pipes.

In case of using the existing pipes for R22, be careful with the followings.

- For A36 and A42, be sure to perform replacement operation before test run.
- Change flare nut to the one provided with this product. Use a newly flared pipe.
- Avoid using thin pipes.

Make sure that the inside and outside of refrigerant piping is clean and it has no contamination such as sulfur hazardous for use, oxides, dirt, shaving particles, etc.

In addition, use pipes with specified thickness.

Contamination inside refrigerant piping can cause deterioration of refrigerant oil etc.

Store the piping to be used indoors during installation and both ends of the piping sealed until just before brazing. (Leave elbow joints, etc. in their packaging.)

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Use ester oil, ether oil or alkylbenzene oil (small amount) as the refrigerant oil applied to flares and flange connections.

If large amount of mineral oil enters, that can cause deterioration of refrigerant oil etc.

Charge refrigerant from liquid phase of gas cylinder.

If the refrigerant is charged from gas phase, composition change may occur in refrigerant and the efficiency will be lowered.

Do not use refrigerant other than R410A.

If other refrigerant (R22 etc.) is used, chlorine in refrigerant can cause deterioration of refrigerant oil etc.

Use a vacuum pump with a reverse flow check valve.

Vacuum pump oil may flow back into refrigerant cycle and that can cause deterioration of refrigerant oil etc.

Use the following tools specifically designed for use with R410A refrigerant.

The following tools are necessary to use R410A refrigerant.

Tools for R410A	
Gauge manifold	Flare tool
Charge hose	Size adjustment gauge
Gas leak detector	Vacuum pump adaptor
Torque wrench	Electronic refrigerant charging scale

Handle tools with care.

If dirt, dust or moisture enters into refrigerant cycle, that can cause deterioration of refrigerant oil or malfunction of compressor.

Do not use a charging cylinder.

If a charging cylinder is used, the composition of refrigerant will change and the efficiency will be lowered.

Ventilate the room if refrigerant leaks during operation. If refrigerant comes into contact with a flame, poisonous gases will be released.

[1] Cautions for service


- (1) Perform service after recovering the refrigerant left in unit completely.
- (2) Do not release refrigerant in the air.
- (3) After completing service, charge the cycle with specified amount of refrigerant.
- (4) When performing service, install a filter drier simultaneously.

Be sure to use a filter drier for new refrigerant.

[2] Additional refrigerant charge

When charging directly from cylinder

- Check that cylinder for R410A on the market is syphon type.
- Charging should be performed with the cylinder of syphon stood vertically. (Refrigerant is charged from liquid phase.)



[3] Service tools

Use the below service tools as exclusive tools for R410A refrigerant.


No.	Tool name	Specifications
1	Gauge manifold	· Only for R410A
		· Use the existing fitting specifications. (UNF1/2)
		· Use high-tension side pressure of 5.3MPa-G or over.
2	Charge hose	· Only for R410A
		· Use pressure performance of 5.09MPa-G or over.
3	Electronic scale	—
4	Gas leak detector	· Use the detector for R134a, R407C or R410A.
5	Adaptor for reverse flow check	· Attach on vacuum pump.
6	Refrigerant charge base	—
7	Refrigerant cylinder	· Only for R410A · Top of cylinder (Pink)
		· Cylinder with syphon
8	Refrigerant recovery equipment	—

2


PART NAMES AND FUNCTIONS

• Indoor Unit


(1) Vertical




(2) Horizontal Right



(3) Horizontal left



(4) Down flow



3

SPECIFICATION

INDOOR UNIT	Service Ref.		PVA-A12AA7	
	Power supply (phase, cycle, voltage)		1 phase, 60Hz, 208/230V	
	Max. Fuse Size		A	15
	Min. Circuit Ampacity		A	3.00
	External finish		Galvanized steel cabinet - Powder coated Slate Gray	
	Heat exchanger		Plate fin coil	
	Fan	Fan (drive) x No.		Sirocco fan x 1
		Fan motor output		kW
		Fan motor		F.L.A
		Airflow (Low-Mid-High)		m ³ /min (CFM)
		External static pressure		Pa (in.WG)
	Operation control & Thermostat		Remote controller & built-in	
	Sound pressure level (Low-Mid-High)	75Pa (0.30 in.WG)	dB (A)	24-28-32
		125Pa (0.50 in.WG)		27-31-35
		200Pa (0.80 in.WG)		32-36-41
	Drain pipe		mm (in.)	19.05 (3/4) FPT
	Dimensions	W	mm (in.)	432 (17)
		D	mm (in.)	548 (21-5/8)
		H	mm (in.)	1275 (50-1/4)
	Weight		kg (lbs)	51 (113)

INDOOR UNIT	Service Ref.		PVA-A18AA7	
	Power supply (phase, cycle, voltage)		1 phase, 60Hz, 208/230V	
	Max. Fuse Size		A	15
	Min. Circuit Ampacity		A	3.00
	External finish		Galvanized Steel Cabinet - Powder coated Slate Gray	
	Heat exchanger		Plate fin coil	
	Fan	Fan (drive) x No.		Sirocco fan x 1
		Fan motor output		kW
		Fan motor		F.L.A
		Airflow (Low-Mid-High)		m ³ /min (CFM)
		External static pressure		Pa (in.WG)
	Operation control & Thermostat		Remote controller & built-in	
	Sound pressure level (Low-Mid-High)	75Pa (0.30 in.WG)	dB (A)	28-33-36
		125Pa (0.50 in.WG)		30-34-38
		200Pa (0.80 in.WG)		34-38-42
	Drain pipe		mm (in.)	19.05 (3/4) FPT
	Dimensions	W	mm (in.)	432 (17)
		D	mm (in.)	548 (21-5/8)
		H	mm (in.)	1275 (50-1/4)
	Weight		kg (lbs)	51 (113)



INDOOR UNIT	Service Ref.		PVA-A24AA7	
	Power supply (phase, cycle, voltage)		1 phase, 60Hz, 208/230V	
			15	
			4.13	
	External finish		Galvanized steel cabinet - Powder coated Slate Gray	
	Heat exchanger		Plate fin coil	
	Fan	Fan (drive) x No.		Sirocco fan x 1
		Fan motor output		0.244
		Fan motor		3.3
		Airflow (Low-Mid-High)		17.3-21.1-24.8 (613-744-875)
		External static pressure		75-125-200 (0.30-0.50-0.80)
	Operation control & Thermostat		Remote controller & built-in	
	Sound pressure level (Low-Mid-High)	75Pa (0.30 in.WG)	dB (A)	30-34-38
		125Pa (0.50 in.WG)		32-36-40
		200Pa (0.80 in.WG)		35-39-43
	Drain pipe		mm (in.)	19.05 (3/4) FPT
	Dimensions	W	mm (in.)	534 (21)
		D	mm (in.)	548 (21-5/8)
		H	mm (in.)	1378 (54-1/4)
	Weight		kg (lbs)	64 (141)

INDOOR UNIT	Service Ref.		PVA-A30AA7	
	Power supply (phase, cycle, voltage)		1 phase, 60Hz, 208/230V	
			15	
			4.13	
	External finish		Galvanized steel cabinet - Powder coated Slate Gray	
	Heat exchanger		Plate fin coil	
	Fan	Fan (drive) x No.		Sirocco fan x 1
		Fan motor output		0.121
		Fan motor		3.3
		Airflow (Low-Mid-High)		17.3-21.1-24.8 (613-744-875)
		External static pressure		75-125-200 (0.30-0.50-0.80)
	Operation control & Thermostat		Remote controller & built-in	
	Sound pressure level (Low-Mid-High)	75Pa (0.30 in.WG)	dB (A)	30-34-38
		125Pa (0.50 in.WG)		32-36-40
		200Pa (0.80 in.WG)		35-39-43
	Drain pipe		mm (in.)	19.05 (3/4) FPT
	Dimensions	W	mm (in.)	534 (21)
		D	mm (in.)	548 (21-5/8)
		H	mm (in.)	1378 (54-1/4)
	Weight		kg (lbs)	64 (141)







INDOOR UNIT	Service Ref.		PVA-A36AA7	
	Power supply (phase, cycle, voltage)		1 phase, 60Hz, 208/230V	
			15	
			5.50	
	External finish		Galvanized Steel Cabinet - Powder coated Slate Gray	
	Heat exchanger		Plate fin coil	
	Fan	Fan (drive) x No.		Sirocco fan x 1
		Fan motor output		0.430
		Fan motor		4.40
		Airflow (Low-Mid-High)		22.3-27.1-31.9 (788-956-1125)
		External static pressure		75-125-200 (0.30-0.50-0.80)
	Operation control & Thermostat		Remote controller & built-in	
	Sound pressure level (Low-Mid-High)	75Pa (0.30 in.WG)	dB (A)	30-34-38
		125Pa (0.50 in.WG)		32-36-40
		200Pa (0.80 in.WG)		37-41-45
	Drain pipe		mm (in.)	19.05 (3/4) FPT
	Dimensions	W	mm (in.)	635 (25)
		D	mm (in.)	548 (21-5/8)
		H	mm (in.)	1511 (59-1/2)
	Weight		kg (lbs)	78 (172)



INDOOR UNIT	Service Ref.		PVA-A42AA7	
	Power supply (phase, cycle, voltage)		1 phase, 60Hz, 208/230V	
	Max. Fuse Size		A	15
	Min. Circuit Ampacity		A	5.63
	External finish		Galvanized Steel Cabinet - Powder coated Slate Gray	
	Heat exchanger		Plate fin coil	
	Fan	Fan (drive) x No.		Sirocco fan x 1
		Fan motor output	kW	0.430
		Fan motor	F.L.A	4.50
		Airflow (Low-Mid-High)	m ³ /min (CFM)	29.4-35.7-42.0 (1040-1262-1485)
		External static pressure	Pa (in.WG)	75-125-200 (0.30-0.50-0.80)
	Operation control & Thermostat		Remote controller & built-in	
	Sound pressure level (Low-Mid-High)	75Pa (0.30 in.WG)	dB (A)	34-38-42
		125Pa (0.50 in.WG)		36-40-44
		200Pa (0.80 in.WG)		39-43-47
	Drain pipe		mm (in.)	19.05 (3/4) FPT
	Dimensions	W	mm (in.)	635 (25)
		D	mm (in.)	548 (21-5/8)
		H	mm (in.)	1511 (59-1/2)
	Weight		kg (lbs)	78 (172)







PVA-A12AA7

Vertical, Horizontal Right, Horizontal Left









PVA-A18AA7

Vertical, Horizontal Right, Horizontal Left









PVA-A24AA7

Vertical, Horizontal Right, Horizontal Left









PVA-A30AA7

Vertical, Horizontal Right, Horizontal Left




PVA-A36AA7

Vertical, Horizontal Right, Horizontal Left








PVA-A42AA7


Vertical, Horizontal Right, Horizontal Left



Downflow




PVA-A12, 18, 24, 30, 36, 42AA7
Air Filter
Power Source: 60Hz, 208/230V




5-1. Sound pressure level

Multi-Position








5-2. NC curves


PVA-A12AA7








PVA-A18AA7




PVA-A24AA7








PVA-A30AA7



PVA-A36AA7




PVA-A42AA7




6 OUTLINES & DIMENSIONS

INDOOR UNIT


PVA-A12, 18, 24, 30, 36, 42AA7





7 WIRING DIAGRAM

PVA-A12, 18, 24, 30, 36, 42AA7




Model	SWITCH		
PVA-A12AA7	SW1 ON 1 2 3 4 5	SW2 ON 1 2 3 4 5	SW5 ON 1 2 3 4 5 6 7 8
PVA-A18AA7	SW1 ON 1 2 3 4 5	SW2 ON 1 2 3 4 5	SW5 ON 1 2 3 4 5 6 7 8
PVA-A24AA7	SW1 ON 1 2 3 4 5	SW2 ON 1 2 3 4 5	SW5 ON 1 2 3 4 5 6 7 8
PVA-A30AA7	SW1 ON 1 2 3 4 5	SW2 ON 1 2 3 4 5	SW5 ON 1 2 3 4 5 6 7 8
PVA-A36AA7	SW1 ON 1 2 3 4 5	SW2 ON 1 2 3 4 5	SW5 ON 1 2 3 4 5 6 7 8
PVA-A42AA7	SW1 ON 1 2 3 4 5	SW2 ON 1 2 3 4 5	SW5 ON 1 2 3 4 5 6 7 8

- Note1. Since the outdoor side electric wiring may change be sure to check the outdoor unit electric wiring for servicing.
2. Indoor and outdoor connecting wires are made with polarities, make wiring matching terminal numbers (S1, S2, S3).
3. Symbols used in wiring diagram above are as follows.
- : CONNECTOR
 - ⊙ : TERMINAL
 - (HEAVY DOTTED LINE): FIELD WIRING
 - - (THIN DOTTED LINE): OPTIONAL PARTS
4. Use copper supply wire.
- UTILISER DES FILS D'ALIMENTATION EN CUIVRE.

SYMBOL	NAME	SYMBOL	NAME	SYMBOL	NAME
I.B.	INDOOR CONTROLLER BOARD	I.B.	INDOOR CONTROLLER BOARD	OPTIONAL PARTS	
CN24-1	CONNECTOR (HEATER CONTROL 1ST)	SW1	SWITCH (FOR MODEL SELECTION)	W.B.	IR WIRELESS REMOTE CONTROLLER BOARD
CN24-2	CONNECTOR (HEATER CONTROL 2ND)	SW2	SWITCH (FOR CAPACITY CODE)	RU	RECEIVING UNIT
CN25	CONNECTOR (HUMIDITY OUTPUT)	SW5	SWITCH (FOR MODE SELECTION)	BZ1	BUZZER
CN2A	CONNECTOR (0-10V ANALOG INPUT)	SWE	CONNECTOR (EMERGENCY OPERATION)	LED1	LED (RUN INDICATOR)
CN2C	CONNECTOR (ERV OUTPUT)	P.B.	POWER SUPPLY BOARD	SW1	SWITCH (HEATING ON/OFF)
CN2L	CONNECTOR (LOSSNAY)	F01	FUSE AC250V 6.3A	SW2	SWITCH (COOLING ON/OFF)
CN32	CONNECTOR (REMOTE SWITCH)	ZNR01,02	VARIATOR	R.B.	WIRED REMOTE CONTROLLER BOARD
CN41	CONNECTOR (HA TERMINAL-A)	DSA	ARRESTOR	TB6	TERMINAL BLOCK (REMOTE CONTROLLER TRANSMISSION LINE)
CN51	CONNECTOR (CENTRALLY CONTROL)	X10	AUX. RELAY		
CN90	CONNECTOR (WIRELESS)	TH1	INTAKE AIR TEMP. THERMISTOR		
CN105	CONNECTOR (RADIO FREQUENCY INTERFACE)	TH2	PIPE TEMP. THERMISTOR/LIQUID		
CNER	CONNECTOR (ERV INPUT)	TH5	COND./EVA. TEMP. THERMISTOR		
CNF	CONNECTOR (HUMIDITY INPUT)	TB4	TERMINAL BLOCK (INDOOR/OUTDOOR CONNECTING LINE)		
LED1	LED (POWER SUPPLY)	TB15	TERMINAL BLOCK (REMOTE CONTROLLER TRANSMISSION LINE)		
LED2	LED (REMOTE CONTROLLER SUPPLY)	RFI	RADIO FREQUENCY INTERFACE FOR RF THERMOSTAT		
LED3	LED (TRANSMISSION INDOOR-OUTDOOR)				

PVA-A12, 18, 24, 30, 36, 42AA7



9 HEATER CONTROL

9-1. Control Specifications And Function Setting

• Table 1 shows the mode setting for the field-installed heater.

Table. 1 [Function Table]

Select unit numbers 01 to 03 or all units (AL [wired remote controller] / 07 [IR wireless remote controller])

Mode (function) No.		Factory Setting	Mode	Heater Operation In Error	Heater Operation During Defrost	Fan Control When Heater ON
Wired remote controller (RF thermostat)						
11 (111)	23 (123)					
1	1	○	No Heater Present			
2	1	—	Heater Available	OFF	OFF	High
			Disable heater during Defrost and Error			
2	2	—	Heater Available	ON	ON	High
			Enable heater and fan during Defrost and Error *1			

^{*1} Heater will not operate during all error modes. Heater will only operate during a communication error between indoor unit and outdoor unit.

• Table 2 shows how the field-installed heater is controlled.

Table. 2 [Heater Control Table]

Mode Change	Condition								
	(To -T _{RA}) > 2.7 ° F [1.5 ° C]	AND	T _{RA} has not increased by 0.9 ° F [0.5° C] in <u>X</u> min	EH1 ON for > 7 min	AND	(To -T _{RA}) > 2.7 ° F [1.5 ° C]	AND	T _{RA} has not increased by 0.9 ° F [0.5° C] in 7 min	(To -T _{RA}) < 0.9 ° F [0.5° C]
EH1 ON	○	AND	○						
EH2 ON				○	AND	○	AND	○	
EH1 OFF									○
EH2 OFF									○
KEY									
• EH1: Electric Heater 1									
• EH2: Electric Heater 2									
• To: Set point temperature									
• T _{RA} : Return Air temperature									
• X: Time delay (Selectable. Default is 24 min. Selectable to 14, 19, or 29 min)									

- Table 3 shows how the time delay is selected

Table. 3 [Time Delay Selection Table]

Request Code ^{*1}	Action ^{*3}
390	Monitor Time Delay Setting
391	Set Time Delay to <u>14</u> minutes
392	Set Time Delay to <u>19</u> minutes
393	Set Time Delay to <u>24</u> minutes ^{*2}
394	Set Time Delay to <u>29</u> minutes

^{*1} Time delay can only be selected with MA controller. If use of a non-MA controller is desired, the time delay must first be selected with the MA controller. Then the non-MA controller can be attached and used.

^{*2} The default time delay setting is 24 minutes.

^{*3} All delay times are approximate.

- Chart 1 and Table 4 show an example of heater operation.

Chart 1 [Heater Operation Example]




Table. 4 [Heater Operation Example]

Step	Condition			Result
①	$(T_o - T_{RA}) > 2.7\text{ °F}$ [1.5 °C]	AND	T_{RA} has not increased by 0.9 °F [0.5 °C] in $X\text{ min}$	EH1 ON
②	$(T_o - T_{RA}) < 2.7\text{ °F}$ [1.5 °C]	AND	T_{RA} increasing faster than 0.9 °F [0.5 °C] in 7 min	EH2 not ON
③	$(T_o - T_{RA}) < 0.9\text{ °F}$ [0.5 °C]			EH1 OFF
④	$(T_o - T_{RA}) > 2.7\text{ °F}$ [1.5 °C]	AND	T_{RA} has not increased by 0.9 °F [0.5 °C] in $X\text{ min}$	EH1 ON
⑤	$(T_o - T_{RA}) > 2.7\text{ °F}$ [1.5 °C]	AND	T_{RA} not increasing faster than 0.9 °F [0.5 °C] in 7 min	EH2 ON
⑥	$(T_o - T_{RA}) < 0.9\text{ °F}$ [0.5 °C]			EH1 OFF EH2 OFF

9-2. Fan control

By setting the Mode No. 23 in the Function Table in section 9-1 and using CN4Y from the CN24RELAY-KIT-CM3 kit, the following patterns of fan control will become possible.

Fan Control Patterns

CN4Y for FAN control (CN24RELAY-KIT-CM3)	Mode (function) No. 23 (123)	Heater operation in defrost and error *1	Fan operation in defrost and error	Fan (All modes other than defrost and error)	Factory Setting
Enabled	1	OFF	STOP	Set (Heater ON)	○
	2	ON	STOP	High*2 (Heater ON)	—

*1 Heater will not operate during all error modes. Heater will only operate during a communication error between indoor unit and outdoor unit

*2 While the heater is on, the fan will operate at high speed regardless of the fan setting on the remote controller.



Warning

*** If a heater is installed in the duct, do not use CN4Y. By doing so, the fan will turn off when the heater is on, which may result in fire.**

Fan Speed Setting *3

Mode	Setting		Mode No.	Setting	Initial Setting
	Heating Thermo-OFF	DEFROST or ERROR			
Fan Control	Very Low	Very Low	25	1	○
	STOP	Remote Controller Setting	25	2	-
	Remote Controller Setting	Remote Controller Setting	25	3	-

*3 Refer to the Installation Manual for function settings.

9-3. CN24RELAY-KIT-CM3 (Optional Parts) installation

The following section describes installation of the External Heater Adapter that connects to PVA-A AA7 series indoor unit. This products is the special wiring parts to drive an electric heater with the air conditioner.

(1) Parts list

◆Check that the following parts are included in the package.

- 1) External output cable..... 2 in total
Two types of cables with different connectors are included.
- 2) Panel heater connector..... 3 in total
White: 3
- 3) Relay

(2) Connection to the indoor unit


◆Use the cables that fit the connectors on the indoor unit control board.

1) External output cable

This cable is used to connect a relay circuit for an interlocked operation with either an electric or a panel heater. Select the heater output pattern (1st = CN24-1 or 2nd = CN24-2) to use, and connect the cable to the connector on the indoor unit control board that corresponds to the selection.


2) Panel heater connector

This connector is used to perform an interlocked operation with a panel heater. Depending on the indoor unit control board specification, connect the cable to CN4Y as appropriate.



(3) Wiring

♦A basic connection method is shown below.



♦The length of the electrical wiring for the CN24RELAY-KIT-CM3 is 2 meters (6-1/2 ft.)


♦To extend this length, use sheathed 2-core cable.

Control cable type: CVV, CVS, CPEV or equivalent.

Cable size: 0.5 mm² ~ 1.25 mm² (16 to 22 AWG)

Don't extend the cable more than 10 meters (32ft)

Recommended circuit



(4) Wiring restrictions

♦Keep the length of the cable connecting to the circuit board of the indoor unit shorter than 10 meters (32ft).

♦Longer than 10 meters (32ft) could cause improper operation.

♦Use a transit relay when extending wiring such as remote wiring.

10 HUMIDIFIER CONTROL

10-1. Humidistat Control

Sequence of operation:

1. The humidistat closes CNF
2. The fan starts on high
3. CN25 provides 12VDC to turn on the Humidifier (do not exceed 1 Watt draw per relay)
4. When the Humidistat opens, the fan continues to run for 30 seconds to clear the ductwork of moist air.
5. If defrost starts during humidifier operation CN25 de-energizes.

Humidistat:

- Non-Voltage a-contact input
- Contact rating voltage $\geq 15\text{VDC}$
- Contact Rating Current $\geq 0.1\text{ A}$

The below table shows how the field-installed humidifier and fan speed are controlled.

Mode (function) No.		Humidistat output	Condition (no defrost/no error)	CN25 output	Fan speed
Wired remote controller (RF thermostat)					
13 (113)	16 (116)	CNF input			
2	1 a	OFF	Heat operation & Thermo OFF	OFF	RC setting
			Heat operation & Thermo ON		
		ON	Heat operation & Thermo OFF	OFF	RC setting
			Heat operation & Thermo ON	ON	High
	2	OFF	Heat operation & Thermo OFF	OFF	RC setting
			Heat operation & Thermo ON		
		ON	Heat operation & Thermo OFF	ON	High
			Heat operation & Thermo ON		
1	-	-	No humidifier operation	OFF	RC setting


^a Factory Settings

RC: Remote Controller

The fan continues to run for 30 seconds after the humidifier stops.

10-2. Installation

A basic connection method is shown below.



11-1. ERV Control

Sequence of operation:

1. The ERV demand switch closes CNER
2. 12VDC is provided to CN2C to turn on ERV
3. If the unit goes into defrost, CN2C stops 12VDC output

ERV Switch:

- Non-Voltage a-contact input
- Contact rating voltage $\geq 15\text{VDC}$
- Contact rating current $\geq 0.1\text{ A}$

The below table show how the field installed ERV is controlled.

ERV output CNER input	Function Mode26	Condition	Fan speed	CN2C output (=Fan output)
OFF	-	Cool/Heat/Fan operation	RC setting	ON
		Defrost	STOP	OFF
		STOP	STOP	OFF
ON	"1" ¹	Cool/Heat/Fan operation	RC setting	ON
		Defrost	STOP	OFF
		STOP	STOP	OFF
	"2"	Cool/Heat/Fan operation	RC setting	ON
		Defrost	STOP	OFF
		STOP	RC setting ^{2, 3}	ON

¹ Factory setting.


² When fan speed setting by RC is "Auto", Fan speed is fixed to "HIGH".

³ If ERV control is effective when STOP, IDU doesn't report fan status or PB error (Fan motor error).

RC: Remote controller

11-2. Installation

A basic connection method is shown below.



12 TROUBLESHOOTING


12-1. Cautions on troubleshooting

(1) Before troubleshooting, check the followings:

- 1 Check the power supply voltage.
- 2 Check the indoor/outdoor connecting wire for mis-wiring.

(2) Take care the followings during servicing.

- 1 Before servicing the air conditioner, be sure to turn off the remote controller first to stop the main unit, and then turn off the breaker.
- 2 When removing the indoor controller board, hold the edge of the board with care NOT to apply stress on the components.
- 3 When connecting or disconnecting the connectors, hold the housing of the connector. DO NOT pull the lead wires.



12-2. Self-check function

- Refer to the installation manual that comes with each remote controller for details.
- RF thermostat is not established.

[Output pattern A] Errors detected by indoor unit

IR wireless remote controller	Wired remote controller RF thermostat	Symptom	Remark
Beeper sounds/OPERATION INDICATOR lamp flashes (Number of times)	Check code		
1	P1	Intake sensor error	
2	P2, P9	Pipe (Liquid or 2-phase pipe) sensor error	
3	E6, E7	Indoor/outdoor unit communication error	
4	P4	Drain sensor error	
5	P5	Drain pump error	
6	P6	Freezing/Overheating safeguard operation	
7	EE	Communication error between indoor and outdoor units	
8	P8	Pipe temperature error	
9	E4	Remote controller signal receiving error	
10	—	—	
11	PB	Fan motor error	
12	Fb	Indoor unit control system error (memory error, etc.)	
No sound	—	No corresponding	

[Output pattern B] Errors detected by unit other than indoor unit (outdoor unit, etc.)

IR wireless remote controller	Wired remote controller RF thermostat	Symptom	Remark
Beeper sounds/OPERATION INDICATOR lamp flashes (Number of times)	Check code		
1	E9	Indoor/outdoor unit communication error (Transmitting error) (Outdoor unit)	For details, check the LED display of the outdoor controller board.
2	UP	Compressor overcurrent interruption	
3	U3, U4	Open/short of outdoor unit thermistors	
4	UF	Compressor overcurrent interruption (When compressor locked)	
5	U2	Abnormal high discharging temperature/49C worked/ insufficient refrigerant	
6	U1, Ud	Abnormal high pressure (63H worked)/ Overheating safeguard operation	
7	U5	Abnormal temperature of heat sink	
8	U8	Outdoor unit fan protection stop	
9	U6	Compressor overcurrent interruption/Abnormal of power module	
10	U7	Abnormality of super heat due to low discharge temperature	
11	U9, UH	Abnormality such as overvoltage or voltage shortage and abnormal synchronous signal to main circuit/Current sensor error	
12	—	—	
13	—	—	
14	Others	Other errors (Refer to the technical manual for the outdoor unit.)	

*1 If the beeper does not sound again after the initial two beeps to confirm the self-check start signal was received and the OPERATION INDICATOR lamp does not come on, there are no error records.

*2 If the beeper sounds three times continuously “beep, beep, beep (0.4 + 0.4 + 0.4 sec.)” after the initial two beeps to confirm the self-check start signal was received, the specified refrigerant address is incorrect.

- On IR wireless remote controller
The continuous buzzer sounds from receiving section of indoor unit.
Blink of operation lamp
- On wired remote controller
Check code displayed on the LCD.

- If the unit cannot be operated properly after the above test run has been performed, refer to the following table to remove the cause.

Symptom			Cause
Wired remote controller		LED 1, 2 (PCB in outdoor unit)	
PLEASE WAIT	For about 2 minutes following power-on	After LED 1, 2 are lighted, LED 2 is turned off, then only LED 1 is lighted. (Correct operation)	<ul style="list-style-type: none">• For about 2 minutes after power-on, operation of the remote controller is not possible due to system start-up. (Correct operation)
PLEASE WAIT → Error code	After about 2 minutes has expired following power-on	Only LED 1 is lighted. → LED 1, 2 blink.	<ul style="list-style-type: none">• Connector for the outdoor unit's protection device is not connected.• Reverse or open phase wiring for the outdoor unit's power terminal block (L1, L2, L3)
Display messages do not appear even when operation switch is turned ON (operation lamp does not light up).		Only LED 1 is lighted. → LED 1, 2 blinks twice, LED 2 blinks once.	<ul style="list-style-type: none">• Incorrect wiring between indoor and outdoor units (incorrect polarity of S1, S2, S3)• Remote controller wire short

On the IR wireless remote controller with conditions above, following phenomena takes place.

- No signals from the remote controller are accepted.
- OPE lamp is blinking.
- The buzzer makes a short ping sound.

Note:

Operation is not possible for about 30 seconds after cancellation of function selection. (Correct operation)

For description of each LED (LED1, 2, 3) provided on the indoor controller, refer to the following table.

LED 1 (power for microcomputer)	Indicates whether control power is supplied. Make sure that this LED is always lit.
LED 2 (power for remote controller)	Indicates whether power is supplied to the remote controller. This LED lights only in the case of the indoor unit which is connected to the outdoor unit refrigerant address "0".
LED 3 (communication between indoor and outdoor units)	Indicates state of communication between the indoor and outdoor units. Make sure that this LED is always blinking.

AUTO RESTART FUNCTION

Indoor controller board

This model is equipped with the AUTO RESTART FUNCTION.

When the indoor unit is controlled with the remote controller, the operation mode, set temperature, and the fan speed are memorized by the indoor controller board.

The auto restart function sets to work the moment the power has restored after power failure, then, the unit will restart automatically.

Set the AUTO RESTART FUNCTION using the wireless remote controller. (Mode no.1).


Function Table

Mode	Settings	Mode (function) No.	Setting no.	Initial setting	Check
		Wired remote controller (RF thermostat)			
Power failure auto restart	Not available	01	1	1	
	Available	(101)	2		
Indoor temperature detecting	Indoor unit operating average	02 (-)	1	1	
	Set by indoor unit's remote controller		2		
	Remote controller's internal sensor		3		
LOSSNAY connectivity	Not Supported	03 (103)	1	1	
	Supported (indoor unit is not equipped with outdoor air intake)		2		
	Supported (indoor unit is equipped with outdoor air intake)		3		
Power voltage	240V (230V)	04 (104)	1	1	
	220V (208V)		2		
Filter sign	100 Hr	07 (107)	1	3	
	2500 Hr		2		
	"No filter sign indicator"		3		
External static pressure	See Section 13.4 of the installation manual	08 (108)	1	2	
			2		
			3		
		10 (110)	1	1	
			2		
Humidifier control	Heat operation & Thermo ON	16 (116)	1	1	
	Heat operation		2		
Humidifier	Humidifier not present	13 (113)	1	1	
	Humidifier present		2		
Heater Control	Heater Not Present	11 (111)	1	1	
	Heater Present *1		2		
Heater control during defrost and error	Disable heater during Defrost and Error	23 (123)	1	1	
	Enable heater and fan during Defrost and Error *2		2		
Fan speed thermo off heating	Extra low	25 (125)	1	1	
	Stop		2		
	RC setting		3		
Fan speed thermo off cooling	RC setting	27 (127)	1	1	
	Stop		2		

*1 While the heater is on, the fan will operate at high speed regardless of the fan setting on the remote controller

*2 Heater will not operate during all error modes. Heater will only operate during a communication error between indoor unit and outdoor unit

Note: When CN4Y is used the fan is off when CN24 is energized which is only for use with supplemental heat that is not in the duct.



Warning

*** If a heater is installed in the duct, do not use Panel heater connector. By doing so, the fan will turn off when the heater is on, which may result in fire.**

12-3. Self-diagnosis action table

Note: Refer to the manual of outdoor unit for the details of display such as F, U, and other E.

Error Code	Abnormal point and detection method	Cause	Countermeasure
P1	Room temperature thermistor (TH1) 1 The unit is in three-minute resume prevention mode if short/open of thermistor is detected. Abnormal if the unit does not reset normally after three minutes. (The unit returns to normal operation, if it has normally reset.) 2 Constantly detected during cooling, drying and heating operation Short: 90°C [194°F] or more Open: -40°C [-40°F] or less	1 Defective thermistor characteristics 2 Contact failure of connector (CN20) on the indoor controller board (Insert failure) 3 Breaking of wire or contact failure of thermistor wiring 4 Defective indoor controller board	1-3 Check resistance value of thermistor. 0: [32°F].....15.0k" 10: [50°F].....9.6k" 20: [68°F].....6.3k" 30: [86°F].....4.3k" 40: [104°F]...3.0k" If you put force on (draw or bend) the lead wire with measuring resistance value of thermistor breaking of wire or contact failure can be detected. 2 Check contact failure of connector (CN20) on the indoor controller board. Refer to 12-5. Turn the power on again and check restart after inserting connector again. 4 Check room temperature display on remote controller. Replace indoor controller board if there is abnormal difference with actual room temperature. Turn the power off, and on again to operate after check.
P2	Pipe temperature thermistor/Liquid (TH2) 1 The unit is in three-minute resume prevention mode if short/open of thermistor is detected. Abnormal if the unit does not reset normally after three minutes. (The unit returns to normal operation, if it has normally reset.) 2 Constantly detected during cooling, drying, and heating (except defrosting) operation. Short: 90°C [194°F] or more Open: -40°C [-40°F] or less	1 Defective thermistor characteristics 2 Contact failure of connector (CN44) on the indoor controller board (Insert failure) 3 Breaking of wire or contact failure of thermistor wiring 4 Defective refrigerant circuit is causing thermistor temperature of 90°C [194°F] or more or -40°C [-40°F] or less. 5 Defective indoor controller board	1-3 Check resistance value of thermistor. For characteristics, refer to (P1) above. 2 Check contact failure of connector (CN44) on the indoor controller board. Refer to 12-5. Turn the power on again and check restart after inserting connector again. 4 Check pipe <liquid> temperature with remote controller in test run mode. If pipe <liquid> temperature is extremely low (in cooling mode) or high (in heating mode), refrigerant circuit may have defective. 5 Check pipe <liquid> temperature with remote controller in test run mode. If there is extreme difference with actual pipe <liquid> temperature, replace indoor controller board. Turn the power off, and on again to operate after check.
P4 (5701)	Contact failure of drain float switch (CN4F) 1 Extract when the connector of drain float switch is disconnected. (3 and 4 of connector CN4F is not short-circuited.) 2 Constantly detected during operation.	1 Contact failure of connector (Insert failure) 2 Defective indoor controller board	1 Check contact failure of float switch connector. Turn the power on again and check after inserting connector again. 2 Operate with connector (CN4F) short-circuited. Refer to 12-5. Replace indoor controller board if abnormality reappears.

Error Code	Abnormal point and detection method	Cause	Countermeasure
P6	Freezing/overheating protection is working 1 Freezing protection (Cooling mode) The unit is in six-minute resume prevention mode if pipe <liquid or condenser/evaporator> temperature stays under -15°C: [5°F] for three minutes after the compressor started. Abnormal if it stays under -15°C: [5°F] for three minutes again within 16 minutes after six-minute resume prevention mode. 2 Overheating protection (Heating mode) The units is in six-minute resume prevention mode if pipe <Liquid or condenser / evaporator> temperature is detected as over 70°C: [158°F] after the compressor started. Abnormal if the temperature of over 70°C: [158°F] is detected again within 10 minutes after six-minute resume prevention mode.	(Cooling or drying mode) 1 Clogged filter (reduced airflow) 2 Short cycle of air path 3 Low-load (low temperature) operation beyond the tolerance range 4 Defective indoor fan motor • Fan motor is defective. • Indoor controller board is defective. 5 Defective outdoor fan control 6 Overcharge of refrigerant 7 Defective refrigerant circuit (clogs) (Heating mode) 1 Clogged filter (reduced airflow) 2 Short cycle of air path 3 Over-load (high temperature) operation beyond the tolerance range 4 Defective indoor fan motor • Fan motor is defective. • Indoor controller board is defective. 5 Defective outdoor fan control 6 Overcharge of refrigerant 7 Defective refrigerant circuit (clogs) 8 Bypass circuit of outdoor unit is defective.	(Cooling or drying mode) 1 Check clogging of the filter. 2 Remove shields. 4 Refer to 12-8. DC Fan motor (FAN MOTOR/ INDOOR CONTROLLER BOARD) 5 Check outdoor fan motor. 6 & 7 Check operating condition of refrigerant circuit. (Heating mode) 1 Check clogs of the filter. 2 Remove shields. 4 Refer to 12-8. DC Fan motor (FAN MOTOR/ INDOOR CONTROLLER BOARD) 5 Check outdoor fan motor. 6~8 Check operating condition of refrigerant circuit.
P8	Pipe temperature <Cooling mode> Detected as abnormal when the pipe temperature is not in the cooling range 3 minutes after compressor start and 6 minutes after the liquid or condenser/evaporator pipe is out of cooling range. Note 1) It takes at least 9 minutes. to detect. Note 2) Abnormality P8 is not detected in drying mode. Cooling range : -3°C (-5.4°F) (TH-TH1) TH: Lower temperature between: liquid pipe temperature (TH2) and condenser/evaporator temperature (TH5) TH1: Intake temperature <Heating mode> When 10 seconds have passed after the compressor starts operation and the hot adjustment mode has finished, the unit is detected as abnormal when condenser/evaporator pipe temperature is not in heating range within 20 minutes. Note 3) It takes at least 27 minutes to detect abnormality. Note 4) It excludes the period of defrosting (Detection restarts when defrosting mode is over) Heating range : 3°C (5.4°F) (TH5-TH1)	1 Slight temperature difference between indoor room temperature and pipe <liquid or condenser / evaporator> temperature thermistor • Shortage of refrigerant • Disconnected holder of pipe <liquid or condenser / evaporator> thermistor • Defective refrigerant circuit 2 Converse connection of extension pipe (on plural units connection) 3 Converse wiring of indoor/ outdoor unit connecting wire (on plural units connection) 4 Defective detection of indoor room temperature and pipe <condenser / evaporator> temperature thermistor 5 Stop valve is not opened completely.	1~4 Check pipe <liquid or condenser / evaporator> temperature with room temperature display on remote controller and outdoor controller circuit board. (Conduct temperature check with outdoor controller circuit board after connecting 'A-Control Service Tool(PAC-SK52ST)'.) 2 & 3 Check converse connection of extension pipe or converse wiring of indoor/outdoor unit connecting wire.

Error Code	Abnormal point and detection method	Cause	Countermeasure
P9	Abnormality of pipe temperature thermistor / Condenser-Evaporator (TH5) 1 The unit is in three-minute resume protection mode if short/open of thermistor is detected. Abnormal if the unit does not get back to normal within three minutes. (The unit returns to normal operation, if it has normally reset.) 2 Constantly detected during cooling, drying, and heating operation (except defrosting) Short: 90°C [194°F] or more Open: -40°C [-40°F] or less	1 Defective thermistor characteristics 2 Contact failure of connector (CN44) on the indoor controller board (Insert failure) 3 Breaking of wire or contact failure of thermistor wiring 4 Temperature of thermistor is 90°C [194°F] or more or -40°C [-40°F] or less caused by defective refrigerant circuit. 5 Defective indoor controller board	1-3 Check resistance value of thermistor. For characteristics, refer to (P1) above. 2 Check contact failure of connector (CN44) on the indoor controller board. Refer to 12-5. Turn the power on and check restart after inserting connector again. 4 Operate in test run mode and check pipe <condenser / evaporator> temperature. If pipe <condenser / evaporator> temperature is extremely low (in cooling mode) or high (in heating mode), refrigerant circuit may have defect. 5 When no problems are found in 1-4 above, replace the indoor unit control board.
E0 or E4	Remote controller transmission error(E0)/signal receiving error(E4) 1 Abnormal if main or sub remote controller can not receive normally any transmission from indoor unit of refrigerant address "0" for three minutes. (Error code : E0) 2 Abnormal if sub remote controller could not receive for any signal for two minutes. (Error code: E0) 1 Abnormal if indoor controller board can not receive normally any data from remote controller board or from other indoor controller board for three minutes. (Error code: E4) 2 Indoor controller board cannot receive any signal from remote controller for two minutes. (Error code: E4)	1 Contact failure at transmission wire of remote controller 2 All remote controllers are set as "sub" remote controller. In this case, E0 is displayed on remote controller, and E4 is displayed at LED (LED1, LED2) on the outdoor controller circuit board. 3 Mis-wiring of remote controller 4 Defective transmitting receiving circuit of remote controller 5 Defective transmitting receiving circuit of indoor controller board of refrigerant address "0" 6 Noise has entered into the transmission wire of remote controller.	1 Check disconnection or looseness of indoor unit or transmission wire of remote controller. 2 Set one of the remote controllers "main". If there is no problem with the action above. 3 Check wiring of remote controller. • Total wiring length: max.500m (Do not use cable 5 3 or more) • The number of connecting indoor units: max.16units • The number of connecting remote controller: max.2units When it is not the above-mentioned problem of 1~3 4 Diagnose remote controllers. a) When "RC OK" is displayed, Remote controllers have no problem. Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board. b) When "RC NG" is displayed, Replace remote controller. c) When "RC E3" is displayed, d) When "ERC 00-06" is displayed, [c),d)→Noise may be causing abnormality.] * If the unit is not normal after replacing indoor controller board in group control, indoor controller board of address "0" may be abnormal.
E3 or E5	Remote controller transmission error(E3)/signal receiving error(E5) 1 Abnormal if remote controller could not find blank of transmission path for six seconds and could not transmit. (Error code: E3) 2 Remote controller receives transmitted data at the same time, compares the data, and when detecting it, judges different data to be abnormal 30 continuous times. (Error code: E3) 1 Abnormal if indoor controller board could not find blank of transmission path. (Error code: E5) 2 Indoor controller board receives transmitted data at the same time, compares the data, and when detecting it, judges different data to be abnormal 30 continuous times. (Error code: E5)	1 Two remote controller are set as "main." (In case of 2 remote controllers) 2 Remote controller is connected with two indoor units or more. 3 Repetition of refrigerant address 4 Defective transmitting receiving circuit of remote controller 5 Defective transmitting receiving circuit of indoor controller board 6 Noise has entered into transmission wire of remote controller.	1 Set a remote controller to main, and the other to sub. 2 Remote controller is connected with only one indoor unit. 3 The address changes to a separate setting. 4~6 Diagnose remote controller. a) When "RC OK" is displayed, remote controllers have no problem. Turn the power off, and on again to check. When becoming abnormal again, replace indoor controller board. b) When "RC NG" is displayed, replace remote controller. c) When "RC E3" or "ERC 00-66" is displayed, noise may be causing abnormality.

Error Code	Abnormal point and detection method	Cause	Countermeasure
E6	Indoor/outdoor unit communication error (Signal receiving error) 1 Abnormal if indoor controller board cannot receive any signal normally for six minutes after turning the power on. 2 Abnormal if indoor controller board cannot receive any signal normally for three minutes. 3 Consider the unit as abnormal under the following condition: When two or more indoor units are connected to an outdoor unit, indoor controller board cannot receive a signal for three minutes from outdoor controller circuit board, a signal which allows outdoor controller circuit board to transmit signals.	1 Contact failure, short circuit or, mis-wiring (converse wiring) of indoor/outdoor unit connecting wire 2 Defective transmitting receiving circuit of indoor controller board 3 Defective transmitting receiving circuit of indoor controller board 4 Noise has entered into indoor/outdoor unit connecting wire.	* Check LED display on the outdoor control circuit board. (Connect A-control service tool, PAC-SK52ST.) Refer to EA-EC item if LED displays EA-EC. 1 Check disconnection or looseness of indoor/outdoor unit connecting wire of indoor unit or outdoor unit. Check all the units in case of twin triple indoor unit system. 2-4 Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board or outdoor controller circuit board. * Other indoor controller board may have defect in case of twin triple indoor unit system.
E7	Indoor/outdoor unit communication error (Transmitting error) Abnormal if "1" receiving is detected 30 times continuously though indoor controller board has transmitted "0".	1 Defective transmitting receiving circuit of indoor controller board 2 Noise has entered into power supply. 3 Noise has entered into outdoor control wire.	1-3 Turn the power off, and on again to check. If abnormality generates again, replace indoor controller board.
Fb	Indoor controller board Abnormal if data cannot be read normally from the nonvolatile memory of the indoor controller board.	1 Defective indoor controller board	1 Replace indoor controller board.
E1 or E2	Remote controller control board 1 Abnormal if data cannot be read normally from the nonvolatile memory of the remote controller control board. (Error code: E1) 2 Abnormal if the clock function of remote controller cannot be operated normally. (Error code: E2)	1 Defective remote controller	1 Replace remote controller.
PB	Fan motor error Abnormal if a) or b) is detected during fan motor operation. a) When the number of rotations is detected to be below the lower limit for 30 seconds. b) When the number of rotations is detected to be above the upper limit for 30 seconds.	1 Motor or fan cannot rotate because of foreign object, etc. 2 Motor wire disconnection or connector disconnection or looseness 3 Motor failure	1 Remove the foreign object causing the problem. 2 Check disconnection of the motor wiring or connector disconnection. 3 Replace the failed motor.

12-4. Troubleshooting by inferior phenomena

Note: Refer to the manual of outdoor unit for the detail of remote controller.

Phenomena	Cause	Countermeasure
(1) LED2 on indoor controller board is off.	<ul style="list-style-type: none"> When LED1 on indoor controller board is also off. <ol style="list-style-type: none"> Power supply of rated voltage is not supplied to outdoor unit. Defective outdoor controller circuit board Power supply of 208~230V is not supplied to indoor unit. Defective indoor controller board 	<ol style="list-style-type: none"> Check the voltage of outdoor power supply terminal block (L, N) or (L3, N). <ul style="list-style-type: none"> When AC 208~230V is not detected. Check the power wiring to outdoor unit and the breaker. When AC 208~230V is detected. —Check 2 (below). Check the voltage between outdoor terminal block S1 and S2. <ul style="list-style-type: none"> When AC 208~230V is not detected. Check the fuse on outdoor controller circuit board. Check the wiring connection. When AC 208~230V is detected. —Check 3 (below). Check the voltage between indoor terminal block S1 and S2. <ul style="list-style-type: none"> When AC 208~230V is not detected. Check indoor/outdoor unit connecting wire for mis-wiring. When AC 208~230V is detected. —Check 4 (below). Check the fuse on indoor controller board. Check the wiring connection. If no problem are found, indoor controller board is defective.
(2) LED2 on indoor controller board is blinking.	<ul style="list-style-type: none"> When LED1 on indoor controller board is also blinking. Connection failure of indoor/outdoor unit connecting wire When LED1 is lit. <ol style="list-style-type: none"> Mis-wiring of remote controller wires Under twin triple indoor unit system, 2 or more indoor units are wired together. Refrigerant address for outdoor unit is wrong or not set. Under grouping control system, there are some units whose refrigerant address is 0. Short-cut of remote controller wires Defective remote controller 	<p>Check indoor/outdoor unit connecting wire for connection failure.</p> <ol style="list-style-type: none"> Check the connection of remote controller wires in case of twin triple indoor unit system. When 2 or more indoor units are wired in one refrigerant system, connect remote controller wires to one of those units. Check the setting of refrigerant address in case of grouping control system. If there are some units whose refrigerant addresses are 0 in one group, set one of the units to 0 using SW1 (3-6) on outdoor controller circuit board. & 4 Remove remote controller wires and check LED2 on indoor controller board. <ul style="list-style-type: none"> When LED2 is blinking, check the short-cut of remote controller wires. When LED2 is lit, connect remote controller wires again and: if LED2 is blinking, remote controller is defective; if LED2 is lit, connection failure of remote controller terminal block etc. has returned to normal.


12-5. Test point diagram

12-5-1. Power supply board

PVA-A12AA7 PVA-A30AA7

PVA-A18AA7 PVA-A36AA7

PVA-A24AA7 PVA-A42AA7



CND Power supply voltage (208 - 230VAC)

CNMF Fan motor output
 1 - 4: 310 - 340 VDC
 5 - 4: 15 VDC
 6 - 4: 0 - 6.5 VDC
 7 - 4: Stop 0 or 15 VDC
 Run 7.5 VDC
 (0 - 15 pulse)

CNXA1 Connect to the indoor controller board

CNXB1 Connect to the indoor controller board

CNXC1 Connect to the indoor controller board

CNXA2 Connect to the indoor power board

CNXB2 Connect to the indoor power board

CNXC2 Connect to the indoor power board

(*1)

V_{FG} Voltage on the (-) side of PC51 and C25
 (Same with the voltage between 7 (+) and 4 (-) of CNMF)

V_{CC} Voltage between the C25 pins 15 VDC
 (Same with the voltage between 5 (+) and 4 (-) of CNMF)


V_{sp} Voltage between the C53 pins
 0VDC (with the fan stopped)
 1 - 6.5VDC (with the fan in operation)
 (Same with the voltage between 6 (+) and 4 (-) of CNMF)

12-5-2. Indoor controller board

PVA-A12AA7 PVA-A30AA7

PVA-A18AA7 PVA-A36AA7

PVA-A24AA7 PVA-A42AA7



SWE Emergency operation

SW1 Model selection

SW2 Capacity setting

CN105 Radio frequency interface

CN32 Remote start/stop adapter

CN22 For MA remote controller cable connection (10 - 13 VDC)

CN51 Centralized control

CN41 JAMA standard HA terminal A

CN44 Thermistor (liquid/condenser/evaporator temperature)

CN4F Float sensor

CN20 Thermistor (Inlet temperature)

CN24-1 1st Heater control (12VDC)

CN24-2 2nd Heater control

CN4Y For fan control

CN3C Indoor-outdoor transmission (0 - 24VDC)

CN90 Wireless remote controller

CNXA2 Connect to the indoor controller board

CNXB2 Connect to the indoor controller board

CNXC2 Connect to the indoor controller board

CNXA1 Connect to the indoor power board

CNXB1 Connect to the indoor power board

CNXC1 Connect to the indoor power board

CNER ERV control

CN2C ERV input

CN25 Humidity control

CNF Humidity input

12-6. Trouble criterion of main parts

PVA-A12AA7 PVA-A30AA7
PVA-A18AA7 PVA-A36AA7
PVA-A24AA7 PVA-A42AA7

Part name	Check method and criterion				
Room temperature thermistor (TH1)	<div>Measure the resistance with a tester. (Part temperature 10C (50F) ~ 30C (86F))</div> <table><tr><td>Normal</td><td>Abnormal</td></tr><tr><td>4.3k~9.6k</td><td>Opened or short-circuited</td></tr></table>	Normal	Abnormal	4.3k~9.6k	Opened or short-circuited
Normal		Abnormal			
4.3k~9.6k		Opened or short-circuited			
Pipe temperature thermistor/liquid (TH2)					
Condenser/evaporator temperature thermistor (TH5)					
Wiring diagram	<div><p>The diagram illustrates the electrical connections for a motor control system. It is divided into three main sections: external inputs, the internal board components, and the motor itself.</p><ul style="list-style-type: none">External Inputs (Left): Four terminals are shown: Vm (Power supply for motor), Vcc (Power supply for control), Vsp (Speed command voltage), and PG (Pulse output for rotation). A GND terminal is at the bottom.Board with build-in motor (Center): This section contains several key components:<ul style="list-style-type: none">Regulator: Connected to Vm and Vcc, it provides a stable power source for the control circuitry.Hall IC: Receives Vcc and provides feedback signals to the Power device.Power device: Receives Vsp and PG signals. It is connected to the Regulator and the Pre driver.Pre driver: Receives signals from the Power device and the Hall IC. It drives the motor winding.Current detecting resistor: Located between the Pre driver and the motor winding, it monitors the current flowing through the motor.Motor (Right): The motor winding is connected to the Pre driver and the current detecting resistor. The entire motor assembly is enclosed in a dashed box labeled 'Motor'.</div>				

12-7. Thermistor

<Thermistor Characteristic graph>


Thermistor for lower temperature

Room temperature thermistor (TH1)
Pipe temperature thermistor (TH2)
Condenser/evaporator temperature thermistor (TH5)

Thermistor $R_0 = 15 \text{ k}\Omega \pm 3\%$
Fixed number of $B = 3480 \text{ k}\Omega \pm 2\%$

$$R_t = 15 \exp \left\{ 3480 \left(\frac{1}{273+t} - \frac{1}{273} \right) \right\}$$

0°C (32°F)	15 k Ω
10°C (50°F)	9.6 k Ω
20°C (68°F)	6.3 k Ω
25°C (77°F)	5.2 k Ω
30°C (86°F)	4.3 k Ω
40°C (104°F)	3.0 k Ω



12-8. DC Fan motor (FAN MOTOR/INDOOR CONTROLLER BOARD)


Check method of DC fan motor (fan motor/indoor controller circuit board)

1 Notes

- High voltage is applied to the connector (CNMF) for the fan motor. Give attention to the service.
- Do not pull out the connector (CNMF) for the motor with the power supply on.
(It causes trouble of the indoor controller circuit board and fan motor.)

2 Self check

Symptom : The indoor fan cannot turn around.



	PVA-A12,18,24,30AA7	PVA-A36,42AA7
Measuring points	Resistance	
pin 1 - pin 4	O.L.	1MΩ
pin 3 - pin 4	50kΩ	47kΩ
pin 6 - pin 4	150kΩ	143kΩ
pin 7 - pin 4	O.L.	O.L.

*To measure the resistance, connect the negative (-) end of the tester to pin 4.

12-9. Functions of dip switch and jumper wire

Each function is controlled by the dip switch and the jumper wire on control p.c. board.

SW1 and SW2 are equipped only for service parts.

Model setting and capacity setting are memorized in the nonvolatile memory of the control p.c. board of the unit.

(Marks in the table below) Jumper wire (○ : Short × : Open)

Jumper wire	Functions	Setting by the dip switch and jumper wire	Remarks																	
SW1	Model settings	For service board <div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>																		
SW2	Capacity settings	<table><tr><th>Model</th><th>Service Board</th></tr><tr><td>PVA-A12AA7</td><td><div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div></td></tr><tr><td>PVA-A18AA7</td><td><div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div></td></tr><tr><td>PVA-A24AA7</td><td><div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div></td></tr><tr><td>PVA-A30AA7</td><td><div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div></td></tr><tr><td>PVA-A36AA7</td><td><div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div></td></tr><tr><td>PVA-A42AA7</td><td><div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div></td></tr></table>	Model	Service Board	PVA-A12AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>	PVA-A18AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>	PVA-A24AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>	PVA-A30AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>	PVA-A36AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>	PVA-A42AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>				
Model	Service Board																			
PVA-A12AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>																			
PVA-A18AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>																			
PVA-A24AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>																			
PVA-A30AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>																			
PVA-A36AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>																			
PVA-A42AA7	<div><div><div>1</div><div>2</div><div>3</div><div>4</div><div>5</div></div><div><div><div></div><div></div><div></div><div></div><div></div></div><div>ON OFF</div></div></div>																			
J41 J42	Pair number setting with wireless remote controller	<table><tr><th rowspan="2">Wireless remote controller setting</th><th colspan="2">Control PCB setting</th></tr><tr><th>J41</th><th>J42</th></tr><tr><td>0</td><td>○</td><td>○</td></tr><tr><td>1</td><td>×</td><td>○</td></tr><tr><td>2</td><td>○</td><td>×</td></tr><tr><td>3 ~ 9</td><td>×</td><td>×</td></tr></table>	Wireless remote controller setting	Control PCB setting		J41	J42	0	○	○	1	×	○	2	○	×	3 ~ 9	×	×	<Settings at time of factory shipment> Wireless remote controller: 0 Control PCB: ○ (for both J41 and J42) Four pair number settings are supported. The pair number settings of the wireless remote controller and indoor control PCB (J41/J42) are given in the table on the left. ('×' in the table indicates the jumper line is disconnected.)
Wireless remote controller setting	Control PCB setting																			
	J41	J42																		
0	○	○																		
1	×	○																		
2	○	×																		
3 ~ 9	×	×																		
JP1	Unit type setting	<table><tr><th>Model</th><th>JP1</th></tr><tr><td>Without TH5</td><td>○</td></tr><tr><td>With TH5</td><td>×</td></tr></table>	Model	JP1	Without TH5	○	With TH5	×	There is no jumper (JP1) because these models have the cond./eva. temperature thermistor (TH5).											
Model	JP1																			
Without TH5	○																			
With TH5	×																			
JP3	Indoor controller board type setting	<table><tr><th>Indoor controller board type</th><th>JP3</th></tr><tr><td>Factory shipment</td><td>○</td></tr><tr><td>Service parts</td><td>○</td></tr></table>	Indoor controller board type	JP3	Factory shipment	○	Service parts	○												
Indoor controller board type	JP3																			
Factory shipment	○																			
Service parts	○																			

13 DISASSEMBLY PROCEDURE

13-1. Control box

Exercise caution when removing heavy parts.

1. Remove the Electric panel (2 screws)




Fig. 1

13-2. Thermistor (Return Air)

Exercise caution when removing heavy parts.

1. Remove the Filter panel (2 thumbscrews).
2. Remove the Blower panel (2 screws).




Fig. 2

3. Remove the cover over the Return Air thermistor box and unplug the thermistor.
4. Pull out the thermistor holder and thermistor inside the box.




Fig. 3

13-3. Coil Assembly

Exercise caution when removing heavy parts.

1. Remove the Electrical, Blower and Filter panel indicated in sections 1 and 2.
2. Remove the Coil panel by removing all of the screws securing it to the (3) smaller panels for refrigerant and drain lines.




Fig. 4

3. Slide the smaller panels in the directions indicated and remove.




Fig. 5

4. Remove the (1 or 2) brackets that secure the coil, unplug the thermistors from the control board and route the wires out of the control box area and into the coil section. Next, slide the coil from the frame.




Fig. 6




Fig. 7

5. Remove the plate covering the coil assembly to access the thermistors.




Fig. 8

6. Remove lower and side drain pan.




Fig. 9

13-4. Blower/Fan Assembly

Exercise caution when removing heavy parts.

1. Remove the Blower and Filter panel (along with filter if installed) indicated in section 2.
2. Remove the (1 or 2) brackets that secure the coil assembly.




Fig. 10

3. Remove the door that covers the small enclosure attached to the fan assembly (Fig.11).
Unplug the motor and route the wire harness out of the enclosure.
4. Remove the (2) screws that secure the fan assembly and slide out.




Fig. 11

This product is designed and intended for use in the residential,
commercial and light-industrial environment.

Please be sure to put the contact address/telephone number on
this manual before handing it to the customer.

mitsubishi **MITSUBISHI ELECTRIC US, INC.**

www.mitsubishielectric-usa.com

Toll Free: 800-433-4822