


SPECIFICATIONS

- **Operating Voltage:** 18-30 VAC
- **Maximum Current:** 2.0 Amps

NON HEAT PUMP – INSTALLATION INSTRUCTIONS

1. Verify power is OFF to heater controls.
2. Wire nut one black wire of thermostat to 24 VAC (red) wire.
3. Wire nut the second black wire of the thermostat to the heating device (white) wire and the fan (green) wire in Electric heat applications.
4. Verify wiring is correct and then apply power.
5. Verify system functions correctly.



- * Fan (green) wire must be connected to heat system (white) wire for electric heat applications.

HEAT PUMP – INSTALLATION INSTRUCTIONS

1. Verify power is OFF to heater controls.
2. Wire nut one black wire of thermostat to 24 VAC (red) wire and the reversing valve (blue) wire if it is heat active.
3. Wire nut the second black wire of the thermostat to the compressor (yellow) wire and the fan (green) wire.
4. Verify wiring is correct and then apply power.
5. Verify system functions correctly.

