

Made in USA

Auto Changeover

85-250 VAC Hardwire

SC900V

2 or 4 Pipe Fan Coil Thermostat, 3 Speed

- 2-pipe systems
- 4-pipe systems
- Pipe sensor compatible
- Configurable
- Large display with backlight
- Selectable fahrenheit or celsius
- Relay outputs (minimum voltage drop in thermostat)
- Remote sensor compatible




Installation, Operation & Application Guide

For more information on our complete range of American-made products – plus wiring diagrams, troubleshooting tips and more, visit us at [www.icmcontrols.com](http://www.icmcontrols.com)



Icon Descriptions



Specifications

**Electrical rating:** 85-250 VAC, 6 amp maximum per output  
**Temperature control range:** 45°F to 90°F (7°C to 32°C)    **Accuracy:** ± 1°F (± 0.5°C)  
**Timing:** Backlight Operation: 10 seconds  
**Terminations:** L, N, Heat, Cool, FH, FM, FL, PS, RS, SC

Important Safety Information

**ELECTRICAL SHOCK HAZARD** – Turn off power at the main service panel by removing the fuse or switching the appropriate circuit breaker to the OFF position before working on a high voltage thermostat.

**WARNING!:** Always turn off power at the main power supply before installing, cleaning, or removing thermostat.

- This thermostat is for 85-250 VAC applications only; do not use on voltages over 250 VAC
- Use this thermostat only as described in this manual

Package Contents/Tools Required

**Package includes:** SC900V thermostat on base, thermostat cover, wiring labels, screws and wall anchors, Installation, Operation and Application Guide

**Tools required for installation:** Drill with 3/16" bit, hammer, screwdriver

To Remove Existing Thermostat

**ELECTRICAL SHOCK HAZARD** – Turn off power at the main service panel by removing the fuse or switching the appropriate circuit breaker to the OFF position before removing the existing thermostat.

1. Turn off power to the heating and cooling system by removing the fuse or switching the appropriate circuit breaker off.
2. Remove cover of old thermostat. This should expose the wires.
3. Label the existing wires with the enclosed wire labels before removing wires.
4. After labeling wires, remove wires from wire terminals or remove wire nuts.
5. Remove existing thermostat base from wall.
6. Refer to the following section for instructions on how to install this thermostat.

To Install Thermostat

**ELECTRICAL SHOCK HAZARD** – Turn off power at the main service panel by removing the fuse or switching the appropriate circuit breaker to the OFF position before removing the existing thermostat.


**IMPORTANT:** Thermostat installation must conform to local and national building and electrical codes and ordinances.

⚡ **Note:** Mount the thermostat about five feet above the floor. Do not mount the thermostat on an outside wall, in direct sunlight, behind a door, or in an area affected by a vent or duct.

1. Turn off power by removing the fuse or switching the appropriate circuit breaker off.
2. To remove cover, remove screw and pull gently at the seam at the top.
3. Set thermostat away from working area.
4. Align thermostat base with junction box mounting holes and feed the control wires through hole.
5. Use supplied screws to mount thermostat base to junction box.
6. Wire nut the thermostat wires to your system wires.
7. Gently tug wire to be sure of proper connection. Double check that each wire is connected to the proper terminal.
8. Snap thermostat to base that is mounted on the wall. Refasten with screw.
9. Turn on power to the system at the main service panel.
10. Test thermostat operation as described in “Testing the Thermostat”.

**CAUTION!:** Be sure exposed portion of wires does not touch other wires.

Wiring Diagrams



Wire Designator Descriptions

L – 120 VAC Hot	Black	FM – Fan Medium	Yellow
N – 120 VAC Neutral	White	FL – Fan Low	Gray
H – Heat	Red	PS – Pipe Sensor (optional)	Orange/White
C – Cool	Blue	RS – Remote Sensor (optional)	Red/White
FH – Fan High	Purple	SC – Sensor Common	Blue/White

Configuration Mode

The configuration mode is used to set the **SC900V** to match your heating/cooling system.

To configure the **SC900V**, perform the following steps:

1. Verify the **SC900V** is in the **OFF** mode. Press the **SYS** (left) button until off mode displays.
2. Press the **CONFIG** button for 5 seconds while the **SC900V** is in **OFF** mode.

Press the **up** or **down** button to change settings within each screen.



Press the **CONFIG** button to advance to the next screen.



⚡ **Note:** Pressing the **SYS** button will return you to the previous screen.

To exit configuration mode, press the **CONFIG** switch for 5 seconds.

Configuration Mode Settings

1 – System

Select the type of operation you require.

1. Heat Only is for a system with only heating.
  2. Cool Only is for a system with only cooling.
  3. 2-Pipe Manual Changeover is for a 2 pipe system that handles both heating and cooling. The user selects whether the system will be set to heating or set to cooling.
  4. 2-Pipe Seasonal Changeover is for a 2 pipe system that handles both heating and cooling. The thermostat selects whether the system will be set to heat or set to cool based on the pipe sensor temperature.
  5. 2-Pipe Manual Changeover with Auxiliary is for a 2 pipe system that handles both heating and cooling. The user selects whether the system will be set to heat or set to cool. If set to heat and the pipe sensor indicates there is not heat, the auxiliary output will be turned on.
  6. 4-Pipe Manual Changeover is for a 4 pipe system. The user selects whether the system will be set to heat, cool or off.
  7. 4-Pipe Auto Changeover is for a 4 pipe system. The user selects whether the system will be set to heat, cool, heat & cool or off.
- |                                |   |
|--------------------------------|---|
| “1” Heat only                  | “5” 2-pipe seasonal changeover w auxiliary    |
| “2” Cool only                  | “6” 4-pipe manual changeover                  |
| “3” 2-pipe manual changeover   | “7” 4-pipe auto changeover ( <b>Default</b> ) |
| “4” 2-pipe seasonal changeover |   |

2 – Temperature Scale

This thermostat can function in Fahrenheit and Celsius.

F = Fahrenheit (**Default**)

C = Celsius

3 – Valve Type

This thermostat operates with Normally Open or Normally Closed valves. Select the correct valve type for your system.

no = Normally Open (**Default**)

nc = Normally Closed

4 – Temperature Sensor

Select the type of room temperature sensor you are using.

o = Onboard temperature sensor (**Default**)

r = Remote temperature sensor

5 – Fan Operation

Select either Automatic Fan or Continuous Fan.

Automatic Fan will automatically adjust the fan speed (Low, Medium, High) based on the set point and room temperature. The more the room temperature is from the set point the faster the fan will operate. The fan will be off in OFF mode.

Continuous Fan will run the fan at the fan speed that is selected with the FAN button. It can be turned OFF only when in OFF mode.

A = Automatic Fan (**Default**)

C = Continuous Fan

