



Wi-Fi Temperature Sensors

Ultra-low power Wi-Fi



ACC-TSENWIFIPRO
5.2"H x 3.1"W x 1.4"D

- Multiple uses:
 - Remote temperature sensor
 - Outdoor temperature sensor**
 - Indoor room temperature averaging
 - Supply Air temperature sensor
 - Return Air temperature sensor
 - Walk-in refrigeration (mid temp or low temp) monitoring
- Selectable internal or external temperature sensor
- **Stainless 'external' duct sensor included**
- Compatible with most Venstar Wi-Fi thermostats*
- Easy setup using the Venstar Configurator App
- Automatic temperature averaging when multiple sensors are used
- Up to 20 sensors per subnet
- Operating temperature range:
 - 0° – 120° F w/alkaline batteries
 - 20° – 130° F w/lithium batteries
- Dual power supply, (4) AA batteries (included) or 24vac
- Expected battery life: Indoor sensor sample rate of 1 per minute: > year (Assumes strong constant Wi-Fi signal strength and connection).



ACC-TSENWIFIMINI
2.5"H x 2.5"W x 1.0"D

- Multiple uses:
 - Remote temperature sensor
 - Outdoor temperature sensor**
- Compatible with most Venstar Wi-Fi thermostats*
- Easy setup using the Venstar Configurator App
- Automatic temperature averaging when multiple sensors are used
- Up to 8 sensors per subnet
- Operating temperature range:
 - 0° – 120° F w/alkaline batteries
 - 20° – 130° F w/lithium batteries
- Small Size
- Uses (2) AAA batteries (included)
- Expected battery life: Indoor sensor sample rate of 1 per minute: > year (Assumes strong constant Wi-Fi signal strength and connection).

Compatible with Venstar Wi-Fi thermostats including ColorTouch, Explorer and Explorer Mini



ColorTouch



EXPLORER



EXPLORER Mini

*Not compatible with T5800, T5900, T6800 & T6900

**Not to be mounted in areas receiving direct rain or snow