




THE MARK (→) SHOWS PIPING DIRECTION



REQUIRED SPACE



WIRELESS REMOTE CONTROLLER (ARC480A83)



BLADE ANGLE

UP / DOWN (AUTOMATIC)

RIGHT / LEFT (MANUAL)

COOLING

DRY



HEATING

FAN



STANDARD LOCATIONS OF WALL HOLES

