

### Thermal Expansion Valves

- For use with Bosch equipment



Order #	Mfg. #	Description
<b>B22-095</b>	8-733-941-929	Thermal Expansion Valve
<b>B22-096</b>	8-733-953-236	Thermal Expansion Valve

Order #	Mfg. #	Description
<b>B22-098</b>	8-733-953-237	Thermal Expansion Valve
<b>B22-100</b>	8-733-953-235	Thermal Expansion Valve

### Reversing Valves

- For use with Bosch equipment



Order #	Mfg. #	Description
<b>B22-093</b>	8-733-953-332	Reversing Valve
<b>B22-097</b>	8-733-953-159	Reversing Valve

### Compressors

- For use with Bosch equipment



Fig.	Order #	Mfg. #	Description
A	<b>B87-376</b>	8-733-941-865	Compressor Bosch
B	<b>B87-380</b>	8-733-953-165	DC Inverter Compressor

Fig.	Order #	Mfg. #	Description
B	<b>B87-381</b>	8-733-953-192	DC Inverter Compressor

### Motors

- For use with Bosch equipment



Order #	Mfg. #	Description
<b>S59-756</b>	8-733-941-930	Blower Motor
<b>S59-757</b>	8-733-941-927	Blower Motor
<b>S59-758</b>	8-733-953-241	ECM Motor
<b>S59-759</b>	8-733-953-242	ECM Motor
<b>S59-760</b>	8-733-953-243	ECM Motor

Order #	Mfg. #	Description
<b>S59-753</b>	8-733-953-322	Indoor Blower Motor
<b>S59-762</b>	8-733-954-668	Indoor Blower Motor
<b>S83-118</b>	8-733-953-149	Outdoor ECM Motor
<b>S83-119</b>	8-733-953-312	Outdoor ECM Motor