

# REPAIR PARTS

---

## AWUT Electric Heat Air Handler

AWUT310516AA  
AWUT310516AB  
AWUT310516AC  
AWUT310816AA  
AWUT310816AB  
AWUT321016AA  
AWUT321016AB  
AWUT370516AA  
AWUT370516AB  
AWUT370816AA  
AWUT370816AB  
AWUT371016AA  
AWUT371016AB



This manual is to be used by qualified technicians only.

This manual replaces RP-4314A

© 2020 - 2021 Goodman Manufacturing Company, L.P. ♦ 5151 San Felipe St, Suite 500 ♦ Houston, TX 77056

## Important Information

---

### Index

Functional Parts List .....	3
Illustration and Parts .....	4 - 11

*Views shown are for parts illustrations only, not servicing procedures.*

#### Text Codes:

AR - As Required

NA - Not Available

NS - Not Shown

00000000 - See Note

QTY - Quantity    Example (QTY 3) (If Quantity not shown, Quantity = 1)

M - Model        Example (M1) (If M Code not shown, then part is used on all Models)

#### Expanded Model Nomenclature:

Example

M1 - Model#1

M2 - Model#2

M3 - Model#3

Goodman Manufacturing Company, L.P. is not responsible for personal injury or property damage resulting from improper service. Review all service information before beginning repairs.

Warranty service must be performed by an authorized technician, using authorized factory parts. If service is required after the warranty expires, Goodman Manufacturing Company, L.P. also recommends contacting an authorized technician and using authorized factory parts.

Goodman Manufacturing Company, L.P. reserves the right to discontinue, or change at any time, specifications or designs without notice or without incurring obligations.

For assistance within the U.S.A. contact:

Homeowner Support

Goodman Manufacturing Company, L.P.

19001 Kermier Road

Waller, Texas 77484

877-254-4729-Telephone

713-863-2382-Facsimile

For assistance outside the U.S.A. contact:

International Division

Goodman Manufacturing Company, L.P.

19001 Kermier Road

Waller, Texas 77484

713-861-2500-Telephone

713-863-2382-Facsimile

# Functional Parts

## Part

**No:**                      **Description:**

---


CONT2P040024V	CONT, 2 POLE, 40 AMP, 24 VAC
BT1420032	ELEMENT, 4.8 KW LARGE HEATER (M1, M2, M3, M8, M9)
BT1420040	ELEMENT, 7.3KW HEATER (M4, M5, M10, M11)
BT1420039	ELEMENT, 9.8KW HEATER (M6, M7)
0131M00504	MOTOR PROGRAMMED (M1, M2)
0131M00505	MOTOR PROGRAMMED (M4, M6)
0131M00506	MOTOR PROGRAMMED (M8, M10, M12)
0131M01020	MOTOR PROGRAMMED (M3)
0131M01021	MOTOR PROGRAMMED (M5, M7)
0131M01022	MOTOR PROGRAMMED (M9, M11, M13)
0130M00138	TRANSFORMER, 208/230, 24V
0151M00066	VALVE, TXV R-410A BOOSTER CHG

### Expanded Model Nomenclature

M1 - AWUT310516AA
M2 - AWUT310516AB
M3 - AWUT310516AC
M4 - AWUT310816AA
M5 - AWUT310816AB
M6 - AWUT321016AA
M7 - AWUT321016AB
M8 - AWUT370516AA
M9 - AWUT370516AB
M10 - AWUT370816AA
M11 - AWUT370816AB
M12 - AWUT371016AA
M13 - AWUT371016AB

WRAPPER ASSEMBLY

WRAPPER ASSEMBLY



# WRAPPER ASSEMBLY

Ref. Part			Ref. Part		
No:	No:	Description:	No:	No:	Description:

---

## Image 1:


11	3702005	WRAPPER, LARGE
41	3701535	FRONT ACCESS PANEL LRG
51	3702500	BRACKET; HANGING
61	3702800	BRACKET; FIELD HANGING
101	0121A01301	BRKT, LEFT FILTER LRG
111	0121A00042	BRKT, LRG TOP FILTER
121	3701242	DRIP SHIELD LRG
131	3701243	BKT, LRG RETAINER
141	0121A01302	BRKT, RIGHT FILTER
151	0160L00388	AIR FILTER 18X20X1
201	0161A00068	PLUG-BUTTON (QTY 2)
251	0121A01163	FILTER BRACKET (QTY 2)

## Expanded Model Nomenclature

M1 - AWUT310516AA
M2 - AWUT310516AB
M3 - AWUT310516AC
M4 - AWUT310816AA
M5 - AWUT310816AB
M6 - AWUT321016AA
M7 - AWUT321016AB
M8 - AWUT370516AA
M9 - AWUT370516AB
M10 - AWUT370816AA
M11 - AWUT370816AB
M12 - AWUT371016AA
M13 - AWUT371016AB

# EVAPORATOR COIL ASSEMBLY

## EVAPORATOR COIL ASSEMBLY



# EVAPORATOR COIL ASSEMBLY

Ref. Part No: No:	Description:	Ref. Part No: No:	Description:
----------------------	--------------	----------------------	--------------

## Image 1:



31	0270A01286	COIL TUBING ASSY (M1, M2, M3, M4, M5, M6, M7)
31	0270A01287	COIL TUBING ASSY (M8, M9, M10, M11, M12, M13)
41	0121A01157	PLATE, CENTER TIE
51	0121A01223	PLATE, BOTTOM TIE
61	3701243	BKT, LRG RETAINER
71	3701500	ACCESS PANEL, DRAIN LRG
81	BT1700051	CAP; LG. AIR HANDLER BOTTOM
91	3702105	TOP WRAPPER LRG
141	0164A00002	GROMMET
171	0121A01164	TXV BRACKET
201	0151M00066	VALVE, TXV R-410A BOOSTER CHG
251	0161R00021	DRAIN PAN LARGE
261	0121A01257	GUTTER RIGHT, WRAPPER ASSY
271	0121A01258	GUTTER LEFT, WRAPPER ASSY
281	3701805	BRACKET, OFFSET (QTY 2)
NS	0128R00007	DRAINPAN SHIELD
NS	B1787000	VALVE CORE

## Expanded Model Nomenclature


M1 - AWUT310516AA
M2 - AWUT310516AB
M3 - AWUT310516AC
M4 - AWUT310816AA
M5 - AWUT310816AB
M6 - AWUT321016AA
M7 - AWUT321016AB
M8 - AWUT370516AA
M9 - AWUT370516AB
M10 - AWUT370816AA
M11 - AWUT370816AB
M12 - AWUT371016AA
M13 - AWUT371016AB

# HEATER PANEL ASSEMBLY

## HEATER PANEL ASSEMBLY



## CONTROL PANEL ASSEMBLY



NOTE: CONTROL PANEL ASSEMBLY  
MAY DIFFER FROM WHAT IS SHOWN



# HEATER PANEL ASSEMBLY

## Ref. Part

No: No:

Description:

## Ref. Part

No: No:

Description:

### Image 1:


11	BT1420032	ELEMENT, 4.8 KW LARGE HEATER (M1, M2, M3, M8, M9)
11	BT1420040	ELEMENT, 7.3KW HEATER (M4, M5, M10, M11)
11	BT1420039	ELEMENT, 9.8KW HEATER (M6, M7)
21	0130A00091	DISCONNECT, PULL OUT (M1, M2, M3, M4, M5, M6, M7, M8, M9, M10, M11)
31	0130M00138	TRANSFORMER, 208/230, 24V
41	CONT2P040024V	CONT, 2 POLE, 40 AMP, 24 VAC
221	0130M00488	FUSE HOLDER
NS	3700804	PANEL, TOP HEATER

### Expanded Model Nomenclature

M1 - AWUT310516AA  
 M2 - AWUT310516AB  
 M3 - AWUT310516AC  
 M4 - AWUT310816AA  
 M5 - AWUT310816AB  
 M6 - AWUT321016AA  
 M7 - AWUT321016AB  
 M8 - AWUT370516AA  
 M9 - AWUT370516AB  
 M10 - AWUT370816AA  
 M11 - AWUT370816AB  
 M12 - AWUT371016AA  
 M13 - AWUT371016AB

# BLOWER ASSEMBLY

## BLOWER ASSEMBLY



# BLOWER ASSEMBLY

Ref. Part No: No:	Description:	Ref. Part No: No:	Description:
----------------------	--------------	----------------------	--------------

## Image 1:

61	3702701	ANGLE, 8.531" BLOWER (M1, M2, M3, M12, M13)
71	3760202	BLOWER HOUSING
111	0131M00504	MOTOR PROGRAMMED (M1, M2)
111	0131M00505	MOTOR PROGRAMMED (M4, M6)
111	0131M00506	MOTOR PROGRAMMED (M8, M10, M12)
111	0131M01020	MOTOR PROGRAMMED (M3)
111	0131M01021	MOTOR PROGRAMMED (M5, M7)
111	0131M01022	MOTOR PROGRAMMED (M9, M11, M13)
281	3739002	BLOWER CUT-OFF LRG
291	0121M00038	MOTOR MOUNT BAND
301	B1376861	MOTOR MOUNT ARM (QTY 3)
311	0150M00058	WHEEL, BLOWER
321	M0250565	TC SCREW 1.25" (QTY 3)
341	B1392918	WASHER, FLAT 1/4 ID X 1 OD (QTY 3)
351	B1393323	MACHINE SCREW HWH 1/4-20 X 1-1/2 BZ
361	B1393800	LOCKNUT, NYLON, INSERT 1/4
391	3702705	BLOWER ANGLE 10"
NS	0130A00021	X-13 LOW VOLTAGE WIRE HARNESS
NS	0130M00022	X-13 POWER HARNESS

## Expanded Model Nomenclature

M1 - AWUT310516AA
M2 - AWUT310516AB
M3 - AWUT310516AC
M4 - AWUT310816AA
M5 - AWUT310816AB
M6 - AWUT321016AA
M7 - AWUT321016AB
M8 - AWUT370516AA
M9 - AWUT370516AB
M10 - AWUT370816AA
M11 - AWUT370816AB
M12 - AWUT371016AA
M13 - AWUT371016AB