


QwikCheck® Acid Test Kit

QwikCheck® is ideal for preventive maintenance checks and for verifying proper acid clean up. The QwikCheck® indicator paper is golden yellow before testing and will turn pink or red upon being exposed to as little as 1 part per million (PPM) of acid.

Perform a Qwik acid test on operating systems. Ideal for preventative maintenance checks or for verifying proper acid clean-up after a compressor burn-out / change-out.

- ▶ 2-Second Refrigeration Acid Test
- ▶ Tests to ARI-700 limit of 1 PPM
- ▶ Tests for Inorganic Acid (including POE)
- ▶ Meets EPA Venting Rules



Directions:

1. Insert the valve core depressor into the center of the suction side of the vapor service valve while the system is operating.
2. Allow vapor to flow through the QwikCheck® for 2-seconds. If the indicator paper does not change color, hold for another 2-seconds. If the indicator paper still does not change color, inorganic acid was not detected.
3. If the indicator paper changes color slightly, add QwikShot® to remove the acid. If the paper turns red, the acid level is very high. Change the oil and the filter-drier, and then add QwikShot®.

For more details or information about QwikCheck® visit www.qwik.com

QwikCheck® 2-Second Acid Test Kit - Part # QT2000
U.S. Patents #6,514,765 & #5,770,048

QwikProducts™ is a trademark of Mainstream Engineering Corporation®. QwikCheck®, QwikShot® and Mainstream Engineering Corporation® are registered trademarks of Mainstream Engineering Corporation, Rockledge, Florida 32955, (321) 631-3550 All QwikProducts™ are made in the USA. © 2016 Mainstream Engineering Corporation

